

Form 3160-5  
(June 1990)

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

5. Lease Designation and Serial No.

NM 0559175

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

Dagger Draw 30N Com

8. Well Name and No.

1

9. API Well No.

30-015-20305

10. Field and Pool, or Exploratory Area  
No. Dagger Draw Penn

11. County or Parish, State

Eddy

**SUBMIT IN TRIPLICATE**

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Conoco, Inc.

3. Address and Telephone No.

10 Desta Dr. Ste 100W, Midland, TX 79705 (915) 686-6548

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FNL & 660' FWL  
Sec. 30, T-19S, R-25E

**12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA**

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other

- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

This well will be P&A'd according to the following procedure:

1. Set CIBP at 7622'
2. Circulate mud
3. Spot 10 sxs cement from 7622'-7562'.
4. Perforate 7" casing at 3450'
5. Set cement retainer at 3400' and pump 40 sxs of cement
6. Spot 10 sxs on top of retainer
7. Spot 50 sxs cement from 1400' and tag cement top
8. Perforate 7" casing at 980', set retainer at 930', and pump 50 sxs cement
9. Spot 10 sxs cement on top of retainer
10. Spot 10 sxs from 50' to surface
11. Install marker

CASING: 13 3/8" set at 930' and 7" set at 7879'

Verbal Approval given by Joe Laxra 6/2/95

RECEIVED  
JUL 06 1995  
OIL CON. DIV.  
DIST. 2

14. I hereby certify that the foregoing is true and correct

Signed

*Joe G. Lara*

Title

Sr. Conservation Coordinator

Date

6/2/95

(This space for Federal or State office use)

(ORIG. SEC.) JOE G. LARA

PETROLEUM ENGINEER

Approved by

Title

Date

6/29/95

Conditions of approval, if any: