

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)copy to SF
Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM7039

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

Northwest Indian Basin Unit

8. FARM OR LEASE NAME

9. WELL NO.

1-Y

10. FIELD AND POOL, OR WILDCAT

Northwest Indian Basin

11. SEC., T., R., M., OR BLK. AND MORROW
SURVEY OR AREA

Sec. 28 T20S R23E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☐ GAS WELL ☒ OTHER

APR 29 1977

2. NAME OF OPERATOR

Charles A. Dean

3. ADDRESS OF OPERATOR

503 Gulf Bldg, Midland, Texas 79701

O.C.C.
ARTESIA, OFFICE4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

2030' FSL & 1980' FWL Section 28, T20S, R23E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4229 GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐

(Other)

PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☒(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent
to this work.)*Perfs: 8747-61 Production Csg 4 1/2" 13.5# set @ 8932'
8 5/8" set @ 1993'
13 3/8" set @ 816' circ. cmt.

1. Set CIBP @ 8515' cap with 5 sx cement on top
2. Circulate hole with brine containing 25 sacks gel per 100 barrels
3. Shot 4 1/2" casing 5886' pulled same set 25 sx cement plug 5935'-5785'
4. Set 50 sx cement plug (150') from 5500'-5350'
5. Set 35 sx cement plug (100') at 3500'-3400'
6. Set 35 sx cement plug (100') at base of 8 5/8' @ 1993' (2050-1950)
7. Set 20 sx cement plug at surface
8. Weld dry hole marker
9. Clear Location.

RECEIVED

OCT 08 1976

U.S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Petroleum Engineer

DATE 10/7/76

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side