

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. Cons. Division
811 S. 1st
Artesia, NM 88202-2834

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.

NM-26057

6. If Indian, Allottee or Tribe Name

If Unit or CA, Agreement Designation

8. Well Name and No.

Atwein B Fed Com #1

API Well No.

30-015-25404

10. Field and Pool, or Exploratory Area

Und. Atoka-Morrow

11. County or Parish, State

Eddy Co., NM

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different year.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

YATES PETROLEUM CORPORATION

(505) 748-5471

3. Address and Telephone No.

105 South 4th St., Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FSL & 1980' FWL of Section 12-T19S-R23E (Unit N, SESW)

CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☒ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to abandon perforations 6186-6562' (Cisco) and recomple to Atoka/Morrow as follows:

1. Flow Cisco perforations 6186-6562' down. Load tubing and casing.
2. Release packer & TOOH with packer and tubing. NOTE: Packer may be a permanent type packer. If it is a permanent packer, will drill out packer. Cisco perms 6186-6562' may be squeezed before drilling packer.
3. Perforate 8390-8408' (Lower Morrow), acidize & frac as necessary for production.
4. If Lower Morrow is not productive, set CIBP or RBP above top perf to abandon. Pressure test plug.
5. Perforate 8198-8239' (Morrow), acidize & frac as necessary for production.
6. Swab test.
7. Set RBP above top Morrow perf to temporarily abandon perms. 8198-8239'.
8. Perforate 7944-7973' (Atoka), acidize and frac as necessary.
9. Swab test.
10. Pull all tools from well. RIH with packer & tubing.
11. Place well into production.

14. I hereby certify that the foregoing is true and correct

Signed

Title Operations Technician

Date May 6, 1999

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side