

SANTA FE ENERGY OPERATING PARTNERS, L.P.
OPERATIONS PLAN
Parkway 30 Federal No. 1

1. Drill a 24" hole to 350'±.
2. Run 18 5/8" 87.5 ppg H-40 ST&C casing. Cement with 650 sacks Class "C" cement containing 2% Calcium Chloride. Run centralizers on every other joint above shoe. Apply thread lock to bottom two joints, float collar and guide shoe.
3. Wait on cement eight hours.
4. Test casing to 600 psi.
5. Drill a 17 1/2" hole to 1150'.
6. Run 13 3/8" 48.0 ppg H-40 ST&C casing. Cement with 700 sacks Howco lite containing 12 ppg salt and 1/4 ppg flocele followed by 250 sacks Class C with 2% CaCl₂. Run guide shoe on bottom and float collar one joint off of bottom. Centralize every other joint for bottom 400' of casing and place two centralizers in surface casing. Thread lock bottom 2 joints.
7. Wait on cement eight hours.
8. Test casing to 600 psi.
9. Drill 12-1/4" hole to 3200'.
10. Run 8 5/8" 24.0 and 32.0 ppg K-55 ST&C casing. Cement with 690 sacks 65/35 Cl C Poz with 6% gel and 15% salt followed by 350 sacks Class C w/2% CaCl₂.
11. Wait on cement 8 hours.
12. Nipple up 3000 psi double ram BOP.
13. Test BOP and casing to 1500 psi.
14. Drill 7 7/8" hole to 5150'.
15. Log.
16. Run 5 1/2", 15.5 ppg, K-55, ST&C casing.
17. Cement with 500 sacks Cl C w/0.5% fluid loss additive.

Exhibit A
Santa Fe Energy Operating Partners, LP
Parkway 30 Federal No. 1
Section 30, T19S-R30E
Eddy County, New Mexico