

UNITED STATES NM 88210
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 8419

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different depth. Use "APPLICATION FOR PERMIT" for such proposals.)

RECEIVED

1. OIL WELL GAS WELL OTHER

NOV 15 1982

2. NAME OF OPERATOR
PETROLEUM DEVELOPMENT CORPORATION

O. C. D.

3. ADDRESS OF OPERATOR
9720-B Candelaria, N.E., Albuquerque, N.M., 87112
ARTESIA, OFFICE

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Arroyo Federal

9. WELL NO.

#1

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)
At surface

10. FIELD AND POOL, OR WILDCAT

Loafer Draw-Strawn Gas

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 26, T21S, R22E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4,224' G.L. / 4,240' K.B.

12. COUNTY OR PARISH

Eddy

13. STATE

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF
FRACTURE TREAT
SHOOT OR ACIDIZE
REPAIR WELL

PULL OR ALTER CASING
MULTIPLE COMPLETE
ABANDON*
CHANGE PLANS

WATER SHUT-OFF
FRACTURE TREATMENT
SHOOTING OR ACIDIZING
(Other)

REPAIRING WELL
ALTERING CASING
ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

T.D. 9,630'

PBTD 8,947'

Perforation: 5 1/2", 17# casing @ 8,399' - 8,415'. Produced gas.

Approx. 2/83:

- * -> 1. Cut 5 1/2" casing @ 7,000' and P.O.H.
- 2. Set 25 sack plug: 8,310' - 8,530'. Tag or test plug
- 3. Set 40 sack plug: 6,950' - 7,050' and tag.
- 4. Set 70 sack plug: ~~6,280' - 6,375'~~ and tag. 5160' - 5060'. Tag or test plug
- 5. Set 40 sack plug: 2,850' - 2,950'.
- 6. Set 40 sack plug: 1,950' - 2,050'. Tag or test plug.
- 7. Set 40 sack plug: 150' - 250'.
- 8. Set 15 sack plug: at surface.
- 9. Install dry-hole marker.

* 150' cmt. plug 8900' - 8750'

RECEIVED

NOV 9 1982

OIL & GAS
MINERALS MGMT. SERVICE
ROSWELL, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED Gary L. Roberts
Gary L. Roberts

TITLE Field Manager

DATE 11/3/82

(This space for Federal or State use only)
APPROVED BY Peter W. Chester
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE _____

NOV 10 1982

FOR
JAMES A. GILLHAM
DISTRICT SUPERVISOR

*See Instructions on Reverse Side