

C/SF

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

RECEIVED
MAR 12 1982

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER		7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR Gulf Oil Corporation ✓		8. FARM OR LEASE NAME Cardenas Federal Com
3. ADDRESS OF OPERATOR P. O. Box 670, Hobbs, NM 88240		9. WELL NO. 1
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1680' FNL & 1980' FWL		10. FIELD AND POOL, OR WILDCAT Bone Springs
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3228' GL	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec 29-T20S-R28E
		12. COUNTY OR PARISH Eddy
		13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data


NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input checked="" type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Circulate abandonment mud 5800'-4800'. Set CIBP at 5690'. Circulate abandonment mud 5690' - surface. Test CIBP 500#. Cap CIBP with 35' cement. Cut casing 4870'. Set 100' cement plug 4920'-4820'. Spot 100' plug 3800'-3700'. Spot 100' plug 2950'-2850'. Wait on Cement. Spot 10 sack surface plug. Install well marker; clear and clean location. P&A 8-23-81.

Posted ID-2
P+A
3-19-82



OIL & GAS
U.S. GEOLOGICAL SURVEY
ROSWELL, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED *P.P.P.*
APPROVED
(This space for Federal or State office use)
(Orig. Sgd.) PETER W. CHESTER
APPROVED BY
CONDITIONS OF APPROVAL
FOR
JAMES A. GILLHAM

TITLE: Area Engineer DATE: 9-16-81
TITLE: DATE:

MAR 11 1982