

Pardue 34 Com #1
(Attachment to Form C-103)

PROCEDURE: P & A

- 10/27/93 **FIRST REPORT**
ND tree, NU BOP, POH w/ tbg. RIH w/ tbg open ended, tag fish @ 5,413', pump 65 sxs of class "C" cmt. POH w/ 30 stds, WOC, SDFN.
- 10/28/93 TIH w/ tbg & tag plug @ 4,995'. ND BOP, ND csg flange, bleed down braiden head, well on 7" pull nipple, cut 7" @ 4,800'.
- 10/29/93 POH w/ tbg & 35 jts of 7" buttress csg, SDFN.
- 10/30/93 POH & lay down 7" csg, had a hard time breaking out jts, csg was over torqued. RIH w/ tbg to 4,850', pump 90 sxs of class "C" cmt. POH w/ 30 stds of tbg, WOC, SDFW.
- 10/31/93 SDFW.
- 11/02/93 Tag stub plug @ 4,600'. POH to 2,600', pump 100 sxs of class "C" cmt w/ 2% CaCl, POH w/ 15 stds. WOC 4 hrs, TIH & tag plug @ 2,335'.
- 11/03/93 Install dry hole marker. Spot 100 sxs of class "C" cmt from 600' to 300', ND BOP & wellhead, spot 10 sxs surface plug, ND plugging equipment. RD pulling unit. Job complete. Wellbore is P&A'd.