

submitted in lieu of Form 3160-5

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
Sundry Notices and Reports on Wells
RECEIVED

COPY

070 FARMINGTON NM

1. Type of Well
Gas

5. Lease Number
NM03717-A
6. If Indian, All. or
Tribe Name

2. Name of Operator
Norman L. Gilbreath

7. Unit Agreement Name


3. Address & Phone No. of Operator
P. O. Box 208, Aztec, NM 87401

8. Well Name & Number
Ben Jones #1
API Well No.
30-045-08392

Location of Well, Footage, Sec., T, R, M

900' FNL and 1100' FEL, Sec. 13 T-29-N, R-11-W,

10. Field and Pool
Aztec Pictured Cliffs
11. County & State
San Juan County, NM



12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA

Type of Submission	Type of Action	
<input type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
<input checked="" type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut off
	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
		<input type="checkbox"/> Other -

13. Describe Proposed or Completed Operations

A-Plus Well Service plugged and abandoned this well for Norman L. Gilbreath, on January 19, 2004 per the attached Plug and Abandonment Report.

14. I hereby certify that the foregoing is true and correct.

Signed Norman L. Gilbreath Title Operator Date 3-4-2004
Norman L. Gilbreath Operator

(This space for Federal or State Office use)
APPROVED BY _____ Title _____ Date _____
CONDITION OF APPROVAL, if any:

ACCEPTED FOR RECORD

NMOCD

AUG 10 2004

FARMINGTON FIELD OFFICE
BY SM

A-PLUS WELL SERVICE, INC.

P.O. BOX 1979
Farmington, New Mexico 87499
505-325-2627 * fax: 505-325-1211

Norman L. Gilbreath

January 21, 2004

Ben Jones #1

Page 1 of 1

900' FNL & 1100' FEL, Section 13, T-29-N, R-11-W

San Juan County, NM

Plug and Abandonment Report

Lease Number: NM03717-A

API #30-045-08392

notice

Cementing Summary:

Plug #1 with CIBP at 2000' spot 50 sxs cement above CIBP up to 1548' to isolate the Pictured Cliffs interval and cover the Fruitland top.

Plug #2 mix and pump 113 sxs cement, squeeze 62 sxs outside 5-1/2" casing from 960' to 750' and leave 51 sxs inside casing up to 499' to cover the Kirtland and Ojo Alamo tops.

Plug #3 with 50 sxs cement pumped down the 5-1/2" casing from 157' to surface, circulate good cement out bradenhead.

Plug and Abandonment Summary:

Notified NMOCD 01/14/04 @ 10:00 AM

1/14/04 Held Company safety meeting at Safety Alliance. Travel to rig. Held JSA. MOL. Set anchors with backhoe and RU. Install pit liner and fence pit. SDFD.

1/15/04 Held JSA. Open up well, no pressures. ND wellhead. Strip on 5-1/2" head and 8-5/8" flange and BOP; test. Change out tools for 1" tubing. TOH and LD 79 joints 1" tubing and 2 - 8' subs. RU A-Plus wireline truck. Round-trip 5-1/2" gauge ring to 2015'. GIH and set 5-1/2" PlugWell Wireline CIBP at 2000'. Change out tools for 1-1/4" tubing. Shut in well. SDFD.

1/16/04 Held JSA. Tally, PU, and TIH with A-Plus' 1-1/4" workstring; tag CIBP at 2000'. Load and circulate well clean with 47 bbls of water. Pressure test casing to 500# for 5 minutes. Plug #1 with CIBP at 2000' spot 50 sxs cement above CIBP up to 1548' to isolate the Pictured Cliffs interval and cover the Fruitland top. TOH and LD tubing. GIH and perforate 3 squeeze holes at 960'. Plug #2 mix and pump 113 sxs cement, squeeze 62 sxs outside 5-1/2" casing from 960' to 750' and leave 51 sxs inside casing up to 499' to cover the Kirtland and Ojo Alamo tops. Shut in well. SDFD.

11/19/04 Held JSA. GIH with wireline and tag cement at 487'. PUH and perforate 3 squeeze holes at 157'. Establish circulation out bradenhead with 3 bbls of water. Plug #3 with 50 sxs cement pumped down the 5-1/2" casing from 157' to surface, circulate good cement out bradenhead. ND BOP. Dig out and cut off wellhead. Cement at surface. Mix 5 sxs cement and install P&A marker. RD and MOL. No NMOCD or BLM representatives were on location.