Form 3160-5 (August 2007)

UNITED STATES DEPARTMENT OF THE INTERIOR

FORM APPROVED OMB No. 1004-0137

	BUREAU OF LAND MAN		IAR OF		: July 31, 2010
		Farm	ngton F		SF-0777 <u>6</u> 4
SUN	DRY NOTICES AND REPO	6! If Indian, Allottee or Tribe	Name		
Do not use	this form for proposals t well. Use Form 3160-3 (A	<u> </u>	RCVD MAR 14:13		
SU	BMIT IN TRIPLICATE - Other ins	tructions on page 2.		7. If Unit of CA/Agreement,	Name and/or No.
1. Type of Well					DIST. 3
Oil Well	Gas Well Other			8. Well Name and No.	UMACHER 11
2. Name of Operator		<u> </u>		9. API Well No.	
Burling	ton Resources Oil & Gas	Company LP		30-	045-09480
3a. Address		3b. Phone No. (include area	•	10. Field and Pool or Explora	atory Area
PO Box 4289, Farmingto	on, NM 87499	(505) 326-97	'00	Ba	asin Dakota
4. Location of Well (Footage, Sec., T., F.	k.,M., or Survey Description)			11. Country or Parish, State	
Surface UNIT K (NES)	W), 1650' FSL & 1650' FW	L, Sec. 18, T30N, R1	WOI	San Juan	, New Mexico
12. CHECK T	HE APPROPRIATE BOX(ES)	TO INDICATE NATUR	RE OF NO	I TICE, REPORT OR OTI	HER DATA
TYPE OF SUBMISSION		TYP	E OF AC	TION	
X Notice of Intent	Acidize	Deepen	P	roduction (Start/Resume)	Water Shut-Off
	Alter Casing	Fracture Treat	R	eclamation	Well Integrity
Subsequent Report	Casing Repair	New Construction	XR	ecomplete	Other
	Change Plans	Plug and Abandon	Πī	emporarily Abandon	
Final Abandonment Notice	Convert to Injection	Plug Back	Π̈́ν	Vater Disposal	
13. Describe Proposed or Completed Op	peration: Clearly state all pertinent de	tails, including estimated sta	rting date of	any proposed work and appro	ximate duration thereof.
	onally or recomplete horizontally, give	-			
	ork will be performed or provide the		-	• •	•
	red operations. If the operation result	· ·	-		
determined that the site is ready fo	Abandonment Notices must be filed	only after all requirements, i	ncluding rec	lamation, have been complete	d and the operator has
determined that the site is ready to	Timal hispection.)				
-	e this well in the Mesaverd rde plat and procedure.			_	
of the normal-Tear Drop	does not anticipate this activities (working area) per the B	BLM FFO Bare Soil F	Reclamat	ion Procedures; Par	t A:3 - Location of

Existing and/or Proposed Production Facilities, Page 16. Burlington Resources realizes that bare soil disturbance greater than 0.10 acre outside the working area will have to be revegetated as dictated by Vegetation Reclamation

Procedure A, Page 6, within 180 days to accommodate optimal reseeding time.

- (ontact this office i)	remedal action is required
_ Contact this office i) _ Submit CAZ to ACENCIOS for REVI	IBW prin to pents
14. I hereby certify that the foregoing is true and correct. Name (Printed/Typed) DENISE JOURNEY	Regulatory Technician
Signature Dennis Journey	2/28/2013 Date
THIS SPACE FOR FEDE	DERAL OR STATE OFFICE USE
Approved by Lunbukl	Title Petr-Eng. Date 3/12/13
Conditions of approval, if any, are attached. Approval of this notice does not warrant or	or certify 3
that the applicant holds legal of equitable title to those rights in the subject lease which	th would Office
entitle the applicant to conduct operations thereon.	

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

District IV

District I 1625 N. French Dr., Hobbs, NM 88240 Phone: (575) 393-6161 Fax: (575) 393-0720 District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720 District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone: (505) 334-6178 Fax: (505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone: (505) 476-3470 Fax: (505) 476-3462

State of New Mexico

Energy, Minerals and Natural Resources

Oil Conservation Division 1220 S. St Francis Dr. Santa Fe, NM 87505

Form C-102 August 1, 2011

MAR 01 2013

Farmington Field Office

1. API Number -045-09480	2. Pool Code 72319	3. Pool Name BLANCO-MESAVERDE (PRORATED O				
4. Property Code	5. Prope SCHUN	6. Well No.				
7. OGRID No. 14538	8. Oper BURLINGTON RESOURCE	9. Elevation 6325				

10. Surface Location


UL - Lot	Section	Township	Range	Lot Idn	Feet From	N/S Line	Feet From	E/W Line	County
K	18	30N	10W		1650	S	1650	W	SAN JUAN

11. Bottom Hole Location If Different From Surface

RCVD MAR 14'13

UL - Lot	Section	То	ownship	Range	Lot	Idn	Feet From	N/S L	ine	Feet From	E/W Line	County
12. Dedicated Acres 309.53		13. J	oint or Infill		14	. Consolidation (Code	j		15. Order No.	_CONS.DIV. DIST. 3	

NO ALLOWABLE WILL BE ASSIGNED TO THIS COMPLETION UNTIL ALL INTERESTS HAVE BEEN CONSOLIDATED OR A NON-STANDARD UNIT HAS BEEN APPROVED BY THE DIVISION



OPERATOR CERTIFICATION

I hereby certify that the information contained herein is true and complete to the best of my knowledge and belief, and that this organization either owns a working interest or unleased mineral interest in the land including the proposed bottom hole location(s) or has a right to drill this well at this location pursuant to a contract with an owner of such a mineral or working interest, or to a voluntary pooling agreement or a compulsory pooling order heretofore entered by the division.

E-Signed By: January Title: REGULATORY TECHNICIAN

Date: 2/5/2013

SURVEYOR CERTIFICATION

I hereby certify that the well location shown on this plat was plotted from field notes of actual surveys made by me or under my supervision, and that the same is true and correct to the best of my belief.

Surveyed By: D.O. Vilven Date of Survey: 5/12/1953



Schumacher #11

Unit K, Section 18, Township 30N, Range 10W

API#: 3004509480

Mesa Verde Recompletion

1/31/2013

Procedure:

- 1. MIRU service rig. TOOH and lay down current production tubing string.
- 2. Wireline set a 5-1/2" composite bridge plug @ 6,950' above the existing Dakota completion.
- 3. Run a GR/CCL/CBL correlation log. The GR will be used to pick formation tops and the CBL will be used to pick the TOC.
- 4. ND well head & NU frac valve. Pressure test frac valve and casing.
- 5. Complete the Mesa Verde formation.
- 6. Flow back well to clean-up.
- 7. RIH with wireline and set a composite bridge plug above top perf.
- 8. TIH with a mill and drill out the top composite plug. Flow test MV up the casing.
- 9. Drill out the CBP set above the DK @ 6,950' and clean out to PBTD @ 7,376'.
- 10. Flow test entire wellbore up the casing.
- 11. TIH and land production tubing.
- 12. Release service rig and turn over to production.

