Form 3160-5 (August 1999)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED
OMB NO. 1004-0135
Expires: November 30, 2000

SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to dril or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals.					Lease Serial No. NMNM03153 If Indian, Allottee or Tribe Name	
SUBMIT IN TRIPLICATE - Other instructions on reverse side.					7. If Unit or CA/Agreement, Name and/or No.	
Type of Well ☐ Oil Well ☐ Other					8. Well Name and No. O H RANDALL 7E	
2. Name of Operator XTO ENERGY INC	HOLLY PERKINS E-Mail: Regulatory@xtoenergy.com			9. API Well No. 30-045-24750-00-S2		
3a. Address 2700 FARMINGTON AVE., BL FARMINGTON, NM 87401	3b. Phone No. (include area code) Ph: 505.324.1090 Ext: 4020 Fx: 505.564.6700			10. Field and Pool, or Exploratory BASIN FRUITLAND COAL		
4. Location of Well (Footage, Sec., 7 Sec 15 T26N R11W NESW 19 36.48486 N Lat, 107.99391 W	11. County or Parish SAN JUAN CO					
12. CHECK APPR	ROPRIATE BOX(ES) TO) INDICATE	NATURE OF	NOTICE, RI	EPORT, OR OTHE	R DATA
TYPE OF SUBMISSION	TYPE OF ACTION					
Notice of Intent	□ Acidize	□ Dee	Deepen		ion (Start/Resume)	☐ Water Shut-Off
	☐ Alter Casing	□ Frac	ture Treat	□ Reclam	ation	☐ Well Integrity
☐ Subsequent Report	Casing Repair	□ New	Construction	□ Recomp	olete	□ Other
☐ Final Abandonment Notice	☐ Change Plans	⊠ Plug	g and Abandon	☐ Tempor	arily Abandon	
	Convert to Injection	□ Plug	g Back	□ Water I	Disposal	
Attach the Bond under which the wor following completion of the involved testing has been completed. Final Abdetermined that the site is ready for fix XTO Energy Inc. plans to P&A	operations. If the operation re- condomment Notices shall be fil inal inspection.) A this well per the attache true and correct.	sults in a multiped only after all	le completion or requirements, incl	MAY 2003	new interval, a Form 316 n, have been completed,	0-4 shall be filed once
Co	# Electronic Submission For XTO E Emmitted to AFMSS for pro	ENERGY INC. I	sent to the Far	minaton	-	
Name (Printed/Typed) DARRIN STEED			Title REGULATORY SUPERVISOR			
Signature (Electronic S	ubmission)		Date 05/27	/2003		
	THIS SPACE FO	R FEDERA	L OR STATE	OFFICE U	SE	Aleger Wiles
Approved By STEPHEN MASON			TitlePETROLEUM ENGINEER		Date 05/28/2003	
Conditions of approval, if any, are attached. Approval of this notice does not warrant or ertify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.			Office Farmington			
itle 18 U.S.C. Section 1001 and Title 43 States any false, fictitious or fraudulent s	U.S.C. Section 1212, make it a statements or representations as	crime for any p to any matter w	erson knowingly a	and willfully to m	ake to any department or	agency of the United

O.H. RANDEL #7E SEC 15, T 26 N, R 11 W SAN JUAN COUNTY NEW MEXICO

Formation:

Fruitland Coal

Surface csg:

8-5/8", 24#, J-55 csg @ 761'. Cmt'd w/550 sx cl "B" cmt w/2% CaCl₂ &

1/4 #/sx Flocele. Circ cmt to surf.

Production csg:

4-1/2", 10.5#, K-55 csg @ 6,245'. DV tool @ 4,425'. Cmt'd 1st stage w/190 sx 50/50 POZ mix w/2% gel & 1/4 #/sx Flocele. Tailed in w/210 sx cl "B" cmt w/1/4 #/sx Flocele. Did not circ cmt to surf. Cmt'd 2nd stage w/400 sx 50/50 POZ mix w/6% gel & 12-1/2#/sx Gilsonite. Tailed in w/665 sx 50/50 POZ mix w/2% gel & 12-1/2#/sx Gilsonite. Circ cmt

to surf.

Tbg:

3 - 2-3/8" tbg subs (10', 10' & 2'), 50 jts 2-3/8" tbg, SN & 6' x 2-3/8"

perf sub & BPMA. EOT @ 1,679'. SN @ 1,641'.

Perfs:

FC: 1,620'-1,636' w/4 JSPF

DK: 6,198'-6,209'. Sqz'd 9/14/99

Current Status:

SI.

- 1 Notify BLM and NMOCD of plugging operations.
- 2. MIRU PU. MI 4 joints 2-3/8" tubing. Check and record tubing, casing and bradenhead pressures.
- 3. Blow well down and kill well with fresh water.
- 4. ND WH. NU and pressure test BOP.
- 5. PU and TIH ±1,770'. Circulate wellbore with fresh water.
- 6. TOH with tubing to 1,724'. Spot a 35 sx type II cement plug inside the casing from 1,724'-1,348' to cover the top Pictured Cliffs formation and the Fruitland Coal formation.
- 7. TOH with tubing to ±811'. Reverse circulate tubing clean.
- 8. WOC. TIH and tag cement top.
- 9. TOH and lay down tubing to 811'.
- 10. Spot a 26 sx type II cement plug inside the casing from 811'-530' to cover the top of the Kirtland, the Ojo Alamo formation and 8-5/8" casing shoe. TOH and lay down tubing to 50'.
- 11. Pressure test bradenhead to 300 psig. If bradenhead holds, spot at 10 sx type II cement plug inside casing from 50' to surface. TOH and lay down tubing. If bradenhead does not hold, perforate the casing at the appropriate depth and circulate cement to surface.
- 12. Cut off wellhead and install P&A marker. Cement marker with 10 sx cement. RDMO PU.