

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

FORM APPROVED
OMB No. 1004-0137
Expires: July 31, 2010

MAY 18 2016

SUNDRY NOTICES AND REPORTS ON WELLS Farmington Field Office
Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals. Bureau of Land Management

5. Lease Serial No.

SF-047020-B

6. Indian Name or Tribe Name

SUBMIT IN TRIPLICATE - Other instructions on page 2.

1. Type of Well

☐ Oil Well

☒ Gas Well

☐ Other

7. If Unit of CA/Agreement, Name and/or No.

8. Well Name and No.

Congress 6E

2. Name of Operator

Burlington Resources Oil & Gas Company LP

9. API Well No.

30-045-24838

3a. Address

PO Box 4289, Farmington, NM 87499

3b. Phone No. (include area code)

(505) 326-9700

10. Field and Pool or Exploratory Area

Otero Chacra

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Surface Unit O (SWSE), 990' FSL & 1790' FEL, Sec. 35, T29N, R11W

11. Country or Parish, State

San Juan, New Mexico

12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☐ Acidize

☐ Alter Casing

☐ Casing Repair

☐ Change Plans

☐ Convert to Injection

☐ Deepen

☐ Fracture Treat

☐ New Construction

☒ Plug and Abandon

☐ Plug Back

☐ Production (Start/Resume)

☐ Reclamation

☐ Recomplete

☐ Temporarily Abandon

☐ Water Disposal

☐ Water Shut-Off

☐ Well Integrity

☐ Other

13. Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 must be filed once Testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.)

The subject well is part of the proposed Mangum SRC 1 P&A program agreed to with the NMOCD. The attached revised procedure replaces the procedure filed with the P&A NOI submitted on 3/30/2016.

Notify NMOCD 24 hrs
prior to beginning
operations

OIL CONS. DIV DIST. 3

JUN 01 2016

BLM'S APPROVAL OR ACCEPTANCE OF THIS
ACTION DOES NOT RELIEVE THE LESSEE AND
OPERATOR FROM OBTAINING ANY OTHER
AUTHORIZATION REQUIRED FOR OPERATIONS
ON FEDERAL AND INDIAN LANDS

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

14. I hereby certify that the foregoing is true and correct. Name (Printed/Typed)

Dollie L. Busse

Title Regulatory Technician

Signature

Dollie L. Busse

Date

5/16/16

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

Jack Lawrence

Title

PE

Date

5/31/16

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

FFO

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

ConocoPhillips
CONGRESS 6E
Expense - P&A

Lat 36° 40' 40.512" N

Long 107° 57' 27.72" W

PROCEDURE

This project requires the use of a steel tank to handle waste fluids circulated from the well and cement wash up.

Prior to commencing abandonment operations, ensure that the bradenhead valve is dug out and properly plumbed to the surface. Record the casing, intermediate and bradenhead pressures with an appropriately ranged gauge. Contact the Engineer if bradenhead pressure is present (per Exhibit "A-3").

1. Hold pre-job safety meeting. Comply with all NMOCD, BLM, and COP safety and environmental regulations. Test rig anchors prior to moving in rig. Before RU, run slickline to ensure tubing is clear. If an obstruction is found, set a locking 3-slip stop in the tubing.

2. MIRU workover rig. Check casing, tubing, and bradenhead pressures and record them in WellView. If there is pressure on the BH, contact the Wells Engineer (per Exhibit "A-3").

3. Remove existing piping on casing valve. RU blow lines from casing valves and begin blowing down casing pressure. Kill well as necessary. Ensure well is dead or on a vacuum.

4. ND wellhead and NU BOPE. Pressure and function test BOP to 250 psi low and 1000 psi over SICP high to a maximum of 2000 psi held and charted for 10 minutes per COP Well Control Manual. PU and remove tubing hanger.

5. TOOH with tubing (per pertinent data sheet).

Tubing size: 2-3/8" 4.7# J-55 EUE

Set Depth: 2,910'

KB: 13'

6. PU 3-3/4" bit and watermelon mill and round trip as deep as possible above top perforation at 2,834'.

7. PU 4-1/2" CR on tubing, and set at 2,770'. Pressure test tubing to 1000 psi. Sting out of CR. Load hole, and pressure test casing to 800 psi. If casing does not test, spot or tag subsequent plugs as appropriate. POOH with tubing.

8. RU wireline and run CBL with 500 psi on casing from CR at 2,770 to surface to identify TOC. Adjust plugs as necessary for new TOC. Email log copy to Wells Engineer, Troy Salyers (BLM) at tsalyers@blm.gov, and Brandon Powell (NMOCD) at brandon.powell@state.nm.us upon completion of logging operations.

All cement volumes use 100% excess outside pipe and 50' excess inside pipe. The stabilizing wellbore fluid will be 8.3 ppg, sufficient to balance all exposed formation pressures. All cement will be ASTM Class B mixed at 15.6 ppg with a 1.18 cf/sk yield.

9. Plug 1 (Perforations and Chacra formation top, 2670-2770', 12 sacks Class B cement)

Mix 12 sx Class B cement and spot a balanced plug inside the casing to cover the perforations and Chacra top. TOOH.

10. Roll the hole with water and ensure that the wellbore is in a stabilized condition with no flow of gas and/or water before spotting the next plug. If flow occurs, the fluid weight must be increased until a stabilized condition is established (per Exhibit "A-3").

11. Plug 2 (Pictured Cliffs and Fruitland formation tops, 1535-1855', 153 sacks Class B cement)

RIH and perforate 3 squeeze holes at 1,855'. Establish injection rate into squeeze holes. RIH with a 4-1/2" CR and set at 1,805'. Mix 153 sx Class B cement. Squeeze 124 sx outside the casing, leaving 29 sx inside the casing to cover the Pictured Cliffs and Fruitland tops. TOOH.

12. Cease operations for 30 minutes allowing the bradenhead to be observed for pressure build. Record pressures with crystal gauge for accuracy. If pressures are observed, notify Wells Engineer and Production Engineering for path-forward discussion with NMOCD (per Exhibit "A-3").

13. Plug 3 (Kirtland and Ojo Alamo formation tops, 570-832', 126 sacks Class B cement)

RIH and perforate 3 squeeze holes at 832'. Establish injection rate into squeeze holes. RIH with a 4-1/2" CR and set at 782'. Mix 126 sx Class B cement. Squeeze 102 sx outside the casing, leaving 24 sx inside the casing to cover the Kirtland and Ojo Alamo tops. TOOH.

Continued on next page

ConocoPhillips
CONGRESS 6E
Expense - P&A

Lat 36° 40' 40.512" N

Long 107° 57' 27.72" W

PROCEDURE (continued)

14. Plug 4 (Surface plug, 0-340', 127 sacks Class B cement)

RU WL and perforate 4 big hole charge (if available) squeeze holes at 340'. TOOH and RD wireline. **Observe well for 30 minutes per BLM regulations.** RU pump, close blind rams and establish circulation out bradenhead with water. Circulate BH clean. TIH with 4-1/2" CR and set at 290'. Mix 101 sx Class B cement and squeeze until good cement returns to surface out BH valve. Shut BH valve and squeeze to max 200 psi. Sting out of CR and reverse circulate cement out of tubing. TOOH and LD stinger. TIH with open ended tubing to 290'. Mix 26 sx Class B cement and pump inside plug. TOOH and LD Tubing. SI well and WOC.

15. Nipple down BOP and cut off casing below the casing flange. Install P&A marker with cement to comply with regulations. RDMO.

Exhibit "A-3"

To Final Agreement - Withdrawal of Notice of Violation (3-15-02)
dated May 4, 2016 from ConocoPhillips Company to NMOCD

Updated Abandonment Procedures


The following procedural changes will be required for the P&A Program:

- 1) Prior to commencing abandonment operations, ensure that the bradenhead valve is dug out and properly plumbed to the surface. Record the casing, intermediate and bradenhead pressures with an appropriately ranged gauge. Contact the Engineer if bradenhead pressure is present. After the last set of completion perforations are abandoned with cement, roll the hole with water and ensure that the wellbore is in a stabilized condition with no flow of gas and/or water before spotting the next plug. If flow occurs, the fluid weight must be increased until a stabilized condition is established.
- 2) Following the plug over the Fruitland Formation Top, and prior to the plug over the Kirtland and Ojo Alamo Tops:
 - a. Operations will cease for 30 minutes allowing the Bradenhead to be observed for pressure build.
 - b. Pressures will be recorded with a crystal gauge for accuracy.
 - c. If pressures are observed, notify Wells Engineer and Production Engineering for path-forward discussion with NMOCD.
- 3) Within 24 hours of the abandonment and after two weeks, BLM will check for the presence of gas at the base of the dry hole marker and at the weep hole. Note ambient weather conditions when recording the results. If gas is detected, contact the Engineer.
- 4) If a Cathodic Protection well is on the well pad, check for the presence of gas at the vent cap. If gas is present, record results in AFMSS and contact the Engineer.


Note: when checking any sample point for the presence of gas, please be prepared for the possibility of anomalous pressure and the H₂S gas.

District NORTH	Field Name OTERO (CHACRA) GAS	API / UWI 3004624838	County SAN JUAN	State/Province NEW MEXICO
Original Spud Date 3/14/1981	Surface Legal Location 03S-029N-011W-O	East/West Distance (ft) 1,790.00	East/West Reference FEL	North/South Distance (ft) 990.00
			North/South Reference FSL	

Original Hole, 3/2/2016 3:33:06 PM



District NORTH	Field Name OTERO (CHACRA) GAS	API / UWI 3004624838	County SAN JUAN	State/Province NEW MEXICO
Original Spud Date 3/14/1981	Surface Legal Location 035-029N-011W-O	East/West Distance (ft) 1,790.00	East/West Reference FEL	North/South Distance (ft) 990.00
			North/South Reference FSL	



UNITED STATES DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
FARMINGTON DISTRICT OFFICE
6251 COLLEGE BLVD.
FARMINGTON, NEW MEXICO 87402

Attachment to notice of
Intention to Abandon:

Re: Permanent Abandonment
Well: Congress #6E

CONDITIONS OF APPROVAL

1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal and Indian Lease."

2. Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 564-7750.

3. The following modifications to your plugging program are to be made:

- a) Set plug #1 (2784-2684) ft. to cover Perforations and Chacra Formation top. Top of perforations for Chacra is at 2834 ft.
- b) Set plug #2 (1855-1434) ft. inside/outside to cover Pictured Cliffs and Fruitland Formation tops. BLM picks top of Fruitland at 1484 ft. BLM picks top of Pictured Cliffs at 1815 ft.

Operator will run CBL from CR @ 2,784 ft. to surface to identify TOC.

H₂S has not been reported at this location, however, low concentrations of H₂S (4 ppm – 27 ppm GSV) have been reported in wells within a 1 mile radius of this location.

You are also required to place cement excesses per 4.2 and 4.4 of the attached General Requirements.

Office Hours: 7:45 a.m. to 4:30 p.m.