Form 3160-5	UNITED STA	TES		FORM APPROVED		
(August 2007) DEPARTMENT OF THE INTERIOR				OMB No. 1004-0137		
	BUREAU OF LAND MA	ANAGEMENT		5. Lease Serial No.	N	
					NM-020982 74	
SUI Do not us abandoned	NDRY NOTICES AND RE this form for proposals well. Use Form 3160-3	6. If Indian, Allottee or Tribe Name				
S	UBMIT IN TRIPLICATE - Other in	nstructions on page 2.	-	7. If Unit of CA/Agreement	, Name and/or No.	
. Type of Well					and the	
Oil Well	X Gas Well Other	8. Well Name and No. Summit B 5				
Burling	gton Resources Oil & Ga	s Company LP		30	-045-60273	
PO Box 4289, Farming	ton, NM 87499	3b. Phone No. (include (505) 32	le area code) 6-9700	10. Field and Pool or Explo Fulcher	ratory Area Kutz Pictured Cliffs	
Location of Well (Footage, Sec., T., Surface Unit F (SE	R.M., or Survey Description) ENW), 1650' FNL & 1650'	FWL, Sec. 33, T2	9N, R11W	11. Country or Parish, State San Juan	, New Mexico	
12 CHECK	THE APPROPRIATE BOX(E	S) TO INDICATE NA	TURE OF NO		HER DATA	
TYPE OF SUBMISSION			TYPE OF AC	TION		
X Notice of Intent	Acidiza	Daapan		Production (Start/Domina)	Water Shut Off	
Trouve of Intent	Alter Casing	Fracture Treat		Reclamation	Well Integrity	
Subsequent Report	Casing Repair	New Construction		Recomplete	Other	
Br	Change Plans	X Plug and Abando	n 🔲 1	emporarily Abandon		
Final Abandonment Notice	Convert to Injection	Plug Back		Water Disposal		
procedure replaces the	procedure filed with the	P&A NOI submit	ted on 3/31/	2016. fy NMOCD 24 hrs (DIL CONS. DIV DIST. 3	
			pri	operations		
RI MIS ADDROVAL	OD ACCEDTANCE OF THIS		0.00		JUN 01 2016	
ACTION DOES NO	OT RELIEVE THE LESSEE A	ND	SEE	ATTACHED FO	R	
OPERATOR FROM AUTHORIZATION ON FEDERAL AND	M OBTAINING ANY OTHER REQUIRED FOR OPERATION D INDIAN LANDS	ONS	CONDIT	IONS OF APPR	OVAL	
4. I hereby certify that the foregoing is						
	true and correct. Name (Printed/Ty)	ped)				
Dollie L. Busse	true and correct. Name (Printed/Ty)	Title	Regulatory T	echnician		
Dollie L. Busse	true and correct. Name (Printed/Ty)	Date	Regulatory T	echnician 116		
Dollie L. Busse Signature	true and correct. Name (Printed/Ty)	Date	Regulatory T 5/16, STATE OFF	echnician //C ICE USE		
Dollie L. Busse Signature	true and correct. Name (Printed/Ty)	Date	Regulatory T 5/16, STATE OFF	echnician 116 FICE USE	Date 5/31/16	
Dollie L. Busse Signature Mulii upproved by Ark Ark Conditions of approval, if any, are attack hat the applicant holds legal or equitable ntille the applicant to conduct operation	true and correct. Name (Printed/Ty)	Title Date	Regulatory T 5/16 STATE OFF Title Office	echnician 116 FFO	Date 5/31/16	
Dollie L. Busse Signature Upproved by onditions of approval, if any, are attack that the applicant holds legal or equitable ntitle the applicant to conduct operation title 18 U.S.C. Section 1001 and Title 4	true and correct. Name (Printed/Ty)	Title] Date Date DR FEDERAL OR	Regulatory T 5/16, STATE OFF Title Office	echnician 116 TICE USE PF FFO to make to any department or	Date 5/31/46	
Dollie L. Busse Signature Signature pproved by onditions of approval, if any, are attach at the applicant holds legal or equitabl ntitle the applicant to conduct operation itle 18 U.S.C. Section 1001 and Title 4 lese, fictitious or fraudulent statements	true and correct. Name (Printed/Typ Algueste THIS SPACE FO THIS SPACE FO Algueste red. Approval of this notice does not e title to those rights in the subject le ins thereon. 3 U.S.C. Section 1212, make it a criti or representations as to any matter w	Title] Date Date DR FEDERAL OR warrant or certify ase which would me for any person knowin ithin its jurisdiction.	Regulatory T 5/16 STATE OFF Title Office Igly and willfully	echnician //C FICE USE PF FFO to make to any department or	Date 5/31/46	

ConocoPhillips SUMMIT B 5 Expense - P&A

Long 107° 59' 58.92" W

PROCEDURE

This project requires the use of an A-Plus steel tank to handle waste fluids circulated from the well and cement wash up.

Prior to commencing abandonment operations, ensure that the bradenhead valve is dug out and properly plumbed to the surface. Record the casing, intermediate and bradenhead pressures with an appropriately ranged gauge. Contact the Engineer if bradenhead pressure is present (per Exhibit "A-3").

1. Hold pre-job safety meeting. Comply with all NMOCD, BLM, and COP safety and environmental regulations. Test rig anchors prior to moving in rig. Before RU, run slickline to remove downhole equipment. If an obstruction is found, set a locking-3-slip-stop in the tubing.

2. MIRU workover rig. Check casing, tubing, and bradenhead pressures and record them in WeilView. If there is pressure on the BH, contact the Weils Engineer.

 Remove existing piping on casing valve. RU blow lines from casing valves and begin blowing down casing pressure. Kill well as necessary. Ensure well is dead or on a vacuum.

4. ND wellhead and NU BOPE. Pressure and function test BOP to 250 psi low and 1000 psi over SICP high to a maximum of 2000 psi held and charted for 10 minutes per COP Well Control Manual. PU and remove tubing hanger.

TOOH with tubing (per pertinent data sheet).		
Tubing size: 1.9" 2.90# J-55	Set Depth: 1,660'	KB: 7'

6. PU 2-3/4" bit and watermelon mill and round trip as deep as possible above top perforation at 1636'.

Lat 36° 41' 5 928" N

7. PU 3-1/2" CR and set at 1618'. Pressure test tubing to 1000 psi. Sting out of CR. Load hole, and pressure test casing to 800 psi. If casing does not test, spot or tag subsequent plugs as appropriate. POOH with tubing.

8. RU wireline and run CBL with 500 psi on casing from CR at 1,618' to surface to identify TOC. Adjust plugs as necessary for new TOC. Email log copy to Wells Engineer, Troy Salyers (BLM) at tsalyers@blm.gov, and Brandon Powell (NMOCD) at brandon.powell@state.nm.us upon completion of logging operations.

All cement volumes use 100% excess outside pipe and 50' excess inside pipe. The stabilizing wellbore fluid will be 8.3 ppg, sufficient to balance all exposed formation pressures. All cement will be ASTM Class B mixed at 15.6 ppg with a 1.18 cf/sk yield.

9. Plug 1 - Pictured Cliffs Formation Top and perforations, 1518' - 1618', 6 Sacks Class B Cement Mix 6 sx Class B cement and spot a balanced plug inside the casing to cover the Pictured Cliffs top and perforations. PUH.

10. Roll the hole with water and ensure that the wellbore is in a stabilized condition with no flow of gas and/or water before spotting the next plug. If flow occurs, the fluid weight must be increased until a stabilized condition is established (per Exhibit "A-3").

10. Plug 2 - Fruitland Formation Top, 1163' - 1263', 69 Sacks Class B Cement

RIH and perforate 3 squeeze holes at 1,263'. Establish injection rate into squeeze holes. RIH with a 3-1/2" CR and set at 1213'. Mix 69 sx Class B cement. Squeeze 63 sx outside the casing, leaving 6 sx inside the casing to cover the Fruitland top. POOH.

11. Cease operations for 30 minutes allowing the bradenhead to be observed for pressure build. Record pressures with crystal gauge for accuracy. If pressures are observed, notify Wells Engineer and Production Engineering for path-forward discussion with NMOCD (per Exhibit "A-3").

12. Plug 3 - Kirtland and Ojo Formation Top, 382' - 544', 290 Sacks Class B Cement

RIH and perforate 3 squeeze holes at 544'. Establish injection rate into squeeze holes. RIH with a 3-1/2" CR and set at 494'. Mix 290 sx Class B cement. Squeeze 281 sx outside the casing, leaving 9 sx inside the casing to cover the Kirtland and Ojo Formation top. POOH.

13. Plug 4 - Surface Plug , 0' - 113', 296 Sacks Class B Cement

RU WL and perforate 4 big hole charge (if available) squeeze holes at 113'. TOOH and RD wireline. Observe well for 30 minutes per BLM regulations. RU pump, close blind rams and establish circulation out bradenhead with water. Circulate BH clean. TIH with 3-1/2" CR and set at 63'. Mix 289 sx Class B cement and squeeze until good cement returns to surface out BH valve. Shut BH valve and squeeze to max 200 psi. Sting out of CR and reverse circulate cement out of tubing. TOOH and LD stinger. TIH with open ended tubing to 63'. Mix 7 sx Class B cement and pump inside plug. TOOH and LD Tubing. SI well and WOC.

14. Nipple down BOP and cut off casing below the casing flange. Install P&A marker with cement to comply with regulations. RDMO.

Exhibit "A-3"

To Final Agreement - Withdrawal of Notice of Violation (3-15-02) dated May 4, 2016 from ConocoPhillips Company to NMOCD

Updated Abandonment Procedures

The following procedural changes will be required for the P&A Program:

- Prior to commencing abandonment operations, ensure that the bradenhead valve is dug out and property plumbed to the surface. Record the casing, intermediate and bradenhead pressures with an appropriately ranged gauge. Contact the Engineer if bradenhead pressure is present. After the last set of completion perforations are abandoned with cement, roll the hole with water and ensure that the wellbore is in a stabilized condition with no flow of gas and/or water before spotting the next plug. If flow occurs, the fluid weight must be increased until a stabilized condition is established.
- Following the plug over the Fruitland Formation Top, and prior to the plug over the Kirtland and Ojo Alamo Tops.
 - Operations will cease for 30 minutes allowing the Bradenhead to be observed for pressure build.
 - b. Pressures will be recorded with a crystal gauge for accuracy.
 - If pressures are observed, notify Wells Engineer and Production Engineering for path-forward discussion with NMOCD.
- 3) Within 24 hours of the abandonment and after two weeks, BLM will check for the presence of gas at the base of the dry hole marker and at the weep hole. Note ambient weather conditions when recording the results. If gas is detected, contact the Engineer.
- 4) If a Cathodic Protection well is on the well pad, check for the presence of gas at the vent cap. If gas is present, record results in AFMSS and contact the Engineer.

Note: when checking any sample point for the presence of gas, please be prepared for the possibility of anomalous pressure and the H2S gas.



Well Name: SUMMIT B #5							
004560273	Surface Legis Location 033-029N-011W-F	Field Name License PLICHER KUTZ PC (SAB) #0015	No. State-Province W NEW MEXICO	el Configuration T) p	in pare		
ound Elevation (11) 5,527	Original KarRT Bevalori (1) 7.00	5,534.00	KG-Casing Flange Distance (II) 7.00	KS-Tubing Hanger	Distance (5)		
An alter Montale		Original Hole, 1/1	/2020 12:06:00 AM				
_		Vertical schematic (actual)		MD (fiKB)	Formation To		
; Surface; 15 1/2	in; 15.000 in; 7.0 ftKB;		Plug #4; 7.0-113.0; 1/1/2020; Squeeze / 289 sx Class B Cement outside casing Surface Casing Gement; 7.0-63.2; -3/9/1947: Cmtd Surf cso w/ 10 sx cmt	6.9 63.0			
Bridge Plug -	Permanent: 63.0-85.0		Circ to surf.	63.3			
				65.0	-		
			Plug #4 : 7.0-113.0: 1/1/2020: Mix 7 sx	97.1			
Perf: 113.0: 1/1/2020	Perf: 113.0: 1/1/2020		Class B Cement and Spot a Balanced Plug	112.9			
				381.9			
			Plug #3 ; 382.0-544.0; 1/1/2020; Squeeze 281 sx Class B Cement	432.1	OJO ALAMO		
ridge Plug - Pern	nanent: 494.0-496.0; 3		Louiside casing	494.1	KIRTLAND		
	-nz Cemen Kediner		Plug #3 - 382 0.544 0-1H/2020-14-0	496.1			
Perf. 544.0: 1/1/2020	Perf: 544.0: 1/1/2020		sx Class B Cement and Spot a Balanced Plug	544.0	-		
				- 566.9			
		5		977.0			
			PU 30 1 100.0 0.00.0 111.00	1,163.1			
	10		 Mug #2 ; 1,163.0-1,263.0; 1/1/2020; Squeeze 63 sx Class B Cement outside casing 	1,212.9			
Bridge Plug 1.215.0: 3-	- Permanent, 1,213.0- 1/2" Cement Retainer		Law and the second s	1,213.9	FRUITLAND		
				1,214.9	-		
Œ	Perf: 1.263.0: 1/1/2020		Plug #2 ; 1,163.0-1,263.0; 1/1/2020; Mix 6 sx Class B Cement and Spot a Balanced Plug	1,263,1			
				1,381.9			
				1,433.1			
				1,518.0			
Bridge Plug - Permanent; 1,618.0- 1,620.0; 3-1/2" Cement Retainer	- Permanent; 1,618.0-		Plug#1;1,518.0-1,618.0;1/1/2020; Mix 6 sx Class B Cement and Spot a Balanced Plug	1,618.1			
	1/2" Cement Retainer		Tenning and the second of the	1,620.1			
				1,628.0	PICTURED CI		
Pictured Cliff	s: 1.636.0: 11/23/1983		Intermediate Casing Cement: 1,433.0-	1.636.2			
2; Intermediate;	51/2 in; 5.012 in; 7.0 ftKB; 1,637.0 ftKB		1,637.0; 3/24/1947; Cmt'd Inter Csg w/ 40 sx cmt. TOC @ 1433' with 75%	1,637.1			
Rathole	fing motion woled '07.			1,721.1			
PBTD: 1.750.0: [Durina 1983 workover	8 8	Cement Plug; 1,750.0-1,788.5; 11/23/1983; PBTD Production Carlos Coment 7.0 4 789.5	1,750.0			
3; Production	; 3 1/2 in; 2.922 in; 7.0 ftKB; 1,788.5 ftKB		11/14/1983; Cmt'd prod csg w/ 175 sx 50/50 Poz. Circ 1/2 bbl to surface.	1,788.7			
	Constraints on the spin of the state state.		Cement Plug; 1,788.5-1,790.0;	1,790.0			

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT FARMINGTON DISTRICT OFFICE 6251 COLLEGE BLVD.

FARMINGTON, NEW MEXICO 87402

Attachment to notice of Intention to Abandon:

Re: Permanent Abandonment Well: Summit B #5

CONDITIONS OF APPROVAL

1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal and Indian Lease."

2. Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 564-7750.

3. The following modifications to your plugging program are to be made:

- a) Set plug #1 (1586-1486) ft. to cover the Pictured Cliffs Formation top and perforations. BLM picks top of Pictured Cliffs perforations at 1636 ft.
- b) Set plug #2 (1354-1254) ft. inside/outside to cover the Fruitland Formation top. BLM picks top of Fruitland at 1304 ft.
- c) Set plug #3 (628-409) ft. inside/outside to cover the Kirtland and Ojo Alamo Formation tops. BLM picks top of Ojo Alamo at 459 ft. BLM picks top of Kirtland at 578 ft.

Operator will run CBL from CR @ 1,586 ft. to surface to identify TOC.

H₂S has not been reported at this location, however, low concentrations of H₂S (27 ppm GSV) have been reported in the NESE/4 Sec. 27, 29N, 11W.

You are also required to place cement excesses per 4.2 and 4.4 of the attached General Requirements.

Office Hours: 7:45 a.m. to 4:30 p.m.