Form 3160-5 (June 2015)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

FORM APPROVED OMB NO. 1004-0137 Expires: January 31, 2018

5. Lease Serial No. NMSF079968

6.	If	Indian,	Allottee	or	Tribe	Name

Do not use thi abandoned wel	is form for proposals to drill or to r II. Use form 3160-3 (APD) for such	re-enter an proposals.	6. If Indian, Allottee or Tribe Name					
SUBMIT IN T	TRIPLICATE - Other instructions or	n page 2	7. If Unit or CA/A	7. If Unit or CA/Agreement, Name and/or No.				
Type of Well Oil Well	ner		8. Well Name and ROPCO 4 2	8. Well Name and No. ROPCO 4 2				
Name of Operator HILCORP ENERGY COMPAN	Contact: PRISCILLA	SHORTY	9. API Well No. 30-045-3042	9. API Well No. 30-045-30422-00-S1				
3a. Address 1111 TRAVIS STREET HOUSTON, TX 77002	3b. Phone N Ph: 505.3	No. (include area code) 324.5188	10. Field and Poo TWIN MOUI	Field and Pool or Exploratory Area TWIN MOUNDS				
4. Location of Well (Footage, Sec., T.	., R., M., or Survey Description)		11. County or Par	ish, State				
Sec 4 T29N R14W NESE 155 36.752719 N Lat, 108.308409			SAN JUAN (SAN JUAN COUNTY, NM				
12. CHECK THE AF	PPROPRIATE BOX(ES) TO INDICA	ATE NATURE OF	NOTICE, REPORT, OR C	OTHER DATA				
TYPE OF SUBMISSION		TYPE OF	ACTION					
Notice of Intent ■ Notice of Intent	☐ Acidize ☐ De	eepen	☐ Production (Start/Resume	Water Shut-Off				
_	☐ Alter Casing ☐ Hy	draulic Fracturing	□ Reclamation	■ Well Integrity				
☐ Subsequent Report	☐ Casing Repair ☐ Ne	ew Construction	☐ Recomplete	□ Other				
☐ Final Abandonment Notice	☐ Change Plans ☐ Plu	ug and Abandon	▼ Temporarily Abandon					
% ⟨	☐ Convert to Injection ☐ Plu	ug Back	■ Water Disposal					
Hilcorp Energy Company requests permission to temporarily abandon the subject well with the intent to return the well to production once gas prices rise. Please see the attached procedure and wellbore schematic.								
			AL	IG 2 8 2019				
			DIST	RICT III				
	Electronic Submission #477335 verifi For HILCORP ENERGY COM committed to AFMSS for processing by	JOE KILLINS on 08	Farmington	ш				
Name (Frimew Typed) PRISCILL	A SHORTY	Title OPERA	HONS REGULATORY TEC	П				
Signature (Electronic S	Submission)	Date 08/09/20	19					
	THIS SPACE FOR FEDER	AL OR STATE (OFFICE USE					
Approved By JOE KILLINS		TitleENGINEEF	1	Date 08/28/2019				
Conditions of approval, if any, are attached	d. Approval of this notice does not warrant or uitable title to those rights in the subject lease act operations thereon.	1						
Title 18 U.S.C. Section 1001 and Title 43	U.S.C. Section 1212, make it a crime for any statements or representations as to any matter	person knowingly and		at or agency of the United				
(Instructions on page 2) ** BLM REV	ISED ** BLM REVISED ** BLM R	REVISED ** BLM	REVISED ** BLM REVI	SED **				



Hilcorp Energy Company ROPCO 4-2

Temporarily Abandon API#: 3004530422

PROCEDURE

- 1. Hold a pre-job safety meeting prior to beginning all operations or during a change in operational scope or initiation of SIMOPs. Properly document all operations via the JSA process. Insure that all personnel onsight abide by HEC safety protocol, including PPE, housekeeping, and procedures. Verify cathodic protection is off and wellhead instrumentation is properly disconnected from wellhead. Comply with all NMOCD, BLM, and HEC safety and environmental regulations. Verify there is no H2S present prior to beginning operations. If H2S is present, take the necessary actions to insure that the operation is safe prior to beginning operations. Observe and record pressures across all strings daily, prior to beginning operations. Notify NMOCD and BLM 24 hours in advance of beginning operations
- 2. MIRU service rig and associated equipment, ND casing risers
- 3. LOTO pumping unit, remove HH and bridle, PU on PR and unseat pump. POOH LD rods and pump.
- 4. ND tree and NU BOPs. Pressure and function test BOPs to 150/1500 psi.
- 5. PU on tbg, release hanger, scan and visually inspect tbg and POOH
- 6. PU junk mill and RIH to 975', POOH LD junk mill
- 7. RIH w/ CBIP on tbg and set at 925', PT CIBP and casing to 600 psi, POOH w/ setting tool.
- 8. RBIH w/ 250' of tbg to use as a kill string. NDNU tree verify tree and wellhead are equipped with functional pressure gauges. RDMO
- 9. Contact BLM and NMOCD to schedule witnessed MIT. PT csg to 600 psi.

