Form 3160-5 (June 2015)

## UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

FORM APPROVED OMB NO. 1004-0137 Expires: January 31, 2018

5. Lease Serial No. NMSF078213

Do not use this form for proposals to drill or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals.						
					6. If Indian, Allottee or	Tribe Name
SUBMIT IN TRIPLICATE - Other instructions on page 2					7. If Unit or CA/Agreement, Name and/or No. NMNM99464	
1. Type of Well ☐ Oil Well ☑ Gas Well ☐ Other					8. Well Name and No. TIGER 3	
2. Name of Operator Contact: AMANDA WALKER HILCORP ENERGY COMPANY E-Mail: mwalker@hilcorp.com					9. API Well No. 30-045-29507-00-S1	
3a. Address         3b. Phone No. (include area code)           1111 TRAVIS STREET         Ph: 505-324-5122					Field and Pool or Exploratory Area     FULCHER KUTZ PICTURED CLIFFS	
HOUSTON, TX 77002  4. Location of Well (Footage, Sec., T., R., M., or Survey Description)					11. County or Parish, State	
Sec 34 T30N R13W NESE 1377FSL 565FEL 36.766324 N Lat, 108.186026 W Lon					SAN JUAN COUNTY, NM	
12. CHECK THE AI	PPROPRIATE BOX(ES) TO	INDICAT	E NATURE OI	F NOTICE,	REPORT, OR OTHE	ER DATA
TYPE OF SUBMISSION	TYPE OF ACTION					
➤ Notice of Intent	☐ Acidize	☐ Deepen		☐ Production (Start/Resume)		☐ Water Shut-Off
☐ Subsequent Report	☐ Alter Casing			☐ Reclama		☐ Well Integrity
	☐ Casing Repair	□ New Construction		Recomp		Other
☐ Final Abandonment Notice	☐ Change Plans ☐ Convert to Injection	<ul><li>☐ Plug and Abandon</li><li>☐ Plug Back</li></ul>			porarily Abandon er Disposal	
Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 must be filed on testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.  Hilcorp Energy Company requests permission to temporarily abandon the subject well with the intent to return the well to production once gas prices rise. Please see the attached procedure and wellbore schematic.  Notify NMOCD 24 hrs prior to beginning operations  SEP 0.5 2019  DISTRICT 111						
14. I hereby certify that the foregoing is true and correct.  Electronic Submission #477352 verified by the BLM Well Information System  For HILCORP ENERGY COMPANY, sent to the Farmington  Committed to AFMSS for processing by JOHN HOFFMAN on 08/30/2019 (19JH0139SE)  Name (Printed/Typed) AMANDA WALKER  Title OPERATIONS REGULATORY TECH						
Name (Printed/Typed) AMANDA	THE OPERA	HONS REG	OLATORT TECH			
Signature (Electronic S	Submission)		Date 08/09/20	019		
	THIS SPACE FOR F	EDERA	OR STATE	OFFICE US	SE	
Approved By JOHN HOFFMAN			TitlePETROLE	UM ENGINE	ER	Date 08/30/2019
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.			Office Farmington			
Title 18 U.S.C. Section 1001 and Title 43 States any false, fictitious or fraudulent				willfully to ma	ke to any department or ag	gency of the United

<sup>(</sup>Instructions on page 2) \*\* BLM REVISED \*\* BLM REVISED \*\* BLM REVISED \*\* BLM REVISED \*\*





## Hilcorp Energy Company TIGER 3

Temporarily Abandon API #: 3004529507

## PROCEDURE

- 1. Hold a pre-job safety meeting prior to beginning all operations or during a change in operational scope or initiation of SIMOPs. Properly document all operations via the JSA process. Insure that all personnel onsight abide by HEC safety protocol, including PPE, housekeeping, and procedures. Verify cathodic protection is off and wellhead instrumentation is properly disconnected from wellhead. Comply with all NMOCD, BLM, and HEC safety and environmental regulations. Verify there is no H2S present prior to beginning operations. If H2S is present, take the necessary actions to insure that the operation is safe prior to beginning operations. Observe and record pressures across all strings daily, prior to beginning operations. Notify NMOCD and BLM 24 hours in advance of beginning operations
- 2. MIRU service rig and associated equipment, ND casing risers
- 3. LOTO pumping unit, remove HH and bridle, PU on PR and unseat pump. POOH LD rods and pump.
- 4. ND tree and NU BOPs. Pressure and function test BOPs to 150/1500 psi.
- 5. PU on tbg, release hanger, scan and visually inspect tbg and POOH
- 6. PU junk mill and RIH to 3950', POOH LD junk mill
- 7. RIH w/ CBIP on tbg and set at 3850', PT CIBP and casing to 600 psi, POOH w/ setting tool.
- 8. RBIH w/ 250' of tbg to use as a kill string. NDNU tree verify tree and wellhead are equipped with functional pressure gauges. RDMO
- 9. Contact BLM and NMOCD to schedule witnessed MIT. PT csg to 600 psi.

