Form 3160-5 (June 2015)

## **UNITED STATES** DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0137 Expires: January 31, 2018

SUNDRY Do not use thi abandoned wel	Lease Serial No.     NMSF078213      If Indian, Allottee or Tribe Name					
SUBMIT IN T	7. If Unit or CA/Agreement, Name and/or No.					
Type of Well	8. Well Name and No. TIGER 9					
Name of Operator HILCORP ENERGY COMPAN	9. API Well No. 30-045-29702-00-S1					
3a. Address 1111 TRAVIS STREET HOUSTON, TX 77002	3b. Phone No. (include area code) Ph: 505-324-5122		10. Field and Pool or Exploratory Area FULCHER KUTZ PICTURED CLIFFS			
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)				11. County or Parish, State		
Sec 26 T30N R13W SWSW 1 36.779947 N Lat, 108.180077		SAN JUAN COUNTY, NM				
12. CHECK THE AF	PPROPRIATE BOX(ES)	ΓΟ INDICATE NATURE O	F NOTICE,	REPORT, OR OTH	HER DATA	
TYPE OF SUBMISSION	TYPE OF ACTION					
☑ Notice of Intent	☐ Acidize	□ Deepen	☐ Production (Start/Resume)		☐ Water Shut-Off	
	☐ Alter Casing	☐ Hydraulic Fracturing	☐ Reclamation		■ Well Integrity	
☐ Subsequent Report	☐ Casing Repair	■ New Construction	☐ Recomplete		☐ Other	
☐ Final Abandonment Notice	☐ Change Plans	□ Plug and Abandon	▼ Temporarily Abandon			
gol.	☐ Convert to Injection	☐ Plug Back	☐ Water Disposal			
13. Describe Proposed or Completed Ope If the proposal is to deepen directions Attach the Bond under which the wor following completion of the involved testing has been completed. Final Ab- determined that the site is ready for fi Hilcorp Energy Company requ to return the well to production wellbore schematic.	ally or recomplete horizontally, g k will be performed or provide to operations. If the operation restorandonment Notices must be file and inspection.	tive subsurface locations and measure he Bond No. on file with BLM/BIA alts in a multiple completion or record only after all requirements, including a standard and the subject we	red and true ver Required sub- impletion in a n ing reclamation	tical depths of all pertir sequent reports must be ew interval, a Form 316 , have been completed a	ent markers and zones. filed within 30 days 0-4 must be filed once	

Notify NMOCD 24 hrs prior to beginning operations



14. I hereby certify that the foregoing is true and correct.  Electronic Submission #477351 verified by the BLM Well Information System  For HILCORP ENERGY COMPANY, sent to the Farmington  Committed to AFMSS for processing by JCHN HOFFMAN on 08/30/2019 (19JH0138SE)						
Name (Printed/Typed)	Name (Printed/Typed) AMANDA WALKER Title OPERATIONS REGULAT		OPERATIONS REGULATORY TECH			
Signature	(Electronic Submission)	Date 08/09/2019				
THIS SPACE FOR FEDERAL OR STATE OFFICE USE						
Approved By JOHN HOFFMAN  Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.			ETROLEUM ENGINEER Farmington	Date 08/30/2019		

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.





## Hilcorp Energy Company TIGER 9

Temporarily Abandon API #: 3004529702

## PROCEDURE

- 1. Hold a pre-job safety meeting prior to beginning all operations or during a change in operational scope or initiation of SIMOPs. Properly document all operations via the JSA process. Insure that all personnel onsight abide by HEC safety protocol, including PPE, housekeeping, and procedures. Verify cathodic protection is off and wellhead instrumentation is properly disconnected from wellhead. Comply with all NMOCD, BLM, and HEC safety and environmental regulations. Verify there is no H2S present prior to beginning operations. If H2S is present, take the necessary actions to insure that the operation is safe prior to beginning operations. Observe and record pressures across all strings daily, prior to beginning operations. Notify NMOCD and BLM 24 hours in advance of beginning operations
- 2. MIRU service rig and associated equipment, ND casing risers
- 3. LOTO pumping unit, remove HH and bridle, PU on PR and unseat pump. POOH LD rods and pump.
- 4. ND tree and NU BOPs. Pressure and function test BOPs to 150/1500 psi.
- 5. PU on tbg, release hanger, scan and visually inspect tbg and POOH
- 6. PU junk mill and RIH to 1800', POOH LD junk mill
- 7. RIH w/ CBIP on tbg and set at 1700', PT CIBP and casing to 600 psi, POOH w/ setting tool.
- 8. RBIH w/ 250' of tbg to use as a kill string. NDNU tree verify tree and wellhead are equipped with functional pressure gauges. RDMO
- 9. Contact BLM and NMOCD to schedule witnessed MIT. PT csg to 600 psi.

