Form 3160-5 (June 2015)

## UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0137 Expires: January 31, 2018

## SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals

NMNM25857

5. Lease Serial No.

abandoned we	6. II Indian, Affolies	6. If Indian, Affolice of Tribe Name				
SUBMIT IN	7. If Unit or CA/Ag	7. If Unit or CA/Agreement, Name and/or No.				
Type of Well     Oil Well		8. Well Name and No. WF FEDERAL 21 1Y				
Name of Operator     HILCORP ENERGY COMPAN	9. API Well No. 30-045-30031	9. API Well No. 30-045-30031-00-C1				
3a. Address 1111 TRAVIS STREET HOUSTON, TX 77002		3b. Phone No. (include area code) Ph: 505-324-5188	BASIN FRUIT	10. Field and Pool or Exploratory Area BASIN FRUITLAND COAL HARPER HILL		
4. Location of Well (Footage, Sec., 7	11. County or Parish	11. County or Parish, State				
Sec 21 T30N R14W SWSW 8 36.794814 N Lat, 108.320664	SAN JUAN CO	SAN JUAN COUNTY, NM				
12. CHECK THE AI	PPROPRIATE BOX(ES)	TO INDICATE NATURE OI	F NOTICE, REPORT, OR OT	THER DATA		
TYPE OF SUBMISSION	TYPE OF ACTION					
☑ Notice of Intent	☐ Acidize	☐ Deepen	☐ Deepen ☐ Production (Start/Resume)			
	☐ Alter Casing	☐ Hydraulic Fracturing	☐ Hydraulic Fracturing ☐ Reclamation			
☐ Subsequent Report	☐ Casing Repair	■ New Construction	☐ Recomplete ☐ Other			
☐ Final Abandonment Notice	☐ Change Plans	□ Plug and Abandon	▼ Temporarily Abandon			
66	Convert to Injection Plug Back		☐ Water Disposal			
13. Describe Proposed or Completed Op If the proposal is to deepen directions Attach the Bond under which the wo following completion of the involved testing has been completed. Final At determined that the site is ready for f	ally or recomplete horizontally, rk will be performed or provide l operations. If the operation respondent Notices must be file	give subsurface locations and measur the Bond No. on file with BLM/BIA sults in a multiple completion or reco	red and true vertical depths of all pert. Required subsequent reports must be impletion in a new interval, a Form 3	tinent markers and zones. be filed within 30 days 160-4 must be filed once		

Hilcorp Energy Company requests permission to temporarily abandon the subject well with the intent to return the well to production once gas prices rise. Please see the attached procedure and wellbore schematic.

NMOCD

SEP 0 5 2019

DISTRICT III

Notify NMOCD 24 hrs prior to beginning operations

14. I hereby certify that the foregoing is true and correct.  Electronic Submission #477516 verified by the BLM Well Information System  For HILCORP ENERGY COMPANY, sent to the Farmington  Committed to AFMSS for processing by JQHN HOFFMAN on 09/03/2019 (19JH0147SE)							
Name (Printed/Typed)	PRISCILLA SHORTY	Title	OPERATIONS REGULATORY TECH				
Signature	(Electronic Submission)	Date	08/12/2019				
THIS SPACE FOR FEDERAL OR STATE OFFICE USE							
Approved By_JOHN HOFFMAN		TitleF	ETROLEUM ENGINEER	Date 09/03/2019			
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.		Office	Farmington				

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.





## Hilcorp Energy Company WF FEDERAL 21-1Y

Temporarily Abandon API #: 3004530031

## PROCEDURE

- 1. Hold a pre-job safety meeting prior to beginning all operations or during a change in operational scope or initiation of SIMOPs. Properly document all operations via the JSA process. Insure that all personnel onsight abide by HEC safety protocol, including PPE, housekeeping, and procedures. Verify cathodic protection is off and wellhead instrumentation is properly disconnected from wellhead. Comply with all NMOCD, BLM, and HEC safety and environmental regulations. Verify there is no H2S present prior to beginning operations. If H2S is present, take the necessary actions to insure that the operation is safe prior to beginning operations. Observe and record pressures across all strings daily, prior to beginning operations. Notify NMOCD and BLM 24 hours in advance of beginning operations
- 2: MIRU service rig and associated equipment, ND casing risers
- 3. LOTO pumping unit, remove HH and bridle, PU on PR and unseat pump. POOH LD rods and pump.
- 4. ND tree and NU BOPs. Pressure and function test BOPs to 150/1500 psi.
- 5. PU on tbg, release hanger, scan and visually inspect tbg and POOH
- 6. PU junk mill and RIH to 1100', POOH LD junk mill
- 7. RIH w/ CBIP on tbg and set at 1015', PT CIBP and casing to 600 psi, POOH w/ setting tool.
- 8. RBIH w/ 250' of tbg to use as a kill string. NDNU tree verify tree and wellhead are equipped with functional pressure gauges. RDMO
- 9. Contact BLM and NMOCD to schedule witnessed MIT. PT csg to 600 psi.

