Form 3160-5 (June 2015)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED
OMB NO. 1004-0137
Expires: January 31, 201

SUNDRY NOTICES AND REPORTS ON WELLS

NMSF079968

Lease Serial No.

Do not use this form for proposals to drill or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals.					500 Day 1970 S	
				6. If Indian, Allottee	or Tribe Name	
SUBMIT IN TRIPLICATE - Other instructions on page 2				7. If Unit or CA/Agreement, Name and/or No.		
1. Type of Well	8. Well Name and No. ROPCO 9 4					
Oil Well Gas Well Oth						
2. Name of Operator Contact: MANDI WALKER HILCORP ENERGY COMPANY E-Mail: mwalker@hilcorp.com				9. API Well No. 30-045-30345-0	00-S1	
3a. Address 1111 TRAVIS STREET HOUSTON, TX 77002	3b. Phone No. (include area code) Ph: 505-324-5122 10. F		 Field and Pool or Exploratory Area TWIN MOUNDS 			
4. Location of Well (Footage, Sec., T	11. County or Parish, State					
Sec 9 T29N R14W SENW 14: 36.744562 N Lat, 108.317268	SAN JUAN COUNTY, NM					
12. CHECK THE A	PPROPRIATE BOX(ES)	TO INDICATE NATURE O	F NOTICE,	REPORT, OR OTH	HER DATA	
TYPE OF SUBMISSION	TYPE OF ACTION					
Notice of Intent	☐ Acidize	☐ Deepen	☐ Production (Start/Resume)		☐ Water Shut-Off	
	☐ Alter Casing	☐ Hydraulic Fracturing	☐ Reclamation		■ Well Integrity	
☐ Subsequent Report	☐ Casing Repair	■ New Construction	☐ Recomplete ☐ O		Other	
☐ Final Abandonment Notice	☐ Change Plans	☐ Plug and Abandon	⊠ Tempora	■ Temporarily Abandon		
3P	☐ Convert to Injection	☐ Plug Back	☐ Water Disposal			
13. Describe Proposed or Completed Ope If the proposal is to deepen directions Attach the Bond under which the wor following completion of the involved testing has been completed. Final Ab- determined that the site is ready for fi Hilcorp Energy Company requ procedure and wellbore schen	ally or recomplete horizontally, it will be performed or provide toperations. If the operation re pandonment Notices must be fil inal inspection.	give subsurface locations and measurthe Bond No. on file with BLM/BIA sults in a multiple completion or record only after all requirements, including	red and true ve Required sub empletion in a n ing reclamation	rtical depths of all pertin sequent reports must be sew interval, a Form 316 n, have been completed a	filed within 30 days 0-4 must be filed once	
				MMOPD		

Notify NMOCD 24 hrs prior to beginning operations

SEP 12 2019

DISTRICT III

14. I hereby certify that the foregoing is true and correct. Electronic Submission #482819 verified by the BLM Well Information System For HILCORP ENERGY COMPANY, sent to the Farmington Committed to AFMSS for processing by JOHN HOFFMAN on 09/11/2019 (19JH0188SE)							
Name (Printed/Typed)	MANDI WALKER	Title	OPERATIONS REGULATORY TECH - S				
Signature	(Electronic Submission)	Date	09/11/2019				
THIS SPACE FOR FEDERAL OR STATE OFFICE USE							
Approved By JOHN HOFFMAN		TitleF	ETROLEUM ENGINEER	Date 09/11/2019			
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.		Office	Farmington				

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.





Hilcorp Energy Company ROPCO 9-4

Temporarily Abandon API#: 3004530345

PROCEDURE

- 1. Hold a pre-job safety meeting prior to beginning all operations or during a change in operational scope or initiation of SIMOPs. Properly document all operations via the JSA process. Insure that all personnel onsight abide by HEC safety protocol, including PPE, housekeeping, and procedures. Verify cathodic protection is off and wellhead instrumentation is properly disconnected from wellhead. Comply with all NMOCD, BLM, and HEC safety and environmental regulations. Verify there is no H2S present prior to beginning operations. If H2S is present, take the necessary actions to insure that the operation is safe prior to beginning operations. Observe and record pressures across all strings daily, prior to beginning operations. Notify NMOCD and BLM 24 hours in advance of beginning operations
- 2. MIRU service rig and associated equipment, ND casing risers
- 3. LOTO pumping unit, remove HH and bridle, PU on PR and unseat pump. POOH LD rods and pump.
- 4. ND tree and NU BOPs. Pressure and function test BOPs to 150/1500 psi.
- 5. PU on tbg, release hanger, scan and visually inspect tbg and POOH
- 6. PU junk mill and RIH to 850', POOH LD junk mill
- 7. RIH w/ CBIP on tbg and set at 750', PT CIBP and casing to 600 psi, POOH w/ setting tool.
- 8. RBIH w/ 250' of tbg to use as a kill string. NDNU tree verify tree and wellhead are equipped with functional pressure gauges. RDMO
- 9. Contact BLM and NMOCD to schedule witnessed MIT. PT csg to 600 psi.

