Form 3160-5 (June 2015)

■ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0137 Expires: January 31, 2018 Lease Serial No.

☐ Water Shut-Off

■ Well Integrity

□ Other

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an

☐ Acidize

☐ Alter Casing

☐ Casing Repair

☐ Change Plans

NMSF081239

Do not use the abandoned we	6. If Indian, Allottee or Tribe Name			
SUBMIT IN	7. If Unit or CA/Agreement, Name and/or No. NMNM104813			
Type of Well Oil Well	8. Well Name and No. JOHNSON GAS COM D 3			
Name of Operator HILCORP ENERGY COMPAN	9. API Well No. 30-045-31438-00-S1			
3a. Address 1111 TRAVIS STREET HOUSTON, TX 77002		3b. Phone No. (include area code) Ph: 505-324-5122	10. Field and Pool or Exploratory Area BASIN FRUITLAND COAL	
4. Location of Well (Footage, Sec., T	11. County or Parish, State			
Sec 15 T30N R12W NWNW 1 36.816000 N Lat, 108.091600	SAN JUAN COUNTY, NM			
12. CHECK THE AF	PPROPRIATE BOX(ES)	TO INDICATE NATURE OF NOTICE	, REPORT, OR OTHER DATA	
TYPE OF SUBMISSION	TYPE OF ACTION			

☐ Plug Back ☐ Convert to Injection ■ Water Disposal Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.

□ Deepen

☐ Hydraulic Fracturing

■ New Construction

□ Plug and Abandon

Hilcorp Energy Company requests permission to temporarily abandon the subject well per the attached procedure and wellbore schematic.

Notify NMOCD 24 hrs prior to beginning operations

NMOCD

☐ Production (Start/Resume)

▼ Temporarily Abandon

□ Reclamation

□ Recomplete

SEP 05 2019

DISTRICT III

14. I hereby certify that the foregoing is true and correct. Electronic Submission #480051 verified by the BLM Well Information System For HILCORP ENERGY COMPANY, sent to the Farmington Committed to AFMSS for processing by JCHN HOFFMAN on 09/04/2019 (19JH0160SE)						
Name (Printed/Typed)	MANDI WALKER	Title OPERATIONS REGULATORY TECH - S				
Signature	(Electronic Submission) THIS SPACE FOR FEDERA	Date 08/22/2019 LL OR STATE OFFICE USE				
Approved By_JQHN_HOFFMAN		TitleP	ETROLEUM ENGINEER	Date 09/04/2019		
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.		Office	Farmington			

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)
** BLM REVISED ** BLM REVISED ** BLM REVISED ** BLM REVISED **





Hilcorp Energy Company JOHNSON GAS COM D 3

Temporarily Abandon API #: 3004531438

PROCEDURE

- 1. Hold a pre-job safety meeting prior to beginning all operations or during a change in operational scope or initiation of SIMOPs. Properly document all operations via the JSA process. Insure that all personnel onsight abide by HEC safety protocol, including PPE, housekeeping, and procedures. Verify cathodic protection is off and wellhead instrumentation is properly disconnected from wellhead. Comply with all NMOCD, BLM, and HEC safety and environmental regulations. Verify there is no H2S present prior to beginning operations. If H2S is present, take the necessary actions to insure that the operation is safe prior to beginning operations. Observe and record pressures across all strings daily, prior to beginning operations. Notify NMOCD and BLM 24 hours in advance of beginning operations.
- 2. MIRU service rig and associated equipment, ND casing risers
- 3. LOTO pumping unit, remove HH and bridle, PU on PR and unseat pump. POOH LD rods and pump.
- 4. ND tree and NU BOPs. Pressure and function test BOPs to 150/1500 psi.
- 5. PU on tbg, release hanger, scan and visually inspect tbg and POOH
- 6. PU junk mill and RIH to 1950', POOH LD junk mill
- 7. RIH w/ CBIP on tbg and set at 1885', PT CIBP and casing to 600 psi, POOH w/ setting tool.
- 8. RBIH w/ 250' of tbg to use as a kill string. NDNU tree verify tree and wellhead are equipped with functional pressure gauges. RDMO
- 9. Contact BLM and NMOCD to schedule witnessed MIT. PT csg to 600 psi.

