Form 3160-5 (June 2015)

## **UNITED STATES**

DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0137 Expires: January 31, 2018

SUNDRY Do not use the abandoned we	NMNM19163  6. If Indian, Allottee				
SUBMIT IN	7. If Unit or CA/Ag	7. If Unit or CA/Agreement, Name and/or No.			
Type of Well     Oil Well		8. Well Name and No. WF FEDERAL 20 4			
2. Name of Operator HILCORP ENERGY COMPA	9. API Well No. 30-045-31569	9. API Well No. 30-045-31569-00-C2			
3a. Address 1111 TRAVIS STREET HOUSTON, TX 77002	b. Phone No. (include area code) Ph: 505-324-5122	BASIN FRUIT	10. Field and Pool or Exploratory Area BASIN FRUITLAND COAL TWIN MOUNDS FRUITLAND SAND PO		
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)			11. County or Parisl	11. County or Parish, State	
Sec 20 T30N R14W NENW 1175FNL 1905FWL 36.803621 N Lat, 108.335078 W Lon			SAN JUAN CO	DUNTY, NM	
12. CHECK THE A	PPROPRIATE BOX(ES) TO	O INDICATE NATURE O	F NOTICE, REPORT, OR OT	THER DATA	
TYPE OF SUBMISSION		ТҮРЕ О	ACTION		
➤ Notice of Intent	☐ Acidize	☐ Deepen	☐ Production (Start/Resume)	☐ Water Shut-Off	
	☐ Alter Casing	☐ Hydraulic Fracturing	☐ Reclamation	☐ Well Integrity	
☐ Subsequent Report	☐ Casing Repair	■ New Construction	☐ Recomplete	☐ Other	
☐ Final Abandonment Notice	☐ Change Plans	□ Plug and Abandon	▼ Temporarily Abandon		
BP	☐ Convert to Injection	☐ Plug Back	☐ Water Disposal	Disposal	
Attach the Bond under which the wo	ork will be performed or provide the ind operations. If the operation result when the control of the control of the control of the control of the control	Bond No. on file with BLM/BIA s in a multiple completion or reco only after all requirements, includ rily abandon the subject we	red and true vertical depths of all perior . Required subsequent reports must lampletion in a new interval, a Form 3 ing reclamation, have been completed.  If with the intent are and	oe filed within 30 days 160-4 must be filed once	
		Make of Que	NMOCD		
Notify NMOCD 24 hrs prior to beginning operations  SEP 05 2019					
		D	ISTRICT III		
14. I hereby certify that the foregoing	Electronic Submission #477		Farmington 08/30/2019 (19JH0144SE)		
Name (Printed/Typed) AMANDA	WALKER	Title OPERA	TIONS REGULATORY TECH		
Signature (Electronic	Submission)	Date 08/09/20	019		
	THIS SPACE FOR	FEDERAL OR STATE	OFFICE USE		
Approved By JOHN HOFFMAN		TitleDETDOLE	UM ENGINEER	Date 08/30/2019	
Conditions of approval, if any, are attach certify that the applicant holds legal or ed which would entitle the applicant to conditions.	t warrant or bject lease	Office Farmington			
Title 18 U.S.C. Section 1001 and Title 4. States any false, fictitious or fraudulent	3 U.S.C. Section 1212, make it a crit		willfully to make to any department	or agency of the United	

(Instructions on page 2) \*\* BLM REVISED \*\* BLM REVISED \*\* BLM REVISED \*\* BLM REVISED \*\*





## Hilcorp Energy Company WF Federal 20-4

Temporarily Abandon API #: 3004531569

## PROCEDURE

- 1. Hold a pre-job safety meeting prior to beginning all operations or during a change in operational scope or initiation of SIMOPs. Properly document all operations via the JSA process. Insure that all personnel onsight abide by HEC safety protocol, including PPE, housekeeping, and procedures. Verify cathodic protection is off and wellhead instrumentation is properly disconnected from wellhead. Comply with all NMOCD, BLM, and HEC safety and environmental regulations. Verify there is no H2S present prior to beginning operations. If H2S is present, take the necessary actions to insure that the operation is safe prior to beginning operations. Observe and record pressures across all strings daily, prior to beginning operations. Notify NMOCD and BLM 24 hours in advance of beginning operations
- 2. MIRU service rig and associated equipment, ND casing risers
- 3. LOTO pumping unit, remove HH and bridle, PU on PR and unseat pump. POOH LD rods and pump.
- 4. ND tree and NU BOPs. Pressure and function test BOPs to 150/1500 psi.
- 5. PU on tbg, release hanger, scan and visually inspect tbg and POOH
- 6. PU junk mill and RIH to 1100', POOH LD junk mill
- 7. RIH w/ CBIP on tbg and set at 950', PT CIBP and casing to 600 psi, POOH w/ setting tool.
- 8. RBIH w/ 250' of tog to use as a kill string. NDNU tree verify tree and wellhead are equipped with functional pressure gauges. RDMO
- 9. Contact BLM and NMOCD to schedule witnessed MIT. PT csg to 600 psi.

