F.*rm 3160-5 (June 2015)

UNITED STATES DEPARTMENT OF THE INTERIOR

FORM APPROVED OMB NO. 1004-0137

BUREAU OF LAND MANAGEMENT SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals.					Expires: Ja	anuary 31, 2018
					5. Lease Serial No. NMNM047	
					6. If Indian, Allottee or Tribe Name	
SUBMIT IN TRIPLICATE - Other instructions on page 2					7. If Unit or CA/Agreement, Name and/or No.	
Type of Well Oil Well					8. Well Name and No. NEW MEXICO FEDERAL N 1G	
2. Name of Operator Contact: MANDI WALKER HILCORP ENERGY COMPANY E-Mail: mwalker@hilcorp.com					9. API Well No. 30-045-33242-00-S1	
3a. Address 1111 TRAVIS STREET HOUSTON, TX 77002			o. (include area code) 24-5122		10. Field and Pool or Exploratory Area BASIN DAKOTA	
4. Location of Well (Footage, Sec., 7	11. County or Parish, State					
Sec 17 T30N R12W NESW 2008FNL 1315FWL 36.811374 N Lat, 108.125199 W Lon				SAN JUAN COUNTY, NM		
12. CHECK THE AI	PPROPRIATE BOX(ES)	TO INDICA	TE NATURE O	F NOTICE,	REPORT, OR OTH	HER DATA
TYPE OF SUBMISSION	TYPE OF ACTION					
Notice of Intent	☐ Acidize	☐ De	epen	☐ Product	ion (Start/Resume)	☐ Water Shut-Off
_	☐ Alter Casing	□ Ну	draulic Fracturing	☐ Reclam	ation	☐ Well Integrity
☐ Subsequent Report	☐ Casing Repair	□ Ne	w Construction	☐ Recomp	olete	Other
☐ Final Abandonment Notice	☐ Change Plans	☐ Change Plans ☐ Plug and Abandon ☒ Temporarily Abandon		arily Abandon		
38	☐ Convert to Injection	☐ Plu	g Back	■ Water Disposal		
If the proposal is to deepen directions Attach the Bond under which the wo following completion of the involved testing has been completed. Final At determined that the site is ready for f Hilcorp Energy Company requ procedure and wellbore scher	rk will be performed or provide d operations. If the operation re- bandonment Notices must be file final inspection.	the Bond No. of sults in a multipled only after all	on file with BLM/BIA ole completion or reco requirements, includ	. Required submpletion in a ring reclamation	osequent reports must be new interval, a Form 316, n, have been completed a ached	filed within 30 days 0-4 must be filed once
					NMOGD	
Notify NMOCD 24 hrs prior to beginning operations			SEP 05 2019 DISTRICT III			
	Electronic Submission #4 For HILCORP EN mmitted to AFMSS for prod	NERGY COM	ANY, sent to the HN HOFFMAN on	Farmington 09/04/2019 (19JH0161SE)	g
Name (Printed/Typed) MANDI WALKER			Title OPERATIONS REGULATORY TECH - S			
Signature (Electronic Submission)			Date 08/22/20	019		
	THIS SPACE FO	R FEDER	AL OR STATE	OFFICE US	SE	
Approved By JOHN HOFFMAN Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease				TitlePETROLEUM ENGINEER Date 09/04/2019		
which would entitle the applicant to condu	•		Office Farming			
Title 18 U.S.C. Section 1001 and Title 43	U.S.C. Section 1212, make it a	crime for any p	erson knowingly and	willfully to ma	ke to any department or	agency of the United

States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.





Hilcorp Energy Company NEW MEXICO COM N 1G

Temporarily Abandon API #: 3004533242

PROCEDURE

- 1. Hold a pre-job safety meeting prior to beginning all operations or during a change in operational scope or initiation of SIMOPs. Property document all operations via the JSA process. Insure that all personnel onsight abide by HEC safety protocol, including PPE, housekeeping, and procedures. Verify cathodic protection is off and wellhead instrumentation is properly disconnected from wellhead. Comply with all NMOCD, BLM, and HEC safety and environmental regulations. Verify there is no H2S present prior to beginning operations. If H2S is present, take the necessary actions to insure that the operation is safe prior to beginning operations. Observe and record pressures across all strings daily, prior to beginning operations. Notify NMOCD and BLM 24 hours in advance of beginning operations
- 2. RU slickline. RIH and clear tbg. Attempt to fish any obstructions or set a 3-slip stop in the tbg.
- 3. MIRU service rig and associated equipment, ND casing risers
- 4. ND tree and NU BOPs. Pressure and function test BOPs to 150/1500 psi.
- 5. PU on tbg, release hanger, scan and visually inspect tbg and POOH
- 6. PU junk mill and RIH to 6730', POOH LD junk mill
- 7. RIH w/ CBIP on tbg and set at 6500', PT CIBP and casing to 600 psi, POOH w/ setting tool.
- 8. RBIH w/ 250' of tbg to use as a kill string. NDNU tree verify tree and wellhead are equipped with functional pressure gauges. RDMO
- 9. Contact BLM and NMOCD to schedule witnessed MiT. PT csg to 600 psi.

