

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
OMB No. 1004-0137
Expires: January 31, 2018

SUNDRY NOTICES AND REPORTS ON WELLS
**Do not use this form for proposals to drill or to re-enter an
abandoned well. Use Form 3160-3 (APD) for such proposals.**

5. Lease Serial No. 301266

6. If Indian, Allottee or Tribe Name
Jicarilla Apache

SUBMIT IN TRIPLICATE - Other instructions on page 2

7. If Unit of CA/Agreement, Name and/or No.

1. Type of Well

☐ Oil Well ☐ Gas Well ☒ Other

8. Well Name and No. Apache #154. Well No. #154

2. Name of Operator
Enervest Operating LLC

9. API Well No. 30-039-23886

3a. Address 2700 Farmington Ave, Building K, Suite 1.
Farmington NM 87401

3b. Phone No. (include area code)
(505) 325-0318

10. Field and Pool or Exploratory Area
W>Lindrith Gal/Dak

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
O-03-24N-04W Lat/Long: 36.33489, -107.24331 NAD83

11. Country or Parish, State
Rio Arriba, New Mexico

12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/Resume)	<input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing	<input type="checkbox"/> Hydraulic Fracturing	<input type="checkbox"/> Reclamation	<input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete	<input checked="" type="checkbox"/> Other
	<input type="checkbox"/> Change Plans	<input type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Temporarily Abandon	
	<input type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal	

13. Describe Proposed or Completed Operation. Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleate horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleation in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.)

Reference #IMPK1913527132

Enervest Operating proposes to isolate the casing to find and repair possible Bradenhead leak. Work will begin before August 20, 2019.

NMOCD will be notified 24 hours before work commences.

Please see attached documents

NMOCD

SEP 25 2019

DISTRICT III

14. I hereby certify that the foregoing is true and correct. Name (Printed/Typed)

Mickey Ahrens

Title Prod Supt

Signature

Date 6-19-19

THE SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

Title

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C Section 1001 and Title 43 U.S.C Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)

NMOCD

Apache 127 # 154 Squeeze Work

- Day 1 Pull Tubing- RIH w/ Casing scraper to top perf.
 RIH w/ RBP/Packer. Set Plug @ 6800'. Test to 1000 psi
 Test casing to 500 psi. POH testing casing.
- Day 2 Finish isolating hole in casing. POH w/ packer. Run CBL (Basin Logging)
 Send log to NMOCD/BLM
- Day 3 Squeeze hole w/ Aplus
- Day 4 Pick up drill collars. Drill cement. Run MIT. If holds set up NMOCD to witness
 MIT.
- Day 5 NMOCD witness MIT. RIH w/ tbg and retrieve RBP. POH. RIH w/
 production tbg. Land well. Clean pits. Put well on prod.
-