Form 3160-5 (June 2015)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0137 Expires: January 31, 2018 Lease Serial No.

SU	INDRY	NOTIC	ES AN	D REP	ORTS	ON	NELLS	
Do no	t use th	is form	for pro	posals i	to drill	or to	re-enter	aı

abandoned well. Use form 3160-3 (APD) for such proposals. SUBMIT IN TRIPLICATE - Other instructions on page 2 7. If Unit or CA/. 1. Type of Well		SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals.						
1. Type of Well								
Oil Well Gas Well Other	T IN TRIPLICATE - Other instructions on page 2 7. If Unit or CA/Agreement, Name and/or No.	SUBMIT IN TRIPLICATE - Other instructions on page 2						
2. Name of Operator HILCORP ENERGY COMPANY B-Mail: ettrujillo@hilcorp.com 30-039-064 30	8. Well Name and No. JICARILLA A 5							
382 ROAD 3100 AZTEC, NM 87410 4. Location of Well (Footage, Sec., T., R., M., or Survey Description) Sec 23 T26N R4W NENE 930FNL 960FEL 36.476718 N Lat, 107.215606 W Lon 12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OR TYPE OF SUBMISSION TYPE OF SUBMISSION TYPE OF ACTION Notice of Intent Alter Casing Hydraulic Fracturing Reclamation Casing Repair New Construction Recomplete Final Abandonment Notice Convert to Injection Plug Back Water Disposal 13. Describe Proposed or Completed Operation. Clearly state all pertinent details, including estimated starting date of any proposed work and a If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all paths of the Work will be performed or provide the Bond No. on file with BLM/BHA. Required subsequent reports multipllowing completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed that the site is ready for final inspection. Hilcorp Energy Company requests permission to temporarily abandon the PC wellbore for future potential. If the wellbore MIT does not pass, then Hilcorp Energy Company requests approval to plug and abandon the wellbore. Attached is current wellbore schematic, proposed TA and P&A schematic with procedure and reclamation plan. Pre-onsite inspection conducted 5/15/19 w/Bob Switzer (BLM) and Bryan Hall (HEC).	Contact: ETTA TRUJILLO 9. API Well No.	2. Name of Operator Contact: ETTA TRUJILLO						
Sec 23 T26N R4W NENE 930FNL 960FEL 36.476718 N Lat, 107.215606 W Lon 12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR ON TYPE OF SUBMISSION TYPE OF SUBMISSION Acidize Deepen		3a. Address 382 ROAD 3100						
12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR ON TYPE OF SUBMISSION TYPE OF SUBMISSION Acidize Deepen	Sec., T., R., M., or Survey Description) 11. County or Parish, State	4. Location of Well (Footage, Sec., T.						
TYPE OF SUBMISSION Acidize		Sec 23 T26N R4W NENE 930FNL 960FEL						
Notice of Intent Acidize Deepen Production (Start/Resumed Alter Casing Hydraulic Fracturing Reclamation Recomplete Casing Repair New Construction Recomplete Pinal Abandonment Notice Change Plans Plug and Abandon Temporarily Abandon Convert to Injection Plug Back Water Disposal	HE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA	12. CHECK THE AF						
Subsequent Report	TYPE OF ACTION	TYPE OF SUBMISSION						
Subsequent Report Gasing Repair New Construction Recomplete	☐ Acidize ☐ Deepen ☐ Production (Start/Resume) ☐ Water Shut-Off	Notice of Intent						
Final Abandonment Notice	☐ Alter Casing ☐ Hydraulic Fracturing ☐ Reclamation ☐ Well Integrity							
13. Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and a If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all p Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports mu following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completermined that the site is ready for final inspection. Hilcorp Energy Company requests permission to temporarily abandon the PC wellbore for future potential. If the wellbore MIT does not pass, then Hilcorp Energy Company requests approval to plug and abandon the wellbore. Attached is current wellbore schematic, proposed TA and P&A schematic with procedure and reclamation plan. Pre-onsite inspection conducted 5/15/19 w/Bob Switzer (BLM) and Bryan Hall (HEC).	☐ Casing Repair ☐ New Construction ☐ Recomplete ☑ Other	☐ Subsequent Report						
13. Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and a If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all particle. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed that the site is ready for final inspection. Hilcorp Energy Company requests permission to temporarily abandon the PC wellbore for future potential. If the wellbore MIT does not pass, then Hilcorp Energy Company requests approval to plug and abandon the wellbore. Attached is current wellbore schematic, proposed TA and P&A schematic with procedure and reclamation plan. Pre-onsite inspection conducted 5/15/19 w/Bob Switzer (BLM) and Bryan Hall (HEC).	ice Change Plans Plug and Abandon Temporarily Abandon	☐ Final Abandonment Notice						
If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all p Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports mu following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completermined that the site is ready for final inspection. Hilcorp Energy Company requests permission to temporarily abandon the PC wellbore for future potential. If the wellbore MIT does not pass, then Hilcorp Energy Company requests approval to plug and abandon the wellbore. Attached is current wellbore schematic, proposed TA and P&A schematic with procedure and reclamation plan. Pre-onsite inspection conducted 5/15/19 w/Bob Switzer (BLM) and Bryan Hall (HEC).	Convert to Injection Plug Back Water Disposal	BY						
and abandon the wellbore. Attached is current wellbore schematic, proposed TA and P&A schematic with procedure and reclamation plan. Pre-onsite inspection conducted 5/15/19 w/Bob Switzer (BLM) and Bryan Hall (HEC).	rectionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones, the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days a provided operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 must be filed once in a Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has dry for final inspection.	If the proposal is to deepen directional Attach the Bond under which the wor following completion of the involved testing has been completed. Final Abdetermined that the site is ready for final Abdetermined that the site is ready for final Hilcorp Energy Company requirements.						
	re. Attached is current wellbore schematic, proposed TA and P&A schematic	and abandon the wellbore. Att with procedure and reclamation						
Notify NMOCD at how	NMOCD	and Bryan Hall (HEC).						
prior to beginning operations								
	DISTRICT 111							

14. Thereby certify that th	Electronic Submission #478385 verifie For HILCORP ENERGY COM Committed to AFMSS for processing by ALBER	ANY,	sent to the Rio Puerco				
Name (Printed/Typed)	ETTA TRUJILLO	Title	OPERATIONS REGULATORY TECH SR				
Signature	(Electronic Submission)	Date	08/15/2019				
THIS SPACE FOR FEDERAL OR STATE OFFICE USE							
Approved By JOE KILLINS			PETROLEUM ENGINEER	Date 10/08/2019			
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.			Rio Puerco				
	1 and Title 43 U.S.C. Section 1212, make it a crime for any peor fraudulent statements or representations as to any matter w			ey of the United			

(Instructions on page 2) ** BLM REVISED **






JOB PROCEDURES

- 1. Hold pre-job safety meeting. Verify cathodic is off. Comply with all NMOCD, BLM, and HEC safety and environmental regulations.
- 2. Check casing, tubing, and bradenhead pressures and record them in WellView. If there is pressure on the BH, contact Operations Engineer.
- 3. MIRU service rig and associated equipment; NU and test BOP.
- 4. TOOH w/ tubing set @ 3,842'.
- 5. PU tubing/work string, TIH w/ 5.5" plug, and set plug @ +/- 3,773'.
- Perform Mechanical Integrity Test (MIT) by pressure testing the 5.5" casing above the plug set @ 3,773' to 560 psig for 30 minutes on a 2 hour chart
 with a 1,000 lb spring.
- 7. IF the MIT Passes, TOOH w/ tubing/work string, shut in well, and RDMO workover rig. IF MIT falls, proceed to P&A procedure starting with Step #8.
- 8. All cement volumes use 100% excess for a casing-open hole annulus and 50' excess for inside casing or a casing-casing annulus. The stabilizing wellbore fluid will be 8.3 ppg, sufficient to balance all exposed formation pressures. All cement will be Class B.
- TOOH w/ tubing/work string. Load the 5.5" casing w/ 2% KCL to surface. RU WL and run CBL from plug set @ 3,773' to surface. Adjust plugs as necessary for new TOC. Email log copy to BLM and NMOCD.
- 10. Plug #1: PICTURED CLIFFS, PRODUCTION CASING SHOE, FRUITLAND AND OJO ALAMO FORMATION TOPS (3,260' 3,773', 64 Sacks of Class B Cement Total):
 - Pump a balanced cement plug leaving +/- 513' of cement within the 5.5" casing (64 sacks (50' excess) of Class B cement with an estimated TOC @ +/- 3,260' and an estimated BOC @ +/- 3,773')
- TOOH w/ tubing/work string. RU WL and perforate 3 squeeze holes @ +/- 2,150'. Establish rate into squeeze holes. RIH w/ 5.6" CICR and set CICR @ +/- 2,100'.
- 12. Plug #2: NACIMIENTO FORMATION TOP (2,050' 2,150', 60 Sacks of Class B Cement Total):


 Pump a cement squeeze leaving +/- 100' of cement within the 5-1/2" x 8-3/4" casing open hole annulus (43 sacks (100% excess) of Class B cement with an estimated TOC @ +/- 2,050' and an estimated BOC @ +/- 2,150'), pump a +/- 50' cement plug beneath the 5.5" CICR (6 sacks of Class B cement with an estimated TOC @ +/- 2,100' and an estimated BOC @ +/- 2,150'). Sting out of retainer, pump +/- 50' balanced cement plug (11 sacks (50' excess) of Class B cement with an estimated TOC @ +/- 2,050' and an estimated BOC @ +/- 2,100').
- 13. TOOH w/ tubing/work string. RU WL and perforate 4 squeeze holes @ +/- 206*. TOOH and RD WL. Observe well for 30 minutes per BLM regulations. Establish circulation out BH w/ water. Circulate BH clean..
- 14. Plug #3: SURFACE PLUG (0' 206'), 98 Sacks of Class B Cement Total):

 Pump a cement squeeze leaving +/- 156' of cement within the 5-1/2" x 8.92" casing annulus and +/- 50' of cement within the 5-1/2" x 8.94" casing-open hole annulus (47 sacks (50' excess) of Class B cement within the 5-1/2" x 8.92" casing annulus and 22 sacks (100% excess) of Class B cement within the 5-1/2" x 8-3/4" casing-open hole annulus with an estimated TOC @ +/- 0' and an estimated BOC @ +/- 206'), circulate til cement returns out BH valve, pump a +/- 206' cement plug in the 5.5" casing from surface (29 sacks (50' excess) of Class B cement with an estimated TOC @ +/- 0' and an estimated BOC @ +/- 206').
- 15. TIH and tag cement top in 5.5" casing. If no cement: cement from surface to fill annular volume.
- 16. ND BOP, cut off casing below casing flange. Top off cement in surface casing annulus, if needed. Install a P&A marker with cement to comply with regulations. Rig down, move off location, cut off anchors, and restore location.














UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT FARMINGTON DISTRICT OFFICE

6251 COLLEGE BLVD. FARMINGTON, NEW MEXICO 87402

Attachment to notice of Intention to Abandon:

Re: Permanent Abandonment
Well: Jicarilla A 5 API: 30-039-06419

CONDITIONS OF APPROVAL

- 1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal and Indian Lease."
- 2. Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 564-7750.
- 3. Submit electronic copy of the CBL for verification to the following addresses: jkillins@blm.gov, jhoffman@blm.gov and Brandon.Powell@state.nm.us. Based on CBL results inside/outside plugs and volumes will be adjusted accordingly. Please review the General Requirements document to ensure volumes meet required excess inside and outside casing.
- 4. To plug the open-hole section of the well a cement plug shall be placed to extend at least 50 feet below bottom of casing except as limited by TD or PBTD to 50 feet above casing bottom depth.

GENERAL REQUIREMENTS FOR PERMANENT ABANDONMENT OF WELLS ON FEDERAL AND INDIAN LEASES FARMINGTON FIELD OFFICE

- 1.0 The approved plugging plans may contain variances from the following minimum general requirements.
 - 1.1 Modification of the approved plugging procedure is allowed only with the prior approval of the Authorized Officer, Farmington Field Office.
 - 1.2 Requirements may be added to address specific well conditions.
- 2.0 Materials used must be accurately measured. (densometer/scales)
- 3.0 A tank or lined pit must be used for containment of any fluids from the wellbore during plugging operations and all pits are to be fenced with woven wire. These pits will be fenced on three sides and once the rig leaves location, the fourth side will be fenced.
 - 3.1 Pits are not to be used for disposal of any hydrocarbons. If hydrocarbons are present in the pit, the fluids must be removed prior to filling in.
- 4.0 All cement plugs are to be placed through a work string. Cement may be bull-headed down the casing with prior approval. Cement caps on top of bridge plugs or cement retainers may be placed by dump bailer.
 - 4.1 The cement shall be as specified in the approved plugging plan.
 - 4.2 All cement plugs placed inside casing shall have sufficient volume to fill a minimum of 100' of the casing, or annular void(s) between casings, plus an excess volume sufficient to provide for 50 linear feet of fill above the plug.
 - 4.3 Surface plugs may be no less than 50' in length.
 - 4.4 All cement plugs placed to fill annular void(s) between casing and the formation shall be of sufficient volume to fill a minimum of 100' of the annular space plus 100% excess, calculated using the bit size, or 100' of annular capacity, determined from a caliper log, plus an excess volume sufficient to provide for 50 linear feet of fill above the plug.
 - 4.5 All cement plugs placed to fill an open hole shall be of sufficient volume to fill a minimum of 100' of hole, as calculated from a caliper log, plus an excess volume sufficient to provide for 50 linear feet of fill above the plug. In the absence of a caliper log, an excess of 100% shall be required.
 - 4.6 A cement bond log or other accepted cement evaluation tool is required to be run if one had not been previously ran or cement did not circulate to surface during the original casing cementing job or subsequent cementing jobs.

- 5.0 All cement plugs spotted across, or above, any exposed zone(s), when; the wellbore is not full of fluid or the fluid level will not remain static, and in the case of lost circulation or partial returns during cement placement, shall be tested by tagging with the work string.
 - 5.1 The top of any cement plug verified by tagging must be at or above the depth specified in the approved plan, without regard to any excess.
 - 5.2 Testing will not be required for any cement plug that is mechanically contained by use of a bridge plug and/or cement retainer, if casing integrity has been established.
 - 5.3 Any cement plug which is the only isolating medium, for a fresh water interval or a zone containing a prospectively valuable deposit of minerals, shall be tested by tagging.
 - 5.4 If perforations are required below the surface casing shoe, a 30 minute minimum wait time will be required to determine if gas and/or water flows are present. If flow is present, the well will be shut-in for a minimum of one hour and the pressure recorded. Short or long term venting may be necessary to evacuate trapped gas. If only a water flow occurs with no associated gas, shut well in and record the pressures. Contact the Engineer as it may be necessary to change the cement weight and additives.
- 6.0 Before setting any cement plugs the hole needs to be rolled. All wells are to be controlled by means of a fluid that is to be of a weight and consistency necessary to stabilize the wellbore. This fluid shall be left in place as filler between all plugs.
 - 6.1 Drilling mud may be used as the wellbore fluid in open hole plugging operations.
 - 6.2 The wellbore fluid used in cased holes shall be of sufficient weight to balance known pore pressures in all exposed formations.
- 7.0 A blowout preventer and related equipment (BOPE) shall be installed and tested prior to working in a wellbore with any exposed zone(s); (1) that are over pressured, (2) where the pressures are unknown, or (3) known to contain H_2S .
- 8.0 Within 30 days after plugging work is completed, file a Sundry Notice, Subsequent Report of Abandonment (Form 3160-5), five copies, with the Field Manager, Bureau of Land Management, 6251 College Blvd., Suite A, Farmington, NM 87402. The report should show the manner in which the plugging work was carried out, the extent, by depth(s), of cement plugs placed, and the size and location, by depth(s), of casing left in the well. Show date well was plugged.
- 9.0 All permanently abandoned wells are to be marked with a permanent monument as specified in 43 CFR 3162.6(d). Unless otherwise approved.
- 10.0 If this well is located in a Specially Designated Area (SDA), compliance with the appropriate seasonal closure requirements will be necessary.

All of the above are minimum requirements. Failure to comply with the above conditions of approval may result in an assessment for noncompliance and/or a Shut-in Order being issued pursuant to 43 CFR 3163.1. You are further advised that any instructions, orders or decisions issued by the Bureau of Land Management are subject to administrative review pursuant to 43 CFR 3165.3 and appeal pursuant to 43 CFR 3165.4 and 43 CFR 4.700.