В	UNITED STATES EPARTMENT OF THE IN UREAU OF LAND MANAG NOTICES AND REPOR	EMENT	LLS			PPROVE 0. 1004-013 1004-013 1004-013	37
Do not use th	is form for proposals to d II. Use form 3160-3 (APD)	Irill or to re-	enter an		6. If Indian, Allottee or EASTERN NAVA		ne
SUBMIT IN	TRIPLICATE - Other instru	uctions on	page 2		7. If Unit or CA/Agreen NMNM87138	ment, Nam	e and/or No.
<ol> <li>Type of Well</li> <li>☐ Oil Well</li> <li>☐ Gas Well</li> <li>☑ Otl</li> </ol>	her: COAL BED METHANE				8. Well Name and No. BUENA SUERTE	COM 1T	г
2. Name of Operator DJR OPERATING LLC		LICE MASC s@djrllc.com	ARENAS		9. API Well No. 30-045-32007-00	)-S1	
3a. Address 1 ROAD 3263 AZTEC, NM 87410		3b. Phone No Ph: 505-63	(include area code) 2-3476		10. Field and Pool or E BASIN FRUITLA	xploratory ND COA	Area AL
4. Location of Well (Footage, Sec., 7	"., R., M., or Survey Description)				11. County or Parish, S	tate	
Sec 4 T25N R11W SWNW 15 36.431200 N Lat, 108.014867					SAN JUAN COU	NTY, NN	Λ
12. CHECK THE A	PPROPRIATE BOX(ES) T	O INDICA	TE NATURE O	F NOTICE,	REPORT, OR OTH	ER DAT	`A
TYPE OF SUBMISSION			TYPE OF	ACTION			
Notice of Intent	□ Acidize	Deep	ben	Product	on (Start/Resume)	U Wate	er Shut-Off
Subsequent Report	□ Alter Casing		raulic Fracturing	Reclama		-	Integrity
_	Casing Repair	_	Construction	Recomp		Othe	r
□ Final Abandonment Notice	<ul> <li>Change Plans</li> <li>Convert to Injection</li> </ul>	Plug	and Abandon	□ Tempor	arily Abandon		
DJR Operating, LLC. request procedure, wellbore diagram,		don the sub	ect well per the a	attached			
					NMOCD	enectronate:	
					MAR 1 2 2020		
Notify the OCO 2	14hrs. prior to k	reginnin	s operatio	ns D	STRICT III	- स्वयं स्वयं द	
14. I hereby certify that the foregoing is	s true and correct. Electronic Submission #50	0411 verifie	by the BLM Wel	I Information	System		
Commit	For DJR OPE	by ALBERT	, sent to the Farr A WETHINGTON	nington on 01/24/202	0 (20AMW0030SE)		
Name (Printed/Typed) ALICE MA	ASCARENAS		Title REGUL	ATORY TEO	CHNICIAN		
Signature (Electronic	Submission)		Date 01/23/20				
	THIS SPACE FOR	R FEDERA	L OR STATE	OFFICE US	SE		
_Approved By_JOE KILLINS			TitlePETROLE		ER	Dat	te 03/06/2020
Conditions of approval, if any, are attached certify that the applicant holds legal or eq which would entitle the applicant to condu-	uitable title to those rights in the s		Office Farming	ton			
Title 18 U.S.C. Section 1001 and Title 43 States any false, fictitious or fraudulent				willfully to ma	ke to any department or a	gency of t	he United
(Instructions on page 2) <b>** BLM REV</b>	ISED ** BLM REVISED	** BLM RE	VISED ** BLN		** BLM REVISED	**	
		P	(				

9

\$

¢

#### **Plug and Abandonment Procedure**

for

DJR Operating, LLC Buena Suerte 4 Com 1T API # 30-045-32007 SW/NW, Unit E, Sec. 4, T25N, R11W San Juan County, NM

I.

- 1. Hold Pre job meeting, comply with all NMOCD, BLM and environmental regulations.
- 2. Check and record tubing, casing and bradenhead pressures.
- 3. Remove existing piping from casing valve, RU blow lines from casing valves and blow down casing pressure. Kill well as necessary. Ensure that well is dead or on a vacuum.
- 4. Trip out of hole with rods and pump. Lay down to be sent in for storage/salvage.
- 5. ND WH, NU BOP, function test BOP.
- 6. Trip out of hole with 2 3/8" tubing. LD tubing to be sent in for storage/salvage.


#### П.

- 7. PU workstring, TIH with bit and scraper, make sure that the bit and scraper will go below 1275'. TOOH.
- 8. PU and RIH with a 4 <sup>1</sup>/<sub>2</sub>" cement retainer. Set the CR at +/- 1275'. Pressure test tubing to 1000 psi, sting out of CR, test casing to 800 psi. If casing does not test, contact engineering.

#### Provided that casing test was good, proceed to step 9.

- 9. RU up cement equipment. Pump water to assure that tubing is clear.
- Plug 1. Fruitland, Kirtland, Ojo Alamo and surface casing shoe. From 1275' to surface, 111 cu ft, 97 sx Class G at 1.15 yield. With 50% excess = 145 sx. (or pump cement until circulation is achieved at surface.)

- 11. RD cementing equipment. Cut off wellhead, fill annuli with cement as necessary. Install P&A marker as per regulatory requirements. Record GPS coordinates for P&A marker and the Final P&A Report. Photograph the P&A marker and attach to the report.
- 12. RD and MO all rig and cement equipment. Assure that location is free of trash and contamination before moving off.
- 13. Send all reports and attachments to DJR Aztec office for regulatory filings.



+ -

- - - <u>-</u> - -

1.11

. . . . . . . .

## Proposed Wellbore P&A Diagram DJR Operating, LLC Buena Suerte 4 Com 1T API # 30-045-32007 SW/NW, Unit E, Sec 4, T25N, R11W

San Juan County, NM GL 6358'

KB 6363' Spud Date 4/16/2004

		FORMATION	TOPS	Plug Detail	į			
<u>SURF CSG</u> Hole size Csg Size:				<u>Plug 1:</u> Fruitland, Kirtland, Oj Surface shoe to surface. 1275 Class G cement.				
Wt: Grade: ID:	23# J-55 6.336	Nacimiento	Surface			]		
Depth cap cf/ft:	135	<b>Ojo Alamo</b>		L				
TOC:		Kirtland	862'					
<u>PROD CSG</u> Hole size Csg Size: Wt:	6.25 4.5 11.6#	Fruitland	1313'					
Grade:	J-55	Pictured Cliffs	1348'					
cap cf/ft: Csg/Csg Ann, cf/ft TOC:	0.1106							
	Surf			Cement Retainer	1275'		~~~~	
				Fruitland perfs 13	302 to 1322'			<b>&gt;&gt;&gt;</b>
				PBTD 14 TD 15				

## GENERAL REQUIREMENTS FOR PERMANENT ABANDONMENT OF WELLS ON FEDERAL AND INDIAN LEASES FARMINGTON FIELD OFFICE

1.0 The approved plugging plans may contain variances from the following <u>minimum general</u> requirements.

- 1.1 Modification of the approved plugging procedure is allowed only with the prior approval of the Authorized Officer, Farmington Field Office.
- 1.2 Requirements may be added to address specific well conditions.
- 2.0 Materials used must be accurately measured. (densometer/scales)

3.0 A tank or lined pit must be used for containment of any fluids from the wellbore during plugging operations and all pits are to be fenced with woven wire. These pits will be fenced on three sides and once the rig leaves location, the fourth side will be fenced.

3.1 Pits are not to be used for disposal of any hydrocarbons. If hydrocarbons are present in the pit, the fluids must be removed prior to filling in.

4.0 All cement plugs are to be placed through a work string. Cement may be bull-headed down the casing with prior approval. Cement caps on top of bridge plugs or cement retainers may be placed by dump bailer.

- 4.1 The cement shall be as specified in the approved plugging plan.
- 4.2 All cement plugs placed inside casing shall have sufficient volume to fill a minimum of 100' of the casing, or annular void(s) between casings, plus an excess volume sufficient to provide for 50 linear feet of fill above the plug.
- 4.3 Surface plugs may be no less than 50' in length.
- 4.4 All cement plugs placed to fill annular void(s) between casing and the formation shall be of sufficient volume to fill a minimum of 100' of the annular space plus 100% excess, calculated using the bit size, or 100' of annular capacity, determined from a caliper log, plus an excess volume sufficient to provide for 50 linear feet of fill above the plug.
- 4.5 All cement plugs placed to fill an open hole shall be of sufficient volume to fill a minimum of 100' of hole, as calculated from a caliper log, plus an excess volume sufficient to provide for 50 linear feet of fill above the plug. In the absence of a caliper log, an excess of 100% shall be required.
- 4.6 A cement bond log or other accepted cement evaluation tool is required to be run if one had not been previously ran or cement did not circulate to surface during the original casing cementing job or subsequent cementing jobs.

5.0 All cement plugs spotted across, or above, any exposed zone(s), when; the wellbore is not full of fluid or the fluid level will not remain static, and in the case of lost circulation or partial returns during cement placement, shall be tested by tagging with the work string.

- 5.1 The top of any cement plug verified by tagging must be at or above the depth specified in the approved plan, without regard to any excess.
- 5.2 Testing will not be required for any cement plug that is mechanically contained by use of a bridge plug and/or cement retainer, if casing integrity has been established.
- 5.3 Any cement plug which is the only isolating medium, for a fresh water interval or a zone containing a prospectively valuable deposit of minerals, shall be tested by tagging.
- 5.4 If perforations are required below the surface casing shoe, a 30 minute minimum wait time will be required to determine if gas and/or water flows are present. If flow is present, the well will be shut-in for a minimum of one hour and the pressure recorded. Short or long term venting may be necessary to evacuate trapped gas. If only a water flow occurs with no associated gas, shut well in and record the pressures. Contact the Engineer as it may be necessary to change the cement weight and additives.

6.0 Before setting any cement plugs the hole needs to be rolled. All wells are to be controlled by means of a fluid that is to be of a weight and consistency necessary to stabilize the wellbore. This fluid shall be left in place as filler between all plugs.

- 6.1 Drilling mud may be used as the wellbore fluid in open hole plugging operations.
- 6.2 The wellbore fluid used in cased holes shall be of sufficient weight to balance known pore pressures in all exposed formations.

7.0 A blowout preventer and related equipment (BOPE) shall be installed and tested prior to working in a wellbore with any exposed zone(s); (1) that are over pressured, (2) where the pressures are unknown, or (3) known to contain  $H_2S$ .

8.0 Within 30 days after plugging work is completed, file a Sundry Notice, Subsequent Report of Abandonment (Form 3160-5), five copies, with the Field Manager, Bureau of Land Management, 6251 College Blvd., Suite A, Farmington, NM 87402. The report should show the manner in which the plugging work was carried out, the extent, by depth(s), of cement plugs placed, and the size and location, by depth(s), of casing left in the well. Show <u>date</u> well was plugged.

9.0 All permanently abandoned wells are to be marked with a permanent monument as specified in 43 CFR 3162.6(d). Unless otherwise approved.

10.0 If this well is located in a Specially Designated Area (SDA), compliance with the appropriate seasonal closure requirements will be necessary.

All of the above are minimum requirements. Failure to comply with the above conditions of approval may result in an assessment for noncompliance and/or a Shut-in Order being issued pursuant to 43 CFR 3163.1. You are further advised that any instructions, orders or decisions issued by the Bureau of Land Management are subject to administrative review pursuant to 43 CFR 3165.3 and appeal pursuant to 43 CFR 3165.4 and 43 CFR 4.700.

## UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT FARMINGTON DISTRICT OFFICE 6251 COLLEGE BLVD. FARMINGTON, NEW MEXICO 87402

Attachment to notice of Intention to Abandon:

Re: Permanent Abandonment Well: Buena Suerte 4 Com 1T

#### **CONDITIONS OF APPROVAL**

1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal and Indian Lease."

2. Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 564-7750.

# BLM FLUID MINERALS Geologic Report

Date Completed: 3/4/20

\_

Well No.	Buena Suerte	4 Com # 1T	Location	1505'	FNL	&	1035'	- FWL
Lease No.	N00C142036	02	Sec. 4		Γ25N			R11W
Operator	DJR		County	San Ju	an	State	New M	exico
Total Depth	1525'	PBTD 1447'	Formation	Fruitland				
Elevation (GL)	6358'		Elevation (K)	B) 6370' (est.	)			

<b>Geologic Formations</b>	Est. Top	Est. Bottom	Log Top	Log Bottom	Remarks
San Jose Fm					Surface/Fresh water sands
Nacimiento Fm			Surface	805'	Fresh water sands
Ojo Alamo Ss			805′	862'	Aquifer (fresh water)
Kirtland Shale			862'	1313'	
Fruitland Fm			1313'	1348'	Coal/Gas/Possible water
Pictured Cliffs Ss			1348′	'	Gas
Lewis Shale					
Chacra					Probable water or dry
La Ventana Tongue					Probable water or dry
Cliff House Ss					Water/Possible gas
Menefee Fm					Coal/Ss/Water/Possible O&G
Point Lookout Ss					Probable water/Possible O&G
Mancos Shale					Source rock
Gallup					O&G/Water
Dakota					O&G/Water

Remarks: P & A

Reference Well: 1) DJR Same

Fm. Tops

te eta uni

- Please ensure that the tops of the Pictured Cliffs and Fruitland formations as well as the entire Ojo Alamo aquifer, identified in this report, are isolated by proper placement of cement plugs. This will protect the freshwater sands in this well bore.

Prepared by: Walter Gage