

Evans Production Co.
Bullseye A #2 P-13-16N-10W

Presumed Downhole Conditions and Equipment

8 5/8" casing at 30' with 10 sacks of cement
4 1/2" casing at 865' with 59 cu. ft. of cement
Deepened to an unknown depth (probably 900'-1000'
in massive Gallup)

Division Approved Plugging Program

1. Go in hole with tubing and clean out hole to TD. Set a 200' bottom plug.
2. Wait on cement a minimum of 3 hours. Go in hole with tubing and tag plug #1. If plug is in place go to step 3. If not, fill to required depth. Come out of hole with tubing.
3. Perforate 4 1/2" casing at 150'. Set a cement plug 150' to surface in and outside casing.
4. Set dry hole marker, fill pits, clean and level location.

All plugs will be with neat cement with or without an accelerator.

Note: This is a re-entry on which we have incomplete records. If other conditions are found to exist. The plugging program will be revised.