State of New Mexico Energy, Minerals and Natural Resources Department Oil Conservation Division

			API # (assigned by OCD	
I. Type of Well OIL			5.	Lease Number Fee
			6.	State Oil & Gas Lease
2. Name of Operator Geo Engineering			7.	Lease Name/Unit Name Santa Fe Pacific I
3. Address & Phone No. of Operat			8.	Well No. #20
P.O.Box 2966 Santa Fe, NM 87505			9.	Pool Name or Wildcat
4. Location of Well, Footage, Sec. Sec. 29, T-20-N, R-9-W, NMPM, Unit F, 1349' FNL and 2555' FW	McKinley County		10.	Elevation:
Type of Submission	Type of Action	· · · · · · · · · · · · · · · · · · ·		
X Notice of Intent	X Abandonment Recompletion	Change of New Const		
Subsequent Report	Plugging Back Casing Repair	Non-Routir Water Shu	e Fra	
Final Abandonment	Altering Casing Other -	Conversion	to In	ection
13. Describe Proposed or Complete A-Plus Well Service, contra			cord	ing to the attached
741 105 110H 00H 1100; 00HH	ictor, will plug and aban	don said weil ad		ing to the attached
procedure prepared by NM This work will be in accorda	OCD.			
procedure prepared by NM	OCD.			98-521.25-059.
procedure prepared by NM	OCD.			98-521.25-059.
procedure prepared by NM. This work will be in accorda	OCD. Ance with State of New I	Mexico Contrac	No.	98-521.25-059. DECEIVED JAN 2 2 1998 OIL CON. DIV.
procedure prepared by NM	OCD.		No.	98-521.25-059. DECEIVED JAN 2 2 1998 OIL CON. DIV.
procedure prepared by NM. This work will be in accorda SIGNATURE	OCD. Ance with State of New I	December	30, 1	98-521.25-059. DECEIVED JAN 2 2 1998 OIL CON. DIV.

COMPANY		PROPERTY HAY:		WELL NO.	
(Seo Engineering	Sante	Fe Pacific I	90	
DATE	LOCATION (ULATR)		FOOTAGE		
API NO.	1 F-29-20N				
mer no.	*	100L			
والمروف وجواطنا الأناسات			***************************************		
	9 11	// - //			
	a " pipe wi	th 2 2."		Г	
	tee with a	gaugeint	دو ا		
		0 0			
	· · · · · · · · · · · · · · · · · · ·				
		•			
				•	
	······································	•		•	
					
· · · · · · · · · · · · · · · · · · ·		•		.	
Casing Re	CORD:				
	9"050 @ 500	2 /			
	2"csg.@500 calc. T.O.C.@ 40'	t			
	calc. T.D.C. @ 40'	7 '		·	
·		•			
! 				407'	
		-		(, Calc T.oc	
	-		()	1)(
	• •	•		. [2]	
			 	 };	
	•], (113	
			(')	\{\frac{1}{2}	
			\ \\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	K (
				lίζ	
			1 1	1) /	
			(! !	105xs.	
				W 2"	
			0.H.	509'	
	. ,	•	545		
ı			* 1		

:

DATE LOCATION (ULSTR) Sante Fe Pacific I 20 FOOTAGE F-29-20N-09W	COMPANY	C -	PROPERTY HAME			UPI I NO
ASINO RECORD: 2" csq. @ 50q! calc. T.O.C. @ 407' 1. Determine depth of well 2. If depth is 300' or more continue with procedure. If not clean out csq. to 3. Coil aso(+30') 3. Cill with slickline + lead csq. with A AH with slickline + pump down csq d cinc. cement to the surg 1. Install Dryhole marker	(reo Engineering			I	20
ASING RECORD: 2" csg. @ 509' calc. T.O.C. @ 407' 1. Determine depth of well 2. If depth is 300' or more continue with procedure. If not clean out csg. to 3. Coll with Slickline + load csg. with Cement A. A. H with Slickline + pump down csg 4 cinc.cement to the sung Tinstall Dryhole marken	DATE	LOCATION (ULSTR)	- 0.00	FOOTAGE		
ASING RECORD: 2"csg. @ 509! Calc. T.O.C. @ 407! 1. Determine depth of well 2. If depth is 300 or more continue with procedure. It not clean out csg. to 3.00; @ 300'+30' 3. Coff with Slick line + load csg. with Cement 4. AoH with Slick line + pump down csg 4 circ, cement to the surf 5. Install Dryhole marken	API NO.			<u> </u>		
ASING RECORD: 2"csg. @ 509! Calc. T.O.C. @ 407! 1. Determine depth of well 2. If depth is 300 or more continue with procedure. It not clean out csg. to 3.00; @ 300'+30' 3. Coff with Slick line + load csg. with Cement 4. AoH with Slick line + pump down csg 4 circ, cement to the surf 5. Install Dryhole marken			والمستوارة في المستوارة والمستوارة	***************************************		·
ASING RECORD: 2"csg. @ 509! Calc. T.O.C. @ 407! 1. Determine depth of well 2. If depth is 300 or more continue with procedure. It not clean out csg. to 3.00; @ 300'+30' 3. Coff with Slick line + load csg. with Cement 4. AoH with Slick line + pump down csg 4 circ, cement to the surf 5. Install Dryhole marken	* ************************************					And the second s
ASING RECORD: 2"csg. @ 509! Calc. T.O.C. @ 407! 1. Determine depth of well 2. If depth is 300 or more continue with procedure. It not clean out csg. to 3.00; @ 300'+30' 3. Coff with Slick line + load csg. with Cement 4. AoH with Slick line + pump down csg 4 circ, cement to the surf 5. Install Dryhole marken		2 " PIPE WI	th 22"		7	P
ASING RECORD: 2"C5g. @ 50q' calc. T.O.C. @ 407' 1. Determine depth of well 2. If depth is 300' or more continue with procedure. If not clean out csg. to 3. 200' 2300' + 30' 3. Giff with Slickline + lead csg. with cement 4. AoH with Slickline + pump down csg 4 circ. cement to the sung 5. Install Dryhole marken	·	tee with a	gauge in t	و		
2" C5g. @ 509! Calc. T.O.C. @ 407' 1. Determine depth of well 2. If depth is 300' or more continue with procedure. If not clean out c5g. to 3. Oct. @ 300' + 30' 3. Gill with Slickline + load c5g. with Cement 4. AoH with slickline + pump down c5g 4 circ. cement to the sung 5. Install Dryhole marken 0. H.			<u> </u>			
2" C5g. @ 509! Calc. T.O.C. @ 407' 1. Determine depth of well 2. If depth is 300' or more continue with procedure. If not clean out c5g. to 3. Oct. @ 300' + 30' 3. Gill with Slickline + load c5g. with Cement 4. AoH with slickline + pump down c5g 4 circ. cement to the sung 5. Install Dryhole marken 0. H.						
2" C5g. @ 509! Calc. T.O.C. @ 407' 1. Determine depth of well 2. If depth is 300' or more continue with procedure. If not clean out c5g. to 3. Oct. @ 300' + 30' 3. Gill with Slickline + load c5g. with Cement 4. AoH with slickline + pump down c5g 4 circ. cement to the sung 5. Install Dryhole marken 0. H.	*****		-			
2" C5g. @ 509! Calc. T.O.C. @ 407' 1. Determine depth of well 2. If depth is 300' or more continue with procedure. If not clean out c5g. to 3. Oct. @ 300' + 30' 3. Gill with Slickline + load c5g. with Cement 4. AoH with slickline + pump down c5g 4 circ. cement to the sung 5. Install Dryhole marken 0. H.						
2" C5g. @ 509! Calc. T.O.C. @ 407' 1. Determine depth of well 2. If depth is 300' or more continue with procedure. If not clean out c5g. to 3. Oct. @ 300' + 30' 3. Gill with Slickline + load c5g. with Cement 4. AoH with slickline + pump down c5g 4 circ. cement to the sung 5. Install Dryhole marken 0. H.			·			
2" C5g. @ 509! Calc. T.O.C. @ 407' 1. Determine depth of well 2. If depth is 300' or more continue with procedure. If not clean out c5g. to 3. Oct. @ 300' + 30' 3. Gill with Slickline + load c5g. with Cement 4. AoH with slickline + pump down c5g 4 circ. cement to the sung 5. Install Dryhole marken 0. H.			•			
2" C5g. @ 509! Calc. T.O.C. @ 407' 1. Determine depth of well 2. If depth is 300' or more continue with procedure. If not clean out c5g. to 3. Oct. @ 300' + 30' 3. Gill with Slickline + load c5g. with Cement 4. AoH with slickline + pump down c5g 4 circ. cement to the sung 5. Install Dryhole marken 0. H.					ŀ	
2" C5g. @ 509! Calc. T.O.C. @ 407' 1. Determine depth of well 2. If depth is 300' or more continue with procedure. If not clean out c5g. to 3. Oct. @ 300' + 30' 3. Gill with Slickline + load c5g. with Cement 4. AoH with slickline + pump down c5g 4 circ. cement to the sung 5. Install Dryhole marken 0. H.						
2" C5g. @ 509! Calc. T.O.C. @ 407' 1. Determine depth of well 2. If depth is 300' or more continue with procedure. If not clean out c5g. to 3. Oct. @ 300' + 30' 3. Gill with Slickline + load c5g. with Cement 4. AoH with slickline + pump down c5g 4 circ. cement to the sung 5. Install Dryhole marken 0. H.						
2" C5g. @ 509! Calc. T.O.C. @ 407' 1. Determine depth of well 2. If depth is 300' or more continue with procedure. If not clean out c5g. to 3. Oct. @ 300' + 30' 3. Gill with Slickline + load c5g. with Cement 4. AoH with slickline + pump down c5g 4 circ. cement to the sung 5. Install Dryhole marken 0. H.	·	M ** - 1 ** ** ** ** ** * * * * * * * * *				
1. Determine depth of well 2. If depth is 300' or more continue with procedure. It not clean out csq. to 3. Colf. D 300' + 30' 3. Giff with Slickline + load csq. with Cement 4. AoH with slickline + pump down csq 4 circ, cement to the sunf 5. Install Dryhole marken 0. H.	CASING RE	CORD:	· · · · · · · · · · · · · · · · · · ·			
1. Determine depth of well 2. If depth is 300' or more continue with procedure. It not clean out csq. to 3. Colf. D 300' + 30' 3. Giff with Slickline + load csq. with Cement 4. AoH with slickline + pump down csq 4 circ, cement to the sunf 5. Install Dryhole marken 0. H.		9"000 @ 500	, /			
1. Determine depth of well 2. If depth is 300' or more continue with procedure. It not clean out csq. to 3. Colf. D 300' + 30' 3. Giff with Slickline + load csq. with Cement 4. AoH with slickline + pump down csq 4 circ, cement to the sunf 5. Install Dryhole marken 0. H.		4 65g. @ 309				
2. If death is 300' or more continue with procedure. It not clean out csq. to 3. Acrt. 2300' + 30' 3. Gilt with Slickline + load csq. with Cement 4. AoH with shekline + pump down csq 4 circ, cement to the surf 5. Install Dryhole marken 0.4.		calc. T.D.C. @ 40'	7 '			
2. If death is 300' or more continue with procedure. It not clean out csq. to 3. Acrt. 2300' + 30' 3. Gilt with Slickline + load csq. with Cement 4. AoH with shekline + pump down csq 4 circ, cement to the surf 5. Install Dryhole marken 0.4.	1 Dat	2434444 4 13 0				
3. Perf.@300'+30' 3. Bill with Slickline + load csg. with cement 4. AoH with slickline + pump down csg d cinc, cement to the sunf 5. Install Dryhole marken 105xs. 2" 500') Te	crmine depth of well				1/2-1
3. Perf.@300'+30' 3. Bill with Slickline + load csg. with cement 4. AoH with slickline + pump down csg d cinc, cement to the sunf 5. Install Dryhole marken 105xs. 2" 500'	∀. 4+4	leth is 300 or more	continue wil	-h		
GIH with Slickline + load csg. with Cement A. AoH with slickline + pump down csg 4 circ, cement to the sung Tristall Dryhole marken O.H. O.H.	I -	- until not class	A 1		()	1)(
F. Fostall Dryhole marken 1. AoH with slickline + pump down esg 4 cinc, cement to the sung 1. Install Dryhole marken	3. Aeri	f.@300'+30'				. [{}
F. Fostall Dryhole marken 1. AoH with slickline + pump down esg 4 cinc, cement to the sung 1. Install Dryhole marken	ce	ment	sad csg. with			} <u>{</u>
F. Install Dryhole marken 105xs.	A . AON	Landa et la			70	(')
F. Install Dryhole marken 105xs.	4 01	re come of the pu	mp down esq		\ <u> </u>	1)'i
0.H. 105xs.	& Inc	Lall a	inf			<u> </u> }}
0.H. 105xs.	, ,	rall pryhole marken		8	18	}
0.H. { 500,					(
				, i	14	1/2"
				48	}	509'
				7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7	'-	