

State of New Mexico
Energy, Minerals and Natural Resources Department
Oil Conservation Division

Sundry Notices and Reports on Wells

1. Type of Well OIL	API # (assigned by OCD) 30-03-2534 5. Lease Number Fee 6. State Oil & Gas Lease #
2. Name of Operator Geo Engineering	7. Lease Name/Unit Name Santa Fe Pacific I
3. Address & Phone No. of Operator P.O.Box 2966 Santa Fe, NM 87505	8. Well No. #5
4. Location of Well, Footage, Sec., T, R, M Sec. 29 T-20-N, R-9-W, NMPM, McKinley County Unit B, 615' FNL and 1920' FEL	9. Pool Name or Wildcat 10. Elevation:

Type of Submission	Type of Action	
<input type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input checked="" type="checkbox"/> Subsequent Report	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut off
<input type="checkbox"/> Final Abandonment	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Other -	

13. Describe Proposed or Completed Operations

A-Plus Well Service, contractor, plugged and abandoned said well according to the attached Daily Report.

This work was completed under State of New Mexico Contract No. 98-521.25-059.

RECEIVED
MAR 13 1998

OIL CON. DIV.
DIST. 3

SIGNATURE William F. Clark Contractor
William F. Clark

March 4, 1998

(This space for State Use)
Approved by Johnny Robinson DEPUTY OIL & GAS INSPECTOR, DIST. 3 Title _____ Date MAR 13 1998

Daily Report

A - PLUS WELL SERVICE

P.O. BOX 1979 • FARMINGTON, NM 87499
505-325-2627 • FAX (505) 325-1211

Rig No 6-7

Date 2/23/98

Well No Santa Fe Pacific I[#] 5 Location 29-20N R9W Company Geo Engineering

FROM	TO	DESCRIPTION OF OPERATION
2/23/98		
2pm		Move to Well dig out well w/ Ron Backhoe Found 2" Well Bore Had. cement around 2" csg down to 6' AS Fore AS w dug. chip of cement down Approx 3:30pm 1' Below Top of 2" to good 2" pipe Then weld on 2" collar
3:30	4pm	Run WL to 465' Pump down csg at 1BPM at 300PSI Pump SBBL. (Pump down cement Job.)
4pm		Plug #1 mix 25 SX Pump down 2" csg. at 1BPM at 400PSI Shut Well in No Disp. Washup PT Install Marker
5:30pm		move Cement Equipment to SFPI 21

Fuel & Motor Oil _____ Water Hauled _____

Rental Equipment _____ Cement Retainers _____

Cementing Plug 25 SX

Wireline (Nordest) Run in Hole to 465'