

State of New Mexico
Energy, Minerals and Natural Resources Department
Oil Conservation Division

Sundry Notices and Reports on Wells

1. **Type of Well**
OIL

2. **Name of Operator**
Geo Engineering

3. **Address & Phone No. of Operator**
P. O. Box 2966
Santa Fe, NM 87505

4. **Location of Well, Footage, Sec., T, R, M**
Sec. 20 T-20-N, R-9-W, NMPM, McKinley County
Unit P, 450' FSL and 1145' FEL

API # (assigned by OCD)

-031-05396

5. **Lease Number**
Fee

6. **State Oil & Gas Lease #**

7. **Lease Name/Unit Name**
Santa Fe Pacific

8. **Well No.**
#24

9. **Pool Name or Wildcat**

10. **Elevation:**

Type of Submission

☐ Notice of Intent

☒ Subsequent Report

☐ Final Abandonment

Type of Action

☐ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other -

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut off

☐ Conversion to Injection

13. Describe Proposed or Completed Operations

A-Plus Well Service, contractor, plugged and abandoned said well according to the attached Daily Report on February 11, 1998.

This work was completed under State of New Mexico Contract No. 98-521.25-059.

SIGNATURE William F. Clark Contractor
William F. Clark

February 12, 1998

(This space for State Use)

Approved by Johnny Robinson

DEPUTY OIL & GAS INSPECTOR, DIST. #3
Title

Date FEB 17 1998

Daily Report

A - PLUS WELL SERVICE

13976

P.O. BOX 1979 • FARMINGTON, NM 87499

505-325-2627 • FAX (505) 325-1211

Rig No 7

Date

2/6/98 - 2/11/98Well No SANTAFE Pkwy #24 Location Red Mtn Company Geo Eng

FROM	TO	DESCRIPTION OF OPERATION
<u>2-6-98</u>		
<u>10:00</u>	<u>10:30</u>	<u>Run WL in to 409 + tag</u>
<u>2/10/98</u>		
<u>9am</u>	<u>9:30am</u>	<u>move to Well setup PT105 Tie in to 2" csg.</u>
		<u>+ Pump down csg w/ 5 BBL. at 1 BPM at 200 PSI</u>
<u>9:30</u>	<u>10am</u>	<u>Plug #1 mix 13 sx cement + Displace to 300' shut well in</u>
		<u>w/ 200 PSI WDC move to SFP #42</u>
<u>11am</u>	<u>11:30</u>	<u>Rig up WL + Run in Hole to 308' tag cement</u>
		<u>Then Perf 2-1 1/16 Bywire shot at 300'</u>
<u>11:30</u>		<u>Pump down 2" csg w/ 5 BBL get circulation Behind</u>
		<u>2" csg. Plug #2 mix 25 sx + Pump down 2" csg get</u>
		<u>1/2 BBL good cement Returns to Surface shut well in</u>
	<u>12 Noon</u>	<u>Wash up + move off. to SFP 42</u>
<u>2/11/98</u>		
<u>12 Noon</u>	<u>1pm</u>	<u>make marker + Install</u>

Fuel & Motor Oil _____ Water Hauled _____

Rental Equipment _____ Cement Retainers _____

Cementing Plug #1 13 sx Plug #2 25 sxWireline 2-1 1/16 Perf at 300'