

State of New Mexico
Energy, Minerals and Natural Resources Department
Oil Conservation Division

Sundry Notices and Reports on Wells

<p>1. Type of Well OIL</p> <hr/> <p>2. Name of Operator Geo Engineering</p> <hr/> <p>3. Address & Phone No. of Operator P.O.Box 2966 Santa Fe, NM 87505</p> <hr/> <p>4. Location of Well, Footage, Sec., T, R, M Sec. 20 T-20-N, R-9-W, NMPM, McKinley County Unit O, 490' FSL and 2300' FEL</p>	<p>API # (assigned by OCD) 30-031-05400</p> <p>5. Lease Number Fee</p> <p>6. State Oil & Gas Lease #</p> <p>7. Lease Name/Unit Name Santa Fe Pacific</p> <p>8. Well No. #23</p> <p>9. Pool Name or Wildcat</p> <p>10. Elevation:</p>
--	---

Type of Submission

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment

Type of Action


<input checked="" type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut off
<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
<input type="checkbox"/> Other -	

13. Describe Proposed or Completed Operations

A-Plus Well Service, contractor, will plug and abandon said well according to the attached procedure prepared by NMOCD.
This work will be in accordance with State of New Mexico Contract No. 98-521.25-059.

SIGNATURE William F. Clark Contractor

December 30, 1997



(This space for State Use)

Approved by Jimmy Robinson Title _____

Date JAN 2 1998

COMPANY Geo Engineering		PROPERTY NAME Santa Fe Pacific		WELL NO. 23
DATE	LOCATION (ULSTM) 0-20-20N-09W		FOOTAGE	
API NO.		POOL		

2" Line Pipe with a collar
+ 2" ball valve. 2 feet
above ground level

CASING RECORD:

2" Line Pipe @ 440'

calc T.O.C. @ 365'

1. Determine depth
2. If depth is 300' or more continue with procedure if not move rig in + clean out csg. to 440'
3. Per @ 300' + 30'. establish circ. to the surf.
4. GIH with slick line + load hole with cement.
5. POH with slick line + pump cement down the csg. + circ. cement to the surf.
6. Install dry hole marker