

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <u>Dry Hole</u>		7. Unit Agreement Name
2. Name of Operator <u>Tesoro Petroleum Corporation</u>		8. Farm or Lease Name <u>Santa Fe R.R.</u>
3. Address of Operator <u>8520 Crownhill Boulevard, San Antonio, Texas 78209</u>		9. Well No. <u>57</u>
4. Location of Well UNIT LETTER <u>J</u> <u>2330</u> FEET FROM THE <u>East</u> LINE AND <u>1620</u> FEET FROM THE <u>South</u> LINE, SECTION <u>1</u> TOWNSHIP <u>17N</u> RANGE <u>9W</u> NMPM.		10. Field and Pool, or Wildcat <u>Undesignated</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>6952' GL 6960' RKB</u>		12. County <u>McKinley</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1-22-70: Set 15-sack cement plug from 1644' to 1513' GL. Cut 5-1/2" 15.5# casing at 822' GL and recovered 26 joints. Set 30-sack cement plug 58' inside 5-1/2" and 80' down into 7-7/8" hole. Total plug 138' from 883' to 745' GL.

1-27-70: Set 10-sack plug in top of 8-5/8" surface pipe and installed marker.

Cleaned and leveled location with bulldozer.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>A. H. Herman</u>	TITLE <u>Petroleum Engineer</u>	DATE <u>June 26, 1970</u>
APPROVED BY <u>Emory Elmer</u>	TITLE <u>SUPERVISOR DIST. #3</u>	DATE <u>JUL 1 1970</u>
CONDITIONS OF APPROVAL, IF ANY:		