
Submit 3 Copies To Appropriate District	State of New Mexico				Form C-10	
Office District 1	Energy, Minerals and Natural Resources			Revised March 25, 1999 WELL API NO.		
1625 N. French Dr., Hobbs, NM 88240	<u>Ail</u> a			30-031-20375		
District II 811 South First, Artesia, NM 87210	OIL CONSERVATION DIVISION			5. Indicate Type of Lease		
District III	1220 South St. Francis Dr			STATE X FEE		
1000 Rio Brazos Rd., Aztec, NM 87410 Santa Fe, NM 87505			6. State Oil & Gas Lease No.			
1220 S. St. Francis Dr., Santa Fe, NM 87505			STATE			
SUNDRY NOTICES AND REPORTS ON WELLS  (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)				7. Lease Name or Unit Agreement Name:		
1. Type of Well: Oil Well X Gas Well Other				ENDY		
2. Name of Operator ENERDYNE LLC				8. Well No. 58		
3. Address of Operator P.O. BOX 502, ALBUQ., NM 87103				9. Pool name or Wildcat BLACKEYE, MESAVERDE		
4. Well Location						
Unit Letter D :	726feet from the	FNL	line and	863 feet from		
Section 32	Township 20	N Ra	nge 9W	NMPM	County McKINL	EY
10. Elevation (Show whether DR, RKB, RT, GR, etc.) 6499 GR.						
11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data  NOTICE OF INTENTION TO:  SUBSEQUENT REPORT OF:						
NOTICE OF IN PERFORM REMEDIAL WORK □	TENTION TO: PLUG AND ABANDON	<b>(3</b> )	SUB REMEDIAL WOR		ALTERING CASING	
TEMPORARILY ABANDON	CHANGE PLANS		COMMENCE DR	ILLING OPNS.	PLUG AND ABANDONMENT	
PULL OR ALTER CASING	MULTIPLE COMPLETION		CASING TEST A	ND		
OTHER:			OTHER:			
<ol> <li>Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.</li> </ol>						
Work to be completed by 6-1-02						
Casing: 4 1/2", 9.6 # / ft., set to 1038'. Cement 80 sks. (94 cu. ft.). Estimated cement top 425 GR.						
Open hale completion 1038' - 1050'.						
Proposed Plugging Procedure: Pull rods & pump out of hole. Tag 1D with tubing and circulate note.						
Snot 65' cement plug with 6 sks. class B neat cement ( / cu. it. ), top						
of plug @ 985'. Pull 4 jts. of tubing and wait on cement. After 4 hours,						
tag cement top to varify location. Upon completion of bottom plug,						
pull tubing out of hole, perforate casing @ 425', install 4" x 2"						
swedge, circulate water to surface outside of casing thru perfs and follow by circulating 55 sks. of class B neat cement (64 cu. ft.) to						
surface. Fill hole with mud-laden fluid and displace top 100' with						
8 sks. of class B neat cement. Install dry hole marker and clean location.						
	/ · · · · · · · · · · · · · · · · · · ·					
I hereby certify that the information above is true and complete to the best of my knowledge and belief.						
SIGNATURE	<u> </u>	_TITLE_	MEMBER		DATE <u>5-9-02</u>	
Type or print name DON	L. HANOSH, ENE	ERDYN	E LLC	Tele	phone No. 332-780	07
(This space for Same and Same						
APPPROVED BY		_TITLE_			DATENT 1 J	2002

## **WELL DATA**

SPUD 8-15-73 HOLE 6 3/4" CASING 4 1/2", 9.6# / FT. CEMENT 80 SKS.



Circulate 55 sks. ( 64 cu. ft. ) class B neat cement thru perforations to surface

☐ Perforations @ 425'

D

Mud-laden fluid

65' bottom plug, top @ 985' or 50' above open hole 6 sks. ( 7 cu. ft. ) class B neat cement

Open hole 1038'-1050'

TD 1050'

ENDY 58 30-031-20375 D-32-20N-9W BLACKEYE MESAVERDE