

NO. OF COPIES RECEIVED	6
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	2
LAND OFFICE	1
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
NM 662	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - A" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry hole		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
Tesoro Petroleum Corporation		Hospah Sand Unit
3. Address of Operator		9. Well No.
1776 Lincoln St., Suite 1012, Denver, Colorado 80203		86
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER G, 2310 FEET FROM THE North LINE AND 1650 FEET FROM East LINE, SECTION 36 TOWNSHIP 18N RANGE 9W NMPM.		Hospah
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
GL 7144; KB 7155		McKinley

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

This well drilled to the Dakota 'D' zone was incapable of producing at a commercial oil or gas rate from either the Dakota 'D' or the Upper Hospah.

Tesoro Proposes to plug and abandon this well according to the following procedure:

1. Spot a 25 sk plug (130') over the U. Hospah perms. (1816-20')
2. Cut off the 5½" oil string at approx. 1000'.
3. Set a 200' cement plug over the 5½" csg. cut off (100' inside the 5½" and 100' in the OH section above).
4. Set a 100' cement plug over the 8 5/8" surface casing shoe at 146' (50' inside the 8 5/8" and 50' in the OH section below).
5. Spot a 10' cement plug inside the 8 5/8" at the surface, install proper well head marker back fill pits, level and clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>L. C. V. Hargrett</u>	TITLE <u>District Engineer</u>	DATE <u>9/17/74</u>
APPROVED BY <u>Ernest [Signature]</u>	TITLE <u>SUPERVISOR DIST. #3</u>	DATE <u>9.20.74</u>
CONDITIONS OF APPROVAL, IF ANY:		