

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well ☒ gas well ☐ other ☐

2. NAME OF OPERATOR
Tenneco Oil Company

3. ADDRESS OF OPERATOR
P.O. Box 3249, Englewood, CO 80155

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 1360' FNL, 900' FEL
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☒
REPAIR WELL ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☐
ABANDON* ☐
(other) ☐

SUBSEQUENT REPORT OF:

☐
☐
☐
☐
☐
☐
☐
☐
☐
☐

RECEIVED
(NOTE: Report results of multiple completion or zone change on Form 9-330.)
SEP 15 1983 SEP 19 1983
OIL CON. DIV.
DIST. 3

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Tenneco respectfully requests permission to acidize during the operations shown on the attached detailed procedure.

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED John Doe TITLE Production Analyst DATE 9/12/83


(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

NMOCC

R. B. Brum
Asst. Dir.
R. H. Lewis



LEASE South Hospah

WELL NO. 64

9 5/8 "OD, 36 LB, CSG.W/ 89 SX

TOC @ _____

7 "OD, 23 LB, CSG.W/ 375 SX

TOC @ _____

_____ "OD, _____ LB, _____ CSG.W/ _____ SX

TOC @ _____

RECEIVED
SEP 19 1983

OIL CON. DIV.
DIST. 3

DETAILED PROCEDURE:

1. MIRUSU
2. TOOH w/ submersible pump and electrical cable.
3. Tally in hole w/ Model "E" circulating washer and 2 7/8" tbg. Tag bottom.
4. PT swab cups in Model "E" in blank pipe
5. Pull up into bottom perfs (1605')
6. Selectively acidize in 3 feet increments a total of 15' of perfs w. 630 gallons acid.
7. PT swab cups in blank pipe
8. TOOH w/ tbg and Model "E" circulating washer.
9. RIH w/ seating Nipple (SN) and 2-7/8" open ended tbg to 1590' KB. Swab back load.
10. TOOH w/ SN and 2-7/8" tbg.
11. RIH w/new submersible pump, electrical cable and 2-7/8" tbg to 1580' KB.
12. P.O.P.