Submit 3 Copies

to Appropriate

## State of New Mexico

Form C-103 Revised 1-1-89

FEE

District Office

**DISTRICT 1** P.O. Box 1980, Hobbs, NM 88240

DISTRICT II

P.O. Drawer DD, Artesia, NM 88210

DISTRICT III

1000 Rio Brazos Rd Azteo NM 97410

## Energy, Minerals and Natural Resources Department

OIL CONSERVATION DIVISION	
P.O. Box 2088	WELL API NO.
Santa Fe, New Mexico 87504-2088	30-031-20629
	5. Indicate Type of Lease

STATE

SUBSEQUENT REPORT OF:

1000 Kio Brazos Rd., Azte	ec, NM 87410						7079	3/	34	t Gas Lease No. -9725			
	FORM FOR	I KESEKVUIK.	O DRILL OR T	O DEEPEN TION FOR	OR PLUG B	10	N - 9 19	bi	7. Lease Nan	ne or Unit Agreeme		ILROAD	
1. Type of Well OIL WELL X		GAS WELL		ОТНЕ	₹:	elle	GODI GODI	3	-				
2. Name of Operator ROBE	RT L. BA	YLESS				(0)6-	Bus		8. Well No. 32				
3 Address of Operator								-+	9. Pool name	or Wildcat			
	OX 168	FARMING	TON, NM 8	37499			a. *			UEL CREEK	K-GALLI	J <b>P</b>	
4. Well Location			_		*								
Unit Letter	В	990	Feet from the	NC	RTH	Line and	10	650	Feet fro	m The	EAST		Line
Section	29	_	Township	16N	Range		6W_		∨MРМ	McKINLE	Y	County	
				evation	6419	' GR	RKB, RT, GR	ĺ				16	
11.	Che	eck Approp	riate Box	to Indica	ate Natu	re of No	otice, Rep	ort,	or Other	r Data			
NOTI	CE OF	INTENTIO	ON TO:							REPORT	OF ·		

PERFORM REMEDIAL WORK	PLUG AND ABANDON	X	REMEDIAL WORK		ALTERING CASING	
TEMPORARILY ABANDON	CHANGE PLANS		COMMENCE DRILLING OPNS.	$\overline{\Box}$	PLUG AND ABANDONMENT	Ħ
PULL OR ALTER CASING			CASING TEST AND CEMENT JOB			
OTHER:			OTHER:			

12. Describe Proposed or Completed Operations work) SEE RULE 1103.

(Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed

Robert L. Bayless intends to plug and abandon this well in 1999.

I hearby certify that the information above is true and complete to the best of my knowledge and belief.									
SIGNATURE Town M. M. J.	TITLE	ENGINEER	DATE	5/10/99					
TYPE OR PRINT NAME Tom McCarthy			TELEPHONE NO.	(505) 327-2659					
(This space for State OFIGINAL SIGNED BY CHARLE T. PERSON		DEPUTY OIL & GAS INSPECTO	R, DIST. #3	0 1000					
APPROVED BY	TITLE		DATE	JUN 9 1999					
CONDITIONS OF APPROVAL, IF ANY: HIGHER AZTEC OCD IN TIME TO WITNESS	<del></del>								

## Robert L. Bayless Plug and Abandon Procedure

SFPRR No. 32 990' FNL & 1650' FEL, Section 29, T16N, R6W McKinley County, NM

Well Data:

Surface Casing: None.

Production Casing: 4.5" 11# casing set at 742'. Cemented with 160 sx in 7 7/8" hole.

TD: 772' PBD: 772'

Perfs: 742-772' open hole Tubing: 2 3/8" 712'. Rods: Unknown size 712'.

- 1. Install rig anchors if necessary. Dig small workover pit if necessary.
- 2. Move in rig.
- 3. If well has rods, unseat pump and move rods to see if they are free. Reseat pump and pressure test tubing to 1000 PSI. Trip out laying down rods and pump.
- 4. Pick up extra tubing and tag PBD. Trip out and tally tubing. Inspect tubing. Pick up work string if necessary.
- 5. Trip in with tubing open ended. Tag PBD and raise tubing 2'. Circulate casing clean. Spot balanced **Cement Plug No. 1** (see volume below) down tubing. Trip out above cement and WOC. Trip in and tag cement. Spot additional plug if necessary.
- 6. Trip out with tubing.
- 7. Rig up wireline. Perforate 3 squeeze holes at 100'. Attempt to establish circulation out the bradenhead (if there is one) or outside the production string to the surface. Mix cement for **Cement Plug No. 2** (see volume below) and pump down casing, attempting to circulate to surface. Shut in and WOC.
- 8. Cut off casing. Fill casings with cement if necessary. Install P & A marker. Rig down and move off.

Cement Plug No. 1: 29 sx. Cement Plug No. 2: 45 sx.

Notes: All cement will be Class B Neat.

Other than the cement, the well bore fluid will be 8.3 PPG water.

All cement volumes will be 100% excess outside casing and 50' excess inside casing.