

State of New Mexico
Energy, Minerals and Natural Resources Department
Oil Conservation Division

Sundry Notices and Reports on Wells

1. **Type of Well**
Oil

2. **Name of Operator**
Robert L. Bayless

3. **Address & Phone No. of Operator**
PO Box 168, Farmington, NM 87499 (505)327-2659

4. **Location of Well, Footage, Sec., T, R, M**
Unit B, 330' FNL and 1650' FEL
Section 29, T-16-N, R-6-W, NMPM, McKinley County

5. **API # (assigned by OCD)**
30-031-20633

6. **Lease Number**
Fee

7. **State Oil&Gas Lease #**
Lease Name/Unit Name
Santa Fe Pacific RR

8. **Well No.**
#36

9. **Pool Name or Wildcat**
Miguel Creek Gallup

10. **Elevation:**

RECEIVED
AUG 10 1999
OIL CON. DIV.
DIST. 3

Type of Submission

☐ Notice of Intent
☒ Subsequent Report
☐ Final Abandonment

Type of Action

☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other -

☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut off
☐ Conversion to Injection

13. Describe Proposed or Completed Operations

Robert L Bayless plugged and abandoned this well on July 20, 1999.

7-19-99 Rain washed out wash. Wait for backhoe to repair. Chain up all equipment. MO<RU. Load tubing with 1/2 bbl water and PT to 500#, held OK. Unseat pump. LD 10 5/8" and 18 3/4" rods and pump. ND wellhead and NU BOP, test. TOH with 23 joints 2-3/8" tubing with 1 12' mule shoe, total 721'. TIH with tubing and tag bottom at 752'. Load and circulate hole clean with 4 bbls water. Plug #1 with 27 sxs Class B cement with 2% CaCl₂ from 752' to 429'. TOH with tubing and WOC. TIH and tag cement at 463', PUH to 156'. Load hole and establish circulation with 1/2 bbl water. Attempt to PT casing, leak 2 bpm at 0#. Plug #2 with 48 sxs Class B cement from 156', lost circulation out 4-1/2" casing and established circulation out 4-1/2" casing, did not circulate cement to surface. Ran out of cement. LD tubing. Dig out 2' around wellhead, all cement. Shut in well and WOC overnight.

7-20-99 Safety Meeting. With tubing tag cement at 89'. LD tubing. Load casing and establish circulation around 4-1/2" with 2 bbls water. Perforate 2 squeeze holes at 86'. Plug #2b with 36 sxs Class B cement from 86' to surface with good cement out 4-1/2" casing. Shut in well and WOC. PU 1 joint tubing and tag cement at 5', LD tubing. ND BOP and cut off 4-1/2" casing. Mix 8 sxs Class B cement, top off 4-1/2" casing and install P&A marker. H. Villanueva, NMOCD, was on location.

SIGNATURE Tom McCarthy Engineer August 5, 1999

(This space is for State Use)

Approved by E. Villanueva Title DEPUTY OIL & GAS INSPECTOR, DIST. 3

AUG 10 1999