Submit 3 Copies to Appropriate	State of New Mexico Energy, Minerals and Natural Resources Department			Form C-103 Revised 1-1-89
District Office  DISTRICT I P.O. Box 1980, Hobbs, NM 88240	OIL CONSERVATION P.O. Box 2088	WELL API NO.		
DISTRICT II P.O. Drawer DD, Artesia, NM 88210	Santa Fe, New Mexico 87	30-031-20704 5. Indicate Type of Lease		
DISTRICT III			STATE	FEE X
1000 Rio Brazos Rd., Aztec, NM 87410			6. State Oil & Gas Lease No.	
SUNDRY	Y NOTICES AND REPORTS ON WELLS	n mark to the	0-9725	
	PROPOSALS TO DRILL OR TO DEEPEN OR PLUG	BACK TO A	7. Lease Name or Unit Agreer	nent Name
DIFFERENT	RESERVOIR. USE "APPLICATION FOR PERMIT"	1999 O 1 NUL	t .	OTTION AND AND
1. Type of Well	(FORM C-101) FOR SUCH PROPOSALS.)	an doll li	£ (*)( )( )	CIFIC RAILROAD
OIL X	GAS WELL OTHER:	OUR COM.		
2. Name of Operator  ROBERT L. BA	YLESS	DIENO S	8. Well No. 55	
3. Address of Operator			9. Pool name or Wildcat	· · · · · · · · · · · · · · · · · · ·
P.O. BOX 168 4. Well Location	FARMINGTON, NM 87499		MIGUEL CRE	EK-GALLUP
Unit Letter K	: 1650 Feet from the SOUTH	Line and 2310	Feet from The	WEST Line
Section 21	Township 16N Ra	nge 6W	NMPM McKINL	EV a
Section 21		whether DF, RKB, RT, GR, etc.,		EY County
Ch		94' GL	04 5	
	eck Appropriate Box to Indicate Na INTENTION TO:		or Other Data QUENT REPORT	Γ OF ·
PERFORM REMEDIAL WORK	PLUG AND ABANDON X	REMEDIAL WORK		g casing
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRILLING OPNS	S. PLUG AN	ID ABANDONMENT
PULL OR ALTER CASING		CASING TEST AND CEMENT	r JOB	
OTHER:		OTHER:		
12. Describe Proposed or Complete	ed Operations (Clearly state all pertinent de	tails, and give pertinent dates, inc	luding estimated date of st	arting any proposed
work) SEE RULE 1103.				
Robert L. Bayless intends to plug and abandon this well in 1999.				
	, 1			
<del></del>				
I hearby certify that the information about	is true and complete to the best of my knowledge and belief.			
SIGNATURE DW V	TITLE	ENGINEER	DATE	6/9/99
TYPE OR PRINT NAME	Tom McCarthy		TELEPHONE NO.	(505) 327-2659
(This space for State Use)		DEPUTY OIL & GAS INSPE	, <del></del>	JUN 1 0 1999
	SIGNED BY CHARLIE T. PERFIN TITLE		DATE	0014 1 0 1999
CONDITIONS OF APPROVAL, IF ANY	9			

NOTIFY AZTEC OCD IN TIME TO WITNESS

## Robert L. Bayless Plug and Abandon Procedure

SFPRR No. 55 1650' FSL & 2310' FWL, Section 21, T16N, R6W McKinley County, NM

Well Data:

Surface Casing: None.

Production Casing: 4.5" 9.5# casing set at 798'. Cemented with 125 sx in 7 7/8" hole.

TD: 798'

PBD: Unknown. Perfs: None. Tubing: None. Rods: None.

- 1. Install rig anchors if necessary. Dig small workover pit if necessary.
- 2. Move in rig.
- 3. If well has rods, unseat pump and move rods to see if they are free. Reseat pump and pressure test tubing to 1000 PSI. Trip out laying down rods and pump.
- 4. Pick up tubing work string and tag PBD. Trip out and tally tubing.
- 5. Trip in with tubing open ended to PBD. Circulate casing clean. Spot balanced Cement Plug No. 1 (see volume below) down tubing. Trip out above cement and WOC. Trip in and tag cement. Spot additional plug if necessary.
- 6. Trip out with tubing.
- 7. Rig up wireline. Perforate 3 squeeze holes at 100'. Attempt to establish circulation out the bradenhead (if there is one) or outside the production string to the surface. Mix cement for **Cement Plug No. 2** (see volume below) and pump down casing, attempting to circulate to surface. Shut in and WOC.
- 8. Cut off casing. Fill casings with cement if necessary. Install P & A marker. Rig down and move off.

Cement Plug No. 1: 15 sx. Cement Plug No. 2: 45 sx.

Notes: All cement will be Class B Neat.

Other than the cement, the well bore fluid will be 8.3 PPG water.

All cement volumes will be 100% excess outside casing and 50' excess inside casing.