

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240
DISTRICT II
P.O. Drawer DD, Artesia, NM 88210
DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO.	30-031-20733
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	LH-3667
7. Lease Name or Unit Agreement Name	STATE
8. Well No.	4
9. Pool name or Wildcat	North Miguel Creek Field

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well
OIL WELL GAS WELL OTHER: _____

2. Name of Operator
ROBERT L. BAYLESS

3. Address of Operator
P.O. BOX 168 FARMINGTON, NM 87499

4. Well Location
Unit Letter M : 990 Feet from the SOUTH Line and 990 Feet from The WEST Line
Section 16 Township 16N Range 6W NMPM McKINLEY County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
6564 GL

JUN 2002

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO :	SUBSEQUENT REPORT OF :
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: _____ <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: _____ <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Robert L. Bayless intends to plug and abandon this well by June 1, 2003. The procedure is attached.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Tom McCarthy TITLE ENGINEER DATE 6/6/02

TYPE OR PRINT NAME Tom McCarthy TELEPHONE NO. (505) 327-2659

APPROVED BY ORIGINAL SIGNED BY CHARLIE T. POTTS TITLE DEPUTY OIL & GAS INSPECTOR, DIST. I DATE JUN 10 2002

CONDITIONS OF APPROVAL, IF ANY:

Robert L. Bayless

Plug and Abandon Procedure

State No. 4
990' FSL & 990' FWL, Section 16, T16N, R6W
McKinley County, NM

Well data:

Surface Casing: None.
Production Casing: 5 1/2" 14# casing set at 1226'. Cemented with 150 sxs. Cement circulated to surface.
TD: 1227'
PBD: 1220'
Perfs: 1189-99'.
Tubing: 2 3/8" 1170'.
Rods: 1170'.

1. Install rig anchors if necessary. Dig small workover pit if necessary.
2. Move in rig.
3. If well has rods, unseat pump and move rods to see if they are free. Reseat pump and pressure test tubing to 1000 PSI. Trip out laying down rods and pump.
4. Pick up extra tubing and tag PBD. Trip out and tally tubing. Inspect tubing. Pick up work string if necessary.
5. Trip in with tubing open ended to 1199'. Circulate casing clean. Spot balanced **Cement Plug No. 1** (see volume below) down tubing. Trip out above cement and WOC. Trip in and tag cement. Spot additional plug if necessary.
6. Trip out with tubing to 50'. Mix cement for **Cement Plug No. 2** (see volume below) and pump down tubing. Trip out tubing.
7. Cut off casing. Fill casings with cement if necessary. Install P & A marker. Rig down and move off.

Cement Plug No. 1: 19 sx.

Cement Plug No. 2: 6 sx.

Notes: All cement will be Class B Neat.

Other than the cement, the well bore fluid will be 8.3 PPG water.

All cement volumes will be 100% excess outside casing and 50' excess inside casing.