

X

State of New Mexico  
Energy, Minerals and Natural Resources Department  
Oil Conservation Division

Sundry Notices and Reports on Wells

1. Type of Well OIL	<b>RECEIVED</b> FEB 17 1998	API # (assigned by OCD) 30-031-20766
		5. Lease Number
		6. State Oil & Gas Lease #
2. Name of Operator Geo Engineering	<b>OIL CON. DIV.</b> DIST. 3	7. Lease Name/Unit Name State
3. Address & Phone No. of Operator P. O. Box 2966 Santa Fe, NM 87505.		8. Well No. #26
4. Location of Well, Footage, Sec., T, R, M Sec., 28 T-20-N, R-9-W, NMPM, McKinley County Unit B, 620' FNL & 1965' FEL		9. Pool Name or Wildcat
		10. Elevation:

Type of Submission	Type of Action	
<input type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
<input checked="" type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut off
	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Other -	

13. Describe Proposed or Completed Operations

A-Plus Well Service, contractor, plugged and abandoned said well according to the attached Daily Report on February 11, 1998.

This work was completed under State of New Mexico Contract No. 98-521.25-059.

SIGNATURE William F. Clark Contractor February 12, 1998  
William F. Clark

(This space for State Use)  
Approved by Johnny Robinson DEPUTY OIL & GAS INSPECTOR, DIST. #3 Title          Date FEB 17 1998

Daily Report

A - PLUS WELL SERVICE

13944

P.O. BOX 1979 • FARMINGTON, NM 87499  
505-325-2627 • FAX (505) 325-1211

Rig No 7

Date 2/3/98 - 2/11/98

Well No STATC #26 Location Red MTN Company Geo Eng.

FROM	TO	DESCRIPTION OF OPERATION
2-3-98		
		Run WH to 281 & Tag
2-5-98		
12:30	1:00	move to well spot PT105 Tie into well 4 1/2 csg
		pump down csg w/12 BBLS at 1 1/2 BPM at 400 PSI
1:00	1:30	Plug #1 mix 29 sxs, pump down csg then displace w/4.5 BBLS to 280' shut well in WOC lhr.
1:30	2:30	WOC
2:30	2:40	Open well standing full, pressure up to 500 PSI
2:40	3:00	Perf 2 holes at 280' 2 1/2 by wire shots
3:00	3:15	pump on perf up to 500 PSI holding at 500 PSI
3:15	3:30	Run in hole w/1 1/2 slickline pipe to 280'
3:30	3:45	Plug #2 mix 22 sxs & spot from 280' to surface
3:45	4:00	POOH w/1 1/2" + bg
<del>4:00</del>	4:10	Perf 2 holes at 30'
4:10	4:20	pump down 4 1/2 csg w/2 BBLS at 100 PSI
		out perfs at 30' wouldn't circulate, pump 2 more BBLS at 0 PSI, no circulation behind csg.
4:20	4:40	Plug #3 mix 20 sxs pump down 4 1/2 & out perfs at 30' left csg full (no circulation at surface behind csg.
4:40	5:00	wash PT105 & move off
2/11/98		
	1/2 HR	set markers

Fuel & Motor Oil \_\_\_\_\_ Water Hauled \_\_\_\_\_

Rental Equipment \_\_\_\_\_ Cement Retainers \_\_\_\_\_

Cementing Plug # 1 29 sxs Plug # 2 22 sxs Plug # 3 20 sxs

Wireline ① 280' 2 2 1/2 by-wire