

**GILA EXPLORATION INC
HOGAN STATE #1, B-16-18N-12W**

Downhole Conditions & Equipment

8 5/8" @ 81' w/60 sacks.

7 7/8" hole to 1084'.

5 1/2" 15.5 and 17# casing to 1084'. Cemented to surface w/363 FT3.

4 3/4" rathole to 1219'.

Lyons inflatable bridge plug @ 1160'.


2 3/8" tubing and Lyons inflatable packer @ 1154'.

3/4" sucker rods w/moyno pump above packer.

Division Approved Plugging Program

1. Pull rods and tubing (tubing may be used as work string if OK).
2. Go in hole with tubing to top of bridge plug @ 1160'. Set a cement plug 1160' to 1010' inside 5 1/2" casing.
3. Pull out of hole to 800' and reverse out tubing. Woc 4 hours and tag cement. If plug is in place, go to step 4. If not, fill to 1010'.
4. Pull out of hole to 150' and circulate cement to surface inside 5 1/2" casing.
5. Set marker, fill pits, clean and level location.

STEEL EXPLORATION, INC.
#1 HOGAN STATE WELL SCHEMATIC



3-18-86
 CH