

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-71

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
Name of Operator Gurley Oil Company	8. Farm or Lease Name NMALCO Gurley
Address of Operator P.O. Box 2092, Farmington, New Mexico 87499	9. Well No. 4
Location of Well UNIT LETTER 0, 330 FEET FROM THE South LINE AND 1750 FEET FROM East THE LINE, SECTION 9 TOWNSHIP 20N RANGE 12W NMPM.	10. Field and Pool, or Wildcat Nose Rock, Hospah Ext.
15. Elevation (Show whether DF, RT, GR, etc.) 6129 GR	12. County McKinley

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
ILL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug and abandon well as follows.

1. Displace hole to 10 PPG Gel. from 2233'.
2. Spot cement plug from 2233' to 1972' (261') 23.36 cu.ft. (20)sacks.
3. Spot cement plug from 1030' to 850' (178') 15.93 cu.ft. 14 sacks.
4. Perforate four holes at 250' from surface.
5. Bull head 15.6PPG cement down 4½" casing and circulate back to surface with 78.61 cu.ft. cement (67) sacks.
6. Install dry hole marker, and restore location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

by Mike Maloney TITLE Manager GOC DATE April 20, 1992

Original Signed by CHARLES GIBLSON

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: