

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1 ✓
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		5a. Indicate Type of Lease State <input type="checkbox"/> Federal <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-		5. State Oil & Gas Lease No.
2. Name of Operator El Paso Natural Gas Company		7. Unit Agreement Name
3. Address of Operator Box 990, Farmington, New Mexico - 87401		8. Farm or Lease Name Ingverson Federal B
4. Location of Well UNIT LETTER I 1650 FEET FROM THE South LINE AND 990 FEET FROM THE East LINE, SECTION 21 TOWNSHIP 24N RANGE 2W NMPM.		9. Well No. 1
15. Elevation (Show whether DF, RT, GR, etc.) 7155' GL		10. Field and Pool, or Wildcat So. Blanco P. C.
12. County Rio Arriba		

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF	
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/> OTHER <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/> OIL CON. COM. <input type="checkbox"/> DIST. 3 <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Because of non-production it is planned to plug and abandon this well as follows:

Pick up tubing, spot 30 sack plug on top of bridge plug at 3050'. Determine free point of the 7" casing. If enough casing is free to be economical to recover, shoot off at free point.

Spot 30 sack cement plug on casing stub, pull casing.

Spot a 50' plug at the base of the surface casing.

Place a 10 sack cement plug and 4" x 4' plug and abandonment marker in the top of the surface casing.

Clean location.

If casing is not pulled, pump 30 sacks of cement into the 7" x 10 3/4" casing annulus.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed By:

SIGNED **L. O. Van Ryan**

TITLE **Petroleum Engineer**

DATE **6-4-69**

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: