Form 3160-5 (June 1990)

UNITED STATES DEPARTMENT OF THE INTERIOR

FORM APPROVED igut Burton No. 1004-0135 Expires: March 31, 1993

	BUREAU OF LAND MANAGEMENT	NM-23738
	NDRY NOTICES AND REPORTS ON WELLS or proposals to drill or to deepen or reentry to a different report of the proposals and proposals.	
	SUBMIT IN TRIPLICATE	7. If Unit or CA, Agreement Designation
1. Type of Well		S. Well Name and No.
Wett Gas Wett Wett 2. Name of Operator	Other	Margarita Com #1
MERRION OIL & GA	S CORPORATION	9. API Well No.
3. Address and Telephone No.	armington, NM 87499 505/327-9801	10. Field and Pool, or Exploratory Area
4. Location of Well (Footage, Sec., T., R., M., or Sarvey Description)		Counselors Gallup
1820' FNL Sec 15, T2	53M' Bem	Rio Arriba, NM
12. CHECK APPI	ROPRIATE BOX(s) TO INDICATE NATURE OF NOTIC	E, REPORT, OR OTHER DATA
TYPE OF SUBN	TYPE O	F ACTION TO THE PROPERTY OF TH
X Notice of latest		Change of Plans New Construction
	MAD 1 111002 Progring Back	Non-Routine Fracturing
Subsequent Rep	Sort MAR1 1/1892 Plugging Back Casing Repair	Water Shed-Off
Final Abandess	CON DIV Altering Cooling	Conversion to Injection Dispose Water
•	DIST 2	
	DIST. 3	Consisten or Recomptonen Report and Log (orm.)
13. Describe Proposed or Companies	Assessment of the control of the con	d deep of starting any proposes work. If well is directionally drilled.
give subsurtace locations a	a Operations (Clearly state all permanes details, and give permanes dates, including estimates and measured and true vertical decails for all markers and zones pertinent to this work.)*	d date of starting any proposed work. If well is directionally druled.
give subsurtace locations a	Assessment of the control of the con	dease of starting any proposed work. If well is directionally druled,
give subsurtace locations a	a Operations (Clearly state all permanes details, and give permanes dates, including estimates and measured and true vertical decails for all markers and zones pertinent to this work.)*	a date of starting any proposed work. If well is directionally drilled,
we pla	a Operations (Clearly state all pertunent details, and give pertunent dates, including estimates and measured and crue vertical decais for all markers and zones pertunent to this work.)* an to plug this well. Following is the procedure:	ot 38 sx 'B' w/ 50-50 poz and 6% gel
We pla	a Operations (Clearly state all pertunent details, and give pertunent dates, including estimated and drue vertical decais for all markets and zones pertinent to this work.)* an to plug this well. Following is the procedure: MIRU. POH w/ 5600' of 2-3/8" tbg. RIH w/ workstring open end to 5692'. RU Cement Co. Spo	at date of starting any proposed work. If well is directionally drilled.
We planting the subsurface social with the subsu	a Operanous (Clearly state all pertunent details, and give pertunent dates, including estumated and drue vertical decais for all markers and zones pertunent to this work.)* an to plug this well. Following is the procedure: MIRU. POH w/ 5600' of 2-3/8" tbg. RIH w/ workstring open end to 5692'. RU Cement Co. Specarross Gallup perfs to 5237'. Pull and reverse clean.	a date of starting any proposed work. If well is directionally drilled. RECEIVED BLM RECEIVE BLM BLM BLM BLM BLM BLM BLM BL
We plant 1.) 2.)	a Operations (Clearly state all pertunent details, and give pertunent dates, including estimated management and crue vertical decahs for all markers and zones pertunent to this work.)* an to plug this well. Following is the procedure: MIRU. POH w/ 5600' of 2-3/8" tbg. RIH w/ workstring open end to 5692'. RU Cement Co. Sporacross Gallup perfs to 5237'. Pull and reverse clean. WOC. Tag cement top. Circ hole full of 9.0 ppg mud. Pull to 3693'. Spot 25 sx (same recipe as above) across Climpul to 2045'. Spot 25 sx (same recipe as above) across Pic to 1604'. Displace w/ mud.	ot 38 sx 'B' w/ 50-50 poz and 6% gel ffhouse to 3250'. Displace w/ mud. tured Cliff, Fruitland and Ojo Alamo
We planting subsurface socialisms with the planting subsurface socialisms with the planting subsurface socialisms and subsurface socialisms with the planting subsurface socialisms and subsurface socialisms and subsurface socialisms and subsurface socialisms with the planting subsurface socialisms and su	a Operations (Clearly state all pertunent details, and give pertunent dates, including estimated management and crue vertical decahs for all markers and zones pertunent to this work.)* an to plug this well. Following is the procedure: MIRU. POH w/ 5600' of 2-3/8" tbg. RIH w/ workstring open end to 5692'. RU Cement Co. Sporacross Gallup perfs to 5237'. Pull and reverse clean. WOC. Tag cement top. Circ hole full of 9.0 ppg mud. Pull to 3693'. Spot 25 sx (same recipe as above) across Climpul to 2045'. Spot 25 sx (same recipe as above) across Pic to 1604'. Displace w/ mud.	ot 38 sx 'B' w/ 50-50 poz and 6% gel ffhouse to 3250'. Displace w/ mud. tured Cliff, Fruitland and Ojo Alamo
We plant 1.) 2.) 3.) 4.) 5.)	an to plug this well. Following is the procedure: MIRU. POH w/ 5600' of 2-3/8" tbg. RIH w/ workstring open end to 5692'. RU Cement Co. Speacross Gallup perfs to 5237'. Pull and reverse clean. WOC. Tag cement top. Circ hole full of 9.0 ppg mud. Pull to 3693'. Spot 25 sx (same recipe as above) across Clippul to 2045'. Spot 25 sx (same recipe as above) across Pic	ot 38 sx 'B' w/ 50-50 poz and 6% gel ffhouse to 3250'. Displace w/ mud. SEE ATTRACTED FOR short is directionally drilled. RECTIVELY RECTIVE RE
3.) 4.) 5.) 6.)	a Operations (Clearly state all pertunent details, and give pertunent dates, including estimated management and crue vertical decahs for all markets and zones pertunent to this work.)* an to plug this well. Following is the procedure: MIRU. POH w/ 5600' of 2-3/8" tbg. RIH w/ workstring open end to 5692'. RU Cement Co. Sporacross Gallup perfs to 5237'. Pull and reverse clean. WOC. Tag cement top. Circ hole full of 9.0 ppg mud. Pull to 3693'. Spot 25 sx (same recipe as above) across Clippull to 2045'. Spot 25 sx (same recipe as above) across Pic to 1604'. Displace w/ mud. Pull to 263'. Spot 15 sx (same recipe as above) across Pic to 1604'. Spot 15 sx (same recipe as above) across Csg Rig down. Install P&A marker. Reclaim location. Move cong is true and correct	ot 38 sx 'B' w/ 50-50 poz and 6% gel ffhouse to 3250'. Displace w/ mud. SEE ATTRACTED FOR short is directionally drilled. RECTIVELY RECTIVE RE
We plan 1.) 2.) 3.) 4.) 5.)	a Operanone (Clearly state all pertunent details, and give pertunent dates, including esturated measured and crue vertical decails for all markets and zones pertunent to this work.)* an to plug this well. Following is the procedure: MIRU. POH w/ 5600' of 2-3/8" tbg. RIH w/ workstring open end to 5692'. RU Cement Co. Spot across Gallup perfs to 5237'. Pull and reverse clean. WOC. Tag cement top. Circ hole full of 9.0 ppg mud. Pull to 3693'. Spot 25 sx (same recipe as above) across Clippull to 2045'. Spot 25 sx (same recipe as above) across Pic to 1604'. Displace w/ mud. Pull to 263'. Spot 15 sx (same recipe as above) across Pic to 1604'. Spot 15 sx (same recipe as above) across Cignon Rig down. Install P&A marker. Reclaim location. Move of	ot 38 sx 'B' w/ 50-50 poz and 6% gel fifthouse to 3250'. Displace w/ mud. SEE ATTEMATED STORY APPROVED APPROVED
We plant 1.) 2.) 3.) 4.) 5.) 6.) 7.)	a Operanous (Clearly state all pertunent details, and give pertunent dates, including esturated management and crue vertical decahs for all markers and zones pertunent to this work.)* an to plug this well. Following is the procedure: MIRU. POH w/ 5600' of 2-3/8" tbg. RIH w/ workstring open end to 5692'. RU Cement Co. Spondaross Gallup perfs to 5237'. Pull and reverse clean. WOC. Tag cement top. Circ hole full of 9.0 ppg mud. Pull to 3693'. Spot 25 sx (same recipe as above) across Climpul to 2045'. Spot 25 sx (same recipe as above) across Pic to 1604'. Displace w/ mud. Pull to 263'. Spot 15 sx (same recipe as above) across Pic to 1604'. Spot 15 sx (same recipe as above) across Climpul to 263'. Spot 15 sx (same recipe as above) across Climpul to 263'. Spot 15 sx (same recipe as above) across Climpul to 263'. Spot 15 sx (same recipe as above) across Climpul to 263'. Spot 15 sx (same recipe as above) across csg Rig down. Install P&A marker. Reclaim location. Move that the state of the stat	ot 38 sx 'B' w/ 50-50 poz and 6% gel fifthouse to 3250'. Displace w/ mud. SEE ATTEMATED STORY APPROVED APPROVED

MERRION OIL AND GAS CORP. WELLBORE SCHEMATIC

WELL Margarita Com #1

LOCATION 1820' FNL 810' FEL Sec 15, T23N1, RGW Rio anibe G, NM

ENG: OFS DRFT: M.E.G.


DATE: 10-10-91

ELEVATION

GL: 500 6949' KB: 500 6962'

FORMATION TOPS:

Ojo alamo 1675'
Fruitland 2000'
PC 2095'
Cliffhones 3643'
Pt Lookont 4360'
Mancos 4568'
Gally 5295'



UNITED STATES DEPARTMENT OF THE INTERIOR

BUREAU OF LAND MANAGEMENT FARMINGTON RESOURCE AREA 1235 LA PLATA HIGHWAY FARMINGTON, NEW MEXICO 87401

Attachment to Notice of

Re: Permanent Abandonment

Intention to Abandon

Well: 1 Margarita Com

CONDITIONS OF APPROVAL

- 1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal Leases."
- 2. Mark Kelly with the Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 326-6201.
- 3. Blowout prevention equipment is required.
- 4. The following modifications to your plugging program are to be made (when applicable):

Office Hours: 7:45 a.m. to 4:30 p.m.

GENERAL REQUIREMENTS FOR PERMANENT ABANDONMENT OF WELLS ON FEDERAL AND INDIAN LEASES FARMINGTON RESOURCE AREA

- 1. Secure prior approval either on a Sundry Notice (Form 3160-5) or verbally from the Fluids Drilling & Production Section at this office before changing the approved plugging program.
- 2. Plugging equipment used shall have separate mixing and displacement pumps and a calibrated tank to assure proper displacement of plugs. The Operator is responsible for providing all measuring devices needed to assure proper measurement of materials being used.
- 3. A proper tank or pit will be used to contain all fluids pumped from the well during plugging operations. Unattended pits are to be fenced.
- 4. All cement plugs are to be placed through tubing (or drillpipe) and shall be a minimum of 100 feet in length with 50% excess inside casing or 100% excess when plug is set in open hole or squeezed into perforations. 15.6#/gal slurry weight is to be used when using class B neat cement or when CaCl₂ is used. Use the recommended slurry weight of other type cements when they are used (Class C, Pozzolan etc.).
- 5. Any cement plugs placed when well is not full of fluid, or when well may be taking fluid, (i.e. across perfs-unless bridge plug or retainer is used, across bad csg., or fresh water formations) will be tagged (touched) after cement has set to verify proper location.
 - The first plug below the surface plug shall generally be tested by either tagging the plug with the working pipe string, or pressuring to a minimum pump (surface) pressure of 1000 psig, with no more than a 10 percent drop during a 15-minute period (cased hole only). If the integrity of any other plug is questioned, it must be tested in the same manner. Also, any cement plug which is the only isolating medium for a fresh water interval or a zone containing a valuable mineral deposit should be tested by tagging with the drill string.
- 6. Mud must be placed between plugs. Plugging mud is to be made up with a minimum of 15 lbs/bbl of sodium bentonite, and a nonfermenting polymer.

 Minimum consistency of plugging mud must be 9 lbs/gal and with a minimum viscosity of 50 sec/qt. Fresh water is to be utilized for mixing mud.
- 7. Following the placement of a cement plug, the withdrawl rate for at least the length of the cement plug shall not exceed 30 ft/min, in order to minimize the contamination of the plug.

- 8. Within 30 days after plugging work is completed, file a Sundry Notice (Subsequent Report of Abandonment, Form 3160-5), in quintuplicate with Area Manager, Bureau of Land Management, 1235 La Plata Highway, Farmington, NM 87401. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. Show date well was plugged.
- 9. All permanently abandoned wells are to be marked with a regulation marker (4" pipe extending 4' above the ground line) containing the information as specified in 43 CFR 3162.6(d). Unless otherwise approved.
- 10. After plugging work is completed the surface is to be rehabilitated in accord with instructions from the Fluids Surface Management Section of the Farmington Resource Area Office.

All above are minimum requirements. The period of liability under the bond of record will not be terminated until the lease is inspected and surface work approved.

Please advise this office when the well location is ready for final inspection.

Failure to comply with the above conditions of approval may result in an assessment for noncompliance and/or a Shut-in Order being issued pursuant to 43 CFR 3163.1.

You are further advised that any instructions, orders or decisions issued by the Bureau of Land Management are subject to administrative review pursuant to 43 CFR 3165.3 and appeal pursuant to 43 CFR 3165.4 and 43 CFR 4.700.