

UNITED STATES-  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE  
(Other instructions on re-  
verse side)

Form Approved  
Budget Bureau No. 1004-0105  
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use APPLICATION FOR PERMIT for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	5. LEASE DESIGNATION AND SERIAL NO. CONTRACT 55A
2. NAME OF OPERATOR DAVE M. THOMAS, JR.	6. IF INDIAN, ALLOTTEE OR TRIBE NAME JICARILLA APACHE
3. ADDRESS OF OPERATOR P. O. BOX 2026, FARMINGTON, NM 87499-2026	7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface  790' FSL, 790' FWL	8. FARM OR LEASE NAME CHACON JICARILLA APACHE "D"
	9. WELL NO. 104
	10. FIELD AND POOL, OR WILDCAT WEST LINDRITH GALLUP-DAKOTA
	11. SEC. T. R. M. OR BLK. AND SURVEY OR AREA SEC. 25, T23N, R3W, N.M.P.M.
14. PERMIT NO.	12. COUNTY OR PARISH 13. STATE SANDOVAL NM
15. ELEVATIONS (Show whether of RT. CR. etc.)	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETION <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON <input type="checkbox"/>	SEALING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT <input checked="" type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANT <input type="checkbox"/>	(Other) <input type="checkbox"/>	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

THE SUBJECT WELL WAS PLUGGED AND ABANDONED PER ATTACHED REPORT.

BELVA CHRISTENSEN WITH THE BUREAU OF LAND MANAGEMENT WITNESSED THE PLUGGING AND ABANDONMENT OPERATIONS.

RECEIVED

AUG 12 1992

OIL CON. DIV.

DIST. 3

Approved as to plugging of the well bore.  
Liability under bond is retained until  
surface restoration is completed.

019 FARMINGTON, N.M.

52 AUG -5 AM 11:39

RECEIVED  
BLM

18. I hereby certify that the foregoing is true and correct

SIGNED

*James R. Roney*

TITLE AGENT FOR DAVE M. THOMAS, JR.

DATE AUGUST 3, 1992

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL IF ANY:

TITLE

APPROVED

AUG 7 1992

AREA MANAGER

\*See instructions on Reverse Side

(505) 325-1211

# BEDFORD INC.

P.O. BOX 2239

FARMINGTON, NEW MEXICO

87499-2239

July 30, 1992

Dave Thomas, Jr.  
P.O. Box 2026  
Farmington, NM 87499

## *PSH Report*

For plug and abandonment of your Chacon Jicarilla D #104,  
located SW/4, Sec. 25, T23N, R3W, Sandoval County, New Mexico.

07/27/92 Drive rig and equipment to location. Safety meeting.  
Rig up and blow well down. ND flow tee and POH with  
96 3/4" and 189 5/8" rods; LD rods. Total of 285  
rods. ND wellhead and release tubing anchor. NU BOP  
and POH with 2-3/8". Shut in well. SDFN.

Note all cement is Class B neat, Y - 1.18 Cf/sx.

07/28/92 RIH with tubing to 7346'. Plug #1 from 7346' to 6740'  
with 46 sxs cement (54cf). POH to 6000'; WOC 4 hrs.  
RIH and tag cmt at 6067'. Pressure test casing to  
550#, OK. Spot 38 B 9#, 50 vis mud fm 6867' to 4545'.  
POH to 4536'. Plug #2 fm 4536' to 4378' with 12 sxs  
cement, POH to 4378'. Spot 23 B 9# mud to 3000'. POH  
to 2996'.

Plug #3 from 2996' to 2334' with 50 sxs (59cf) cement,  
POH to 1700'. SDFN.

07/29/92 RIH with tubing and tag cement at 2269'. Spot 12 B 9#  
mud from 2269' to 1815'. POH to 1827'. Plug #4 fm  
1827' to 1669' with 12 sxs (14cf) cement; POH to 1669'  
spot 9# mud from 1669' to surface. POH and LD tubing.  
Perforate 2 holes at 332'; circulate out bradenhead.  
Plug #5 fm 332' to surface with 110 sxs (130 cf) cmt;  
circulated good cement to surface. Shut in well.

ND BOP and dig out wellhead. Cut off wellhead and  
install dry hole marker with 10 sxs cement. Rig down  
and move off location. Job Complete.