

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT--" for such proposals.)

5. LEASE DESIGNATION AND SERIAL NO.

NM 38584

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Federal 26

9. WELL NO.

22

10. FIELD AND POOL, OR WILDCAT

Wildcat

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 26, T23N, R6W

12. COUNTY OR PARISH

Sandoval

13. STATE

N.M.

OIL ☒ GAS ☐ OTHER ☐
WELL WELL

2. NAME OF OPERATOR

Dietrich Resources Corporation

3. ADDRESS OF OPERATOR

410 17th Street, Suite 2450, Denver, Colorado 80202

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)

At surface

1650' FWL and 1650' FNL Sec. 26,

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

7040 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Procedure to Plug and Abandon the Federal 26 #22 Well:

1. P.O.H. with the rods, install BOP and pull the 2 3/8" tubing.
2. R.I.H. with a 4 1/2" cement retainer on the 2 3/8" tubing, set at 5200' (Gallup perforations 5269' to 5603'), load hole with water, cement with 50 sks. Class B neat. (59 cu. ft.)
3. P.O.H. with the tubing to 3615' (top of Mesa Verde at 3565') and spot a 15 sks.(18 cu. ft.) Class B neat plug.
4. P.O.H. with the tubing and perforate two (2) holes at 2115', establish circulation and pump 225 sks. (265 cu. ft.) Class B neat down casing, displacing the cement to 1475'. This volume of cement will cement the top 50' of the Picture Cliff and extend to 50' above the Ojo Alamo. (top of Ojo Alamo at 1525', Top of Pictured Cliff at 2065')
5. Perforate two (2) holes at 343' (bottom of 8 5/8" surface casing at 293') cement with 105 sks. (124 cu. ft.), circulating cement to the surface in the annular space between the 4 1/2" and 8 5/8" casings, leaving the 4 1/2" casing full of cement.
6. Install dry hole marker and restore the location.

The estimated starting date to begin the above outlined procedure to plug and abandon is 12-21-85.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Agent

DATE 12-20-85

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side