

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

5. LEASE DESIGNATION AND SERIAL NO.

NM-23734

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

1.

OILWELL ☒ GAS WELL ☐ OTHER

7. UNIT AGREEMENT NAME

2. NAME OF OPERATOR Gary Williams Production Company

8. FARM OR LEASE NAME

San Isidro 6

3. ADDRESS OF OPERATOR 1775 Sherman St., Ste 1925

9. WELL NUMBER

Denver, CO 80202 (303) 831-4673

#13

4. LOCATION OF WELL

AT SURFACE

400' FSL, 800' FWL Section 6-T20N-R3W

10. FIELD AND POOL, OR WILDCAT

Rio Puerco Minerals  
Undesignated Cellar

11. SEC., T., R., OR BLK. AND SURVEY

SECTION 6 - T20N - R3W

14. PERMIT NO.

15. ELEVATIONS

6952' GL

12. COUNTY OR PARISH

SANDOVAL

13. STATE

N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐ PULL OR ALTER CASING ☐  
FRACTURE TREAT ☐ MULTIPLE COMPLETE ☐  
SHOOT OR ACIDIZE ☐ ABANDON ☒  
REPAIR WELL ☐ CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐ REPAIR WELL ☐  
FRACTURE TREATMENT ☐ ALTERING CASING ☐  
SHOOTING OR ACIDIZING ☐ ABANDONMENT ☐  
(OTHER) ☐

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS

Request approval to abandon well per the attached procedure.

RECEIVED  
OCT 27 1994

OIL CON. DIV.  
DIST. 3

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Atty-in-Fact

DATE

2 May, 94

(This space for Federal or State office use)

Acting

Chief, Lands and Mineral Resources

APPROVED BY

Joseph Jaramilla

TITLE


DATE

OCT 25 1994

CONDITIONS OF APPROVAL, IF ANY:

2

Samuel Gary, Jr. & Associates  
 San Isidro 6-13 Wellbore Diagram  
 SWSW Sec. 6 T20N R3W  
 Sandoval County, NM



PREPARED BY: S.C. FREDRICKSON  
 PREPARED ON: 5/29/92  
 REVISED BY: C. H. JOHNS  
 REVISED ON: 4/1/94

**SAN ISIDRO #6-13**  
**Plug and Abandon Procedure**

SEE ATTACHED WELL DIAGRAM FOR TUBULAR DETAILS

1. Move in, rig up, service rig.
2. Pump tank bottoms into well.
3. Nipple up BOP's. Pick up tubing string and TIH to 4049'. Fill hole with gelled water.
4. TIH and set Class "H" cement plugs as follows: Plug #1, 25 sacks (30 cu. ft.) @ 4049' to 3949', Plug #2, 25 sacks (30 cu. ft.) from 1250' to 1150'.
5. Perforate the 7" casing with 4 holes at 175'. TIH to 223'. Establish circulation up the 9-5/8" x 7" annulus.
6. Mix and pump 100 sacks (120 cu. ft.) down 7" casing and circulate cement to surface. Leave cement to surface inside 7" casing.
7. Cut off casing below ground level and erect dry hole marker.
8. Remove production equipment and reclaim location to BLM specifications.

March 31, 1994  
Charles H. Johns