


NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION



Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Federal <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. NM 019399

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator El Paso Natural Gas Company 3. Address of Operator Box 990, Farmington, New Mexico - 87401 4. Location of Well UNIT LETTER P 1130 FEET FROM THE South LINE AND 1175 FEET FROM THE East LINE, SECTION 23 TOWNSHIP 24N RANGE 2W NMPM.	7. Unit Agreement Name 8. Farm or Lease Name Federal 9. Well No. 5 10. Field and Pool, or Wildcat So. Blanco P. C.
15. Elevation (Show whether DF, RT, GR, etc.) 7320' GL	12. County Rio Arriba

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-production it is intended to plug and abandon this well in the following manner:

Kill well and spot a 25 sack cement plug on bottom (est. top of plug 3100').

Pull tubing.

Determine free point of 5 1/2" casing by stretch. Shoot casing off above free point and spot a 30 sack cement plug by displacing cement down the casing (30 sacks = 105').

Pull 5 1/2" casing. Place a 25 sack cement plug across base of surface casing.

Place a 10 sack cement plug at surface, install a dry hole marker and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Don Read</u>	TITLE <u>Petroleum Engineer</u>	DATE <u>9-9-69</u>
APPROVED BY <u>Ernest C. Clark</u>	TITLE <u>Sup. Dist. Eng.</u>	DATE <u>9-11-69</u>
CONDITIONS OF APPROVAL, IF ANY:		