

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Federal <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input type="checkbox"/> WELL GAS <input checked="" type="checkbox"/> WELL OTHER- <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator El Paso Natural Gas Company		8. Farm or Lease Name Abraham E
3. Address of Operator Box 990, Farmington, New Mexico - 87401		9. Well No. 2
4. Location of Well UNIT LETTER G 1850 FEET FROM THE North LINE AND 1850 FEET FROM East 24 TOWNSHIP 24N RANGE 2W N.M.P.M. THE LINE, SECTION TOWNSHIP RANGE N.M.P.M.		10. Field and Pool, or Wildcat So. Blanco P. C.
15. Elevation (Show whether DF, RT, GR, etc.) 7422' GL		12. County Rio Arriba

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Because of non-production it is planned to plug and abandon this well as follows:

Kill well and spot 30 sack cement plug on bottom (30 sacks will fill from P.B.T.D. of 3415' to 3150').

Perforate 4 holes at 3100' and spot 30 sack plug.

Determine free point of 5 1/2" casing. If the free point is 800' or deeper, shoot off above free point and spot a 30 sack cement plug on casing stub by displacing down the freed casing (30 sk. = 105'). If less than 800' of casing is free, casing will not be shot.

If casing is pulled, place a 25 sack plug in bottom of surface casing.

If casing is not pulled place a 15 sack plug in the 5 1/2" - 8 5/8" casing.

Place a 15 sack plug at surface with a P & A marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED F. H. WOOD TITLE Petroleum Engineer DATE May 22, 1969

APPROVED BY Emory C. Ames TITLE Sup. Dist. III DATE 5-26-69

CONDITIONS OF APPROVAL, IF ANY:

