Form 9-331 (May 1963)

## UNITED STATES SUBMIT IN TRIPLICATE\* DEPARTMENT OF THE INTERIOR verse side)

Form approved Budget Burean No. 42-R1424. 5. LEASE DESIGNATION AND SERIAL NO.

GEOLOGICAL SURVEY

	6. IF INDIAN,	ALLOTTEE OR TE	IBE NAME
SUNDRY NOTICES AND REPORTS ON WELLS			
Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.			

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  Use "APPLICATION FOR PERMIT—" for such proposals.)	
1.	7. UNIT AGREEMENT NAME
OIL GAS OTHER	
2. NAME OF OPERATOR	8. FARM OR LEASE NAME
Petroleum Consultants, Inc.	Connie
3. ADDRESS OF OPERATOR	9. WELL NO.
1420 Carlisle Blvd., NE Suite 202, Albuquerque, NM 87110	5
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface	Escrito Gallup
1850' FNL & 1650' FEL	11. SEC., T., R., M., OR BLE. AND SURVEY OR AREA 21, T24N, R7W
	12 COUNTY OR PARISH 13. STATE

15. ELEVATIONS (Show whether DF, RT, GR, etc.) 14. PERMIT NO. Rio Arriba New Mexico 7111 KB & 7100 GR

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data 16.

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:				
TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE		PULL OR ALTER CASING MULTIPLE COMPLETE ABANDON*	<u> </u>	WATER SHUT-OFF FRACTURE TREATMENT SHOOTING OR ACIDIZING	REPAIRING WELL ALTERING CASING ABANDONMENT*	_
REPAIR WELL (Other)		CHANGE PLANS		(Other)	ultiple completion on Well Report and Log form.)	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

The subject well has number of casing leaks in addition to packer stuck in hole at 5406'.

It is proposed the well be plugged and abandoned as follows:

- 15 sack cement plug 5300-5400'
- 30 sack cement plug 3100-3450'
- 35 sacks cement plug squeezed into perforation at 2000' with plug left in casing from 1900-2000'
- 35 sack cement plug squeezed into perforation at 300' with plug left in casing from 200-300'
- 10 sack cement plug 0-100'

Install dry hole marker and clean up and restore location to U.S.G.S. specifications.

18. I hereby certif 9-27-76 Agen DATE SIGNED Jack D. Cook (This space for Federal or State office use) DATE TITLE APPROVED BY . CONDITIONS OF APPROVAL, IF ANY: