

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF078924

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL ☒ GAS ☐
WELL WELL OTHER

2. NAME OF OPERATOR
Petroleum Consultants, Inc.

3. ADDRESS OF OPERATOR
1420 Carlisle Blvd., NE Suite 202, Albuquerque, NM 87110

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1850' FNL & 1650' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

7111 KB & 7100 GR

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Connie

9. WELL NO.

5

10. FIELD AND POOL, OR WILDCAT

Escrito Gallup

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

21, T24N, R7W

12. COUNTY OR PARISH 13. STATE

Rio Arriba

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☐

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☒

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*

9-25-76

The subject well was plugged and abandoned as follows:
Rig up Halliburton and Go International

1. Spot 15 sacks cement plug from 5160-5372'
2. Spot 30 sacks cement plug from 3040-3470'
3. Perforate casing at 2000' with four way squeeze shot.
4. Squeeze perforation with 35 sacks cement to 1000 psi leaving
plug from 1900-2000'.
5. Perforate casing at 300' with four way squeeze shot. Squeeze
perforation with 35 sacks cement - cement circulated into
8 5/8X4 1/2" annulus. Left plug from 200-300' in 4 1/2" Casing.
6. Place 10 sacks cement plug in 4 1/2" casing from 0-100'.
7. Install dry hole marker.
8. Location to be cleaned up and restored to U.S.G.S. specifications.
Well plugged and abandoned 9-25-76.

18. I hereby certify that the foregoing is true and correct

SIGNED

Jack D. Cook

TITLE Agent

DATE 9-27-76

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: