

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☒ well gas ☐ well other ☐  
2. NAME OF OPERATOR  
Grace Petroleum Corporation  
3. ADDRESS OF OPERATOR  
80202  
3 Park Central #200, 1515 Arapahoe, Denver, CO  
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: 790'FNL @ 1720'FWL  
AT TOP PROD. INTERVAL:  
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>		<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>		<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>		<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>		<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>		<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>		<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>		<input type="checkbox"/>
ABANDON*	<input type="checkbox"/>		<input checked="" type="checkbox"/>

(other) abandon Dakota interval

5. LEASE  
SF-078562  
6. IF INDIAN, ALLOTTEE OR TRIBE NAME  
7. UNIT AGREEMENT NAME  
8. FARM OR LEASE NAME  
Lybrook  
9. WELL NO.  
1-19  
10. FIELD OR WILDCAT NAME  
Lybrook  
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
Sec 19, 24N-6W  
12. COUNTY OR PARISH  
Rio Arriba  
13. STATE  
NM  
14. API NO.  
15. ELEVATIONS (SHOW DF, KDB, AND WD)  
6631 GL

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

February, 1980

- 1) Kill Gallup NDWH NU BOP
- 2) POOH w 2 strings 2-3/8" tubing
  - 1) Gallup set @ 5413
  - 2) Dakota set @ 6423
- 3) RIH w CIPB on wireline set @ 6000'. Drop 2 sx cmt on top w dump Dist 3
- 4) Set RITS packer on 2-3/8" tubing at 5315 KB
- 5) Pressure test to 500 psi. Held OK.
- 6) Acidize w 2400 gal 7½% HCL @ 4.5 BPM @ 1500 psi avg
- 7) POOH w packer. RIH w 2-3/8" string w SN set @ 5344' KB
- 8) NUWH
- 9) Put on production

Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Kim O. Lube TITLE Operations Eng. DATE 9-26-80

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

NMOCC

ACCEPTED FOR RECORD

OCT 10 1980

\*See Instructions on Reverse Side

FARMINGTON DISTRICT

BY 2