

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Federal <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name Federal
3. Address of Operator Box 990, Farmington, New Mexico - 87401	9. Well No. 4
4. Location of Well UNIT LETTER 0, 1110 FEET FROM THE South LINE AND 1790 FEET FROM East LINE, SECTION 14 TOWNSHIP 24N RANGE 2W NMPM.	10. Field and Pool, or Wildcat So. Blanco P. C.
15. Elevation (Show whether DF, RT, GR, etc.) 7382' GL	12. County Rio Arriba

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

### SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.


Due to non-production it is planned to plug and abandon this well as follows:

Kill well and spot 25 sack cement plug on bottom (est. top of plug at 3230').

Pull tubing, then determine free point of 5 1/2" casing by stretch, shoot casing off above free point and spot a 30 sack cement plug on top of stub by displacing a cement down the casing (30 sks. = 105').

Pull 5 1/2" casing, then place a 25 sack cement plug across base of surface casing.

Place a 10 sack cement plug at surface, install a dry hole marker and clean the location.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Don Read TITLE Petroleum Engineer DATE 8-26-69

APPROVED BY Emory C. Curren TITLE Sup. Dist. III DATE 8-27-69

CONDITIONS OF APPROVAL, IF ANY: